

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Salter](#) /

> [Salter 1074 BKDR Electronic Digital Kitchen Scale, Max 5 Kg, Cooking, Baking, Add & Weigh, Measures Liquids/Fluids, Hidden Until Lit Display, 1.8 litre Dishwasher Safe Bowl, Pouring Lip, Black single](#)

Salter 1074 BKDR

Salter 1074 BKDR Electronic Digital Kitchen Scale

User Instruction Manual

1. INTRODUCTION

Thank you for choosing the Salter 1074 BKDR Electronic Digital Kitchen Scale. This precision instrument is designed to assist you with accurate measurements for cooking and baking. Featuring a versatile 'Add & Weigh' function and an 'Aquatronic' mode for liquids, it simplifies your culinary tasks. The scale comes with a convenient 1.8-litre dishwasher-safe bowl and a clear, hidden-until-lit display.

2. SAFETY INFORMATION

- Always place the scale on a firm, flat, and stable surface to ensure accurate readings.
- Do not immerse the scale unit in water or any other liquid. The scale unit is not waterproof.
- Clean the scale unit with a damp cloth only. The bowl is dishwasher safe.
- Avoid dropping the scale or subjecting it to strong impacts, as this may damage the internal components.
- Do not overload the scale beyond its maximum capacity of 5 kg / 11 lb.
- Keep batteries out of reach of children. Dispose of used batteries responsibly.

3. PACKAGE CONTENTS

- Salter 1074 BKDR Electronic Digital Kitchen Scale Unit
- 1.8 Litre Dishwasher Safe Weighing Bowl
- 3 x AAA Batteries



Image: The Salter 1074 BKDR kitchen scale, including the main unit, the clear weighing bowl, and three AAA batteries.

4. SETUP

1. **Battery Installation:** Open the battery compartment on the underside of the scale. Insert the 3 x AAA batteries, ensuring correct polarity (+/-). Close the compartment securely.
2. **Placement:** Place the scale on a hard, flat, and level surface. Avoid soft or uneven surfaces that could affect accuracy.
3. **Initial Power On:** Press the **ON/OFF/ZERO** button to turn on the scale. The display will show '8888' then '0' or '0g' when ready for use.



Image: The Salter 1074 BKDR scale unit without the weighing bowl, showing its compact design.

5. OPERATING INSTRUCTIONS

5.1. Basic Weighing

1. Ensure the scale is on a flat surface and powered on. The display should show '0' or '0g'.
2. Place the weighing bowl (if using) onto the scale platform. The display will show the weight of the bowl.
3. Press the **ON/OFF/ZERO** button to reset the display to '0'. This is the 'Add & Weigh' or 'Tare' function.
4. Carefully place the item(s) to be weighed into the bowl or directly onto the platform. The weight will be displayed.



Image: The clear weighing bowl placed on the scale, ready for the tare function before adding ingredients.



Image: A close-up view of the scale's display showing a measurement of 280 grams, with brown sugar in the bowl.

5.2. Unit Conversion

Press the **UNIT** button to cycle through the available measurement units:

- Grams (g)
- Ounces (oz)
- Millilitres (ml) - for liquids (Aquatronic function)
- Fluid Ounces (fl.oz) - for liquids (Aquatronic function)

5.3. Aquatronic Function (Measuring Liquids)

The Aquatronic function allows you to measure liquids accurately. Simply select 'ml' or 'fl.oz' using the **UNIT** button before adding your liquid.



Image: The scale displaying a measurement of 508 ml, indicating milk being weighed in the clear bowl.



Image: Milk being poured into the weighing bowl on the scale, with the display showing an initial measurement of 20 ml.

5.4. Add & Weigh (Tare) Function

This function allows you to weigh multiple ingredients in the same bowl without emptying it. After weighing an ingredient, press the **ON/OFF/ZERO** button to reset the display to '0' before adding the next ingredient.

5.5. Auto Shut-Off

The scale will automatically turn off after a period of inactivity to conserve battery life.

6. CARE AND MAINTENANCE

- **Cleaning:** Wipe the scale platform and body with a damp cloth. Do not use abrasive cleaners or immerse the unit in water. The 1.8L weighing bowl is dishwasher safe for easy cleaning.
- **Storage:** Store the scale in a dry place at room temperature. Avoid extreme temperatures or humidity.
- **Battery Replacement:** If the display shows 'Lo', it indicates low battery. Replace all 3 AAA batteries.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Display shows 'Lo'	Low battery power.	Replace all 3 AAA batteries.
Display shows 'Err'	Scale overloaded.	Remove item(s) immediately. Do not exceed 5 kg / 11 lb.
Inaccurate readings	Scale not on a flat, stable surface; external vibrations; internal error.	Ensure scale is on a firm, level surface. Avoid vibrations. Turn off and on again.
Scale does not turn on	Batteries incorrectly installed or dead.	Check battery polarity or replace batteries.

8. SPECIFICATIONS

- **Model:** 1074 BKDR
- **Brand:** Salter
- **Maximum Capacity:** 5 kg / 11 lb / 5000 ml / 175 fl.oz
- **Graduation:** 1 g / 0.1 oz / 1 ml / 0.1 fl.oz
- **Power:** 3 x AAA batteries (included)
- **Product Dimensions:** 20.3 x 25 x 11.5 cm
- **Product Weight:** 720 g
- **Bowl Capacity:** 1.8 Litres
- **Display Type:** Digital, Hidden Until Lit




Image: Diagram showing the approximate dimensions of the scale with the bowl: 21cm width and 23cm height.

MAX	5kg	11lb	5000ml	175fl.oz
÷	1g	0.1oz	1ml	0.1fl.oz

Image: A table detailing the maximum capacity and graduation for various units: 5kg/1g, 11lb/0.1oz, 5000ml/1ml, 175fl.oz/0.1fl.oz.

9. WARRANTY AND SUPPORT

This Salter product comes with a **15-year guarantee** against defects in materials or workmanship. Please retain your proof of purchase for warranty claims. For support or further inquiries, please refer to the contact information provided with your product packaging or visit the official Salter website.