



[Manuals.plus](#) /

› [Devoko](#) /

› Devoko 4-Piece Patio Furniture Set User Manual

Devoko DV18MBK

Devoko 4-Piece Patio Furniture Set User Manual

Model: DV18MBK | Brand: Devoko

INTRODUCTION

This manual provides essential information for the assembly, operation, maintenance, and troubleshooting of your Devoko 4-Piece Patio Furniture Set. Designed for outdoor use, this conversation set offers a comfortable and stylish solution for your patio, porch, backyard, balcony, or poolside area.

SAFETY INFORMATION

Please read and understand all safety warnings and assembly instructions before using this product. Failure to follow these instructions may result in injury or damage.

- Ensure all components are securely fastened before use.
- Do not overload the furniture. Refer to specifications for weight limits.
- Keep children and pets away from the assembly area.
- Use on a flat, stable surface to prevent tipping.
- Protect the furniture from extreme weather conditions, especially strong winds and heavy rain, by using a protective cover or storing indoors.

PACKAGE CONTENTS

Your Devoko 4-Piece Patio Furniture Set includes the following components:

- 2 x Single Chairs
- 1 x Loveseat
- 1 x Glass Coffee Table
- Assembly Hardware Kit
- Installation Instruction Manual



Figure 1: Complete Devoko 4-Piece Patio Furniture Set.

ASSEMBLY INSTRUCTIONS

Assembly of the Devoko patio furniture set is designed to be straightforward. Please follow the included installation instructions carefully. All necessary hardware is provided.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches. Verify all listed components are present.
2. **Assemble Chairs:** Attach the backrests and seats to the chair frames using the provided screws and tools. Ensure all connections are firm but do not overtighten until all screws are in place.
3. **Assemble Loveseat:** Similar to the chairs, connect the loveseat backrest and seat to its frame.
4. **Assemble Coffee Table:** Secure the legs to the coffee table frame. Carefully place the tempered glass top into the embedded design on the table frame.
5. **Final Tightening:** Once all pieces are assembled, gently tighten all screws to ensure stability. Do not overtighten to avoid damaging the frame.



QUALITY MATERIAL

Super breathable textilene fabric

Figure 2: The breathable textilene fabric provides comfort for seating.



WITH GLASS
35.6"*19.8" extra large glass

Figure 3: The coffee table features a tempered glass top for durability and easy cleaning.




Figure 4: Product dimensions for the chairs, loveseat, and coffee table.

OPERATING INSTRUCTIONS

Your Devoko patio furniture set is designed for comfortable outdoor lounging and conversation. It provides seating for up to four individuals.

- Place the furniture on a level surface in your desired outdoor area, such as a patio, porch, backyard, balcony, or poolside.
- The chairs and loveseat are suitable for seating. The coffee table is ideal for holding beverages, snacks, books, or decorative items.
- Avoid placing excessively hot items directly on the glass table without a coaster.

Your browser does not support the video tag.

Video 1: Official product video showcasing the Devoko 4-piece patio conversation set in an outdoor setting.

MAINTENANCE AND CARE

Proper care will extend the life and appearance of your patio furniture. The materials are designed for durability and

resistance to common outdoor wear.

- **Cleaning:** Wipe the steel frame and textilene fabric with a dry cloth. For deeper cleaning, use a mild soap and water solution, then rinse thoroughly and dry completely to prevent water spots or rust. The tempered glass tabletop is also easy to clean.
- **Protection:** While the frame has a rust-resistant coating, it is advisable to use a protective cover during rainy weather or prolonged periods of non-use to further protect against the elements and prevent potential rust accumulation inside the frames.
- **Storage:** During off-seasons or severe weather, consider storing the furniture indoors or under a robust cover to protect it from extreme temperatures and moisture.
- **Durability:** The super breathable textilene fabric and stable steel structure are designed for long service life, resisting splitting, cracking, fading, rotting, and deterioration.

TROUBLESHOOTING

If you encounter any issues with your patio furniture, please refer to the following common solutions:

Problem	Possible Cause	Solution
Furniture feels wobbly or unstable.	Loose screws or uneven surface.	Ensure all assembly screws are tightened. Move furniture to a flat, level surface.
Rust spots appearing on frame.	Prolonged exposure to moisture, especially in crevices.	Clean rust spots with a mild abrasive and apply a rust-inhibiting paint. Always cover the furniture during rain or store indoors. Ensure proper drainage if water collects inside frames.
Fabric appears dirty or stained.	Accumulation of dirt, dust, or environmental debris.	Wipe with a dry cloth or clean with mild soap and water. Rinse thoroughly and air dry.

SPECIFICATIONS

- **Brand:** Devoko
- **Model Number:** DV18MBK
- **Material:** Steel, Textilene Fabric
- **Color:** Black
- **Item Weight:** 55.6 pounds
- **Product Dimensions (L x W x H):** 35.6 x 22.5 x 30.5 inches
- **Assembled Height:** 9 inches
- **Assembled Width:** 23 inches
- **Assembled Length:** 41 inches
- **Product Care Instructions:** Wipe with Dry Cloth

WARRANTY AND SUPPORT

Devoko is committed to providing quality products and excellent customer service.

- **Customer Service:** For any questions about your product, please contact us through Amazon message. Our friendly customer service team is ready to assist you as soon as possible.

- **Protection Plans:** Extended protection plans are available for purchase to cover your product beyond the standard warranty. Options include 2-Year and 3-Year Protection Plans, as well as a Complete Protect plan.
- **Returns:** This product is eligible for 30-day easy returns.