

[Manuals.plus](#) /

› [OurLeeme](#) /

› OurLeeme RGB LED Outdoor Flood Light (Model VES4051) Instruction Manual

OurLeeme VES4051

OurLeeme RGB LED Outdoor Flood Light (Model VES4051) Instruction Manual

PRODUCT OVERVIEW

The OurLeeme RGB LED Outdoor Flood Light (Model VES4051) is an 8W waterproof landscape spotlight designed for outdoor use. It features RGB color-changing capabilities, adjustable brightness, and multiple dynamic lighting modes, all controllable via an included remote. This light can be installed in two ways: staked into the ground or mounted on a wall, making it versatile for various outdoor lighting needs.



Image: The OurLeeme RGB LED Outdoor Flood Light, showcasing its compact design and included ground stake.

We Pay Attention to Every Detail!



Thick aluminum material with fast heat dissipation



Selected high-brightness LED beads



Threaded knob interface prevents rain erosion



Extended 5ft cable, no worry about the distance from the socket



Image: Close-up view highlighting the thick aluminum material for heat dissipation, high-brightness LED beads, threaded knob interface for water resistance, and extended power cable.

SETUP AND INSTALLATION

This flood light offers flexible installation options to suit your outdoor environment.

Package Contents:

- OurLeeme RGB LED Outdoor Flood Light
- Ground Stake
- Mounting Screws
- Remote Control

Installation Methods:

1. **Ground Stake Installation:** Attach the ground stake to the light fixture. Insert the stake firmly into soft ground in

your desired location, such as a lawn, garden bed, or pathway.

2. **Wall Mount Installation:** Use the provided screws to securely mount the light fixture to a wall or other solid surface. Ensure the mounting surface can support the weight of the light.

After installation, connect the light to an AC 85-265V power source. The light features a 180° adjustable angle, allowing you to direct the illumination precisely where needed.



Image: Illustration showing the two installation methods: mounting on a wall and plugging into the ground with a stake.

Your browser does not support the video tag.

Video: A demonstration of the remote control spotlight, showing its color-changing capabilities and how it can be used in various settings.

OPERATING INSTRUCTIONS

The OurLeeme RGB LED Outdoor Flood Light is controlled using the included remote control. The remote has a range of approximately 10 meters (33 feet).

Remote Control Functions:

- **Power ON/OFF:** Use the dedicated buttons to turn the light on or off.
- **Color Selection:** Choose from 16 static colors to set the desired ambiance.
- **Brightness Adjustment:** Adjust the brightness level for static colors (4 levels available).
- **Dynamic Modes:** Select from 4 dynamic lighting modes (e.g., Flash, Strobe, Fade, Smooth) for animated color changes.
- **Memory Function:** The light will remember the last selected color or mode when turned off and on again.



Image: The remote control, illustrating buttons for RGBW lighting, 16 color changes, 4 dynamic modes, dimmable function, and memory function.



Image: The flood light illuminating outdoor Halloween decorations with vibrant colors.

Your browser does not support the video tag.

Video: A vertical video showcasing the bright and color-changing features of the spotlight.

Your browser does not support the video tag.

Video: A demonstration of the color-changing landscape lighting for outdoor use.

MAINTENANCE

The OurLeeme RGB LED Outdoor Flood Light is designed for durability and minimal maintenance.

Cleaning:

To maintain optimal performance and appearance, periodically clean the light fixture. Use a soft, damp cloth to wipe away dirt and debris. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish or optical components.

Weather Resistance:

The light features an IP65 waterproof design, making it suitable for outdoor use in various weather conditions. The aluminum construction and convex glass provide protection against elements.



Image: The flood light shown in a rainy environment, emphasizing its IP65 waterproof rating for both outdoor and indoor suitability.

TROUBLESHOOTING

If you encounter issues with your OurLeeme RGB LED Outdoor Flood Light, refer to the following common troubleshooting steps:

- **Light not turning on:**
 - Ensure the power cable is securely plugged into a functional AC 85-265V outlet.
 - Verify that the power source is active.
 - Check the remote control battery and replace if necessary.
 - Ensure the remote control is pointed directly at the light and within the 10m (33ft) operating range.
- **Remote control not responding:**
 - Replace the remote control battery.

- Ensure there are no obstructions between the remote and the light's sensor.
- Try operating the light from a closer distance.

- **Inconsistent color changes or modes:**

- Ensure the light is not exposed to extreme temperatures or direct sunlight for prolonged periods, which could affect sensor performance.
- Reset the light by unplugging it for a few minutes and then plugging it back in.

If these steps do not resolve the issue, please contact customer support for further assistance.

SPECIFICATIONS

Detailed technical specifications for the OurLeeme RGB LED Outdoor Flood Light (Model VES4051):



Image: Diagram illustrating the dimensions of the flood light, including the fixture and the ground spike.

Feature	Detail
Brand	OurLeeme
Model Number	VES4051
Power Source	AC 85-265V
Wattage	8W
Light Source	LED
Brightness	800 lumens
Light Color	RGB Colorful
Control Method	Remote Control
Material	Aluminum, Convex glass
Water Resistance Level	IP65 Waterproof
Item Dimensions (L x W x H)	2.91"L x 2.9"W x 4.13"H
Item Weight	11.2 ounces
Power Cable Length	Approx. 14.5" (37cm)
Included Components	Remote Control

WARRANTY AND SUPPORT

The OurLeeme RGB LED Outdoor Flood Light (Model VES4051) comes with a **24-month product warranty** and a **3-month replacement guarantee**. Additionally, a **1-year manufacturer warranty** is provided. For any issues, questions, or support needs regarding your product, please contact the seller or manufacturer directly. Refer to your purchase documentation for specific contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question