

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Disney Frozen](#) /
- › [Disney Frozen Anna Fashion Doll Instruction Manual](#)

Disney Frozen E6710

Disney Frozen Anna Fashion Doll Instruction Manual

Model: E6710

PRODUCT OVERVIEW

The Disney Frozen Anna Fashion Doll is inspired by the character Anna from Disney's movie Frozen 2. This classic doll features long red hair and an outfit designed to replicate her appearance in the film, including removable boots. The doll is designed with 5 points of articulation, allowing for various poses to recreate scenes from the movie or for imaginative play.





Image: Disney Frozen Anna Fashion Doll. The doll is depicted in her iconic outfit from Frozen 2, featuring a dark blue dress with intricate gold patterns, a brown belt, and a flowing purple cape. Her long red hair is styled down, and she wears black boots with gold detailing.

WHAT'S IN THE BOX

- One (1) Anna Fashion Doll
- One (1) Doll Outfit (inspired by Frozen 2)
- One (1) Pair of Removable Boots

KEY FEATURES

- **Movie-Inspired Design:** Doll wears an outfit and cape inspired by Disney Frozen 2.
- **Long Red Hair:** Features long, flowing red hair, styled as seen in the movie.
- **Articulated Posing:** Equipped with 5 points of articulation for dynamic posing and play.
- **Removable Accessories:** Includes removable boots for enhanced play.

SETUP AND FIRST USE

The Anna Fashion Doll comes ready to play directly out of the packaging. No assembly is required.

1. Carefully remove the doll and its accessories from the packaging.
2. Ensure all packaging materials are discarded safely, especially plastic ties or small parts that could pose a choking hazard.
3. The doll's outfit and boots are designed to be removable for costume changes or imaginative play.

OPERATING INSTRUCTIONS

The Anna Fashion Doll is designed for imaginative play and storytelling.

- **Posing:** Utilize the doll's 5 points of articulation (neck, shoulders, hips) to position Anna in various poses, recreating favorite movie scenes or inventing new adventures.
- **Outfit Changes:** The doll's outfit and boots can be removed and put back on. Gently slide clothing off and on to avoid damage.
- **Hair Styling:** Anna's long red hair can be styled. Use a soft brush designed for doll hair to prevent tangling.

CARE AND MAINTENANCE

To ensure the longevity of your Anna Fashion Doll, follow these care guidelines:

- **Cleaning:** Wipe the doll's body with a soft, damp cloth. Do not submerge the doll in water. For clothing, spot clean only.
- **Hair Care:** To prevent tangles, gently brush the doll's hair from the ends upwards. Avoid using heat styling tools on the hair.
- **Storage:** Store the doll in a clean, dry place away from direct sunlight and extreme temperatures to prevent fading or material degradation.

TROUBLESHOOTING

Problem	Solution
Doll's hair is tangled.	Gently comb or brush the hair starting from the ends and working your way up to the roots. Use a doll-specific brush if available.
Outfit is difficult to remove/put on.	Ensure the doll's limbs are positioned correctly to allow for easier removal or application of clothing. Avoid forcing the fabric.
Doll's limbs are stiff.	Gently manipulate the joints to loosen them. Avoid excessive force to prevent damage.

PRODUCT SPECIFICATIONS

Product Dimensions	2 x 6.5 x 14 inches
Item Weight	3.77 ounces
Model Number	E6710
ASIN	B07MM2R5DP

Manufacturer Recommended Age	3 years and up
Manufacturer	Hasbro
Language	English
Release Date	October 3, 2019

SAFETY INFORMATION

This product is intended for children aged 3 years and older. Adult supervision is recommended during play, especially with younger children.

- **Choking Hazard:** Contains small parts (e.g., removable boots). Not suitable for children under 3 years due to potential choking hazards.
- **Material Safety:** All materials used are non-toxic and meet international safety standards for toys.
- **Proper Use:** Do not modify the doll or its accessories. Use only as intended for play.

WARRANTY AND SUPPORT

For any questions regarding the Disney Frozen Anna Fashion Doll, please contact the manufacturer, Hasbro, directly. Information regarding product warranty and customer support can typically be found on the official Hasbro website or through their customer service channels.

Please retain this instruction manual for future reference.

© Copyright Disney. Manufactured by Hasbro.
All rights reserved.