



[Manuals.plus](#) /

› [MLMLANT](#) /

› MLMLANT SC541 Steam Cleaner User Manual

MLMLANT SC541

MLMLANT SC541 Steam Cleaner User Manual

Multipurpose Steam Mop for Home and Kitchen Cleaning

IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using the MLMLANT SC541 Steam Cleaner. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the appliance is unplugged from the power outlet before filling with water, cleaning, or performing maintenance.
- Do not leave the steam cleaner unattended while it is operating.
- Use only clean tap water or distilled water. Do not add cleaning solutions, perfumes, or other chemicals to the water tank, as this can damage the appliance and void the warranty.
- The steam produced is very hot. Avoid direct contact with steam. Keep hands, face, and body away from the steam nozzle.
- Do not open the water tank cap while the unit is pressurized or hot. Allow the unit to cool down and release pressure before refilling.
- Keep the appliance out of reach of children and pets.
- Do not immerse the steam cleaner in water or any other liquid.
- Regularly inspect the power cord and hose for any damage. Do not operate if damaged.

PRODUCT OVERVIEW AND COMPONENTS

The MLMLANT SC541 is a versatile steam cleaner designed for deep cleaning various surfaces using high-temperature steam, eliminating the need for harsh chemicals. It comes with 20 accessories to tackle different cleaning tasks.



Image: The MLMLANT SC541 Steam Cleaner unit displayed with its full set of 20 accessories, including various brushes, nozzles, and cloths.

Key Features:

- **Variable Steam Control:** Adjust steam output for different cleaning needs.
- **Large Capacity Tank:** 1.5-liter water tank provides up to 35 minutes of continuous steam.
- **Fast Heating:** Heats up in under 5 minutes.
- **Child & Pet Safe:** Sanitizes surfaces without chemicals, killing 99.99% of bacteria.
- **Extended Reach:** Features a 5-meter power cord and 5-foot steam hose for maneuverability.

MLMLANT STEAM CLEANER

FAST HEATING 2000W Rapid & Powerful Steaming





Image: A close-up view of the MLMLANT steam cleaner, emphasizing its rapid and powerful steaming capabilities with a 2000W heating system.

Included Accessories:

The SC541 comes equipped with a comprehensive set of tools for various cleaning applications:

- Glass Brush
- Floor Brush
- Carpet Glider
- Hanger
- Ironing Brush
- Nylon Brushes (various sizes)
- Measuring Cup
- Funnel
- Extension Wands
- Cleaning Cloths
- And more, totaling 20 versatile attachments.



20 PROFESSIONAL

ACCESSORIES FOR MULTI
PURPOSE USE



Image: A collage demonstrating the steam cleaner's effectiveness on different surfaces, including windows, carpets, stoves, couches, corners, and floors.

SETUP INSTRUCTIONS

Follow these steps for the initial setup of your MLMLANT SC541 Steam Cleaner:

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Assemble:** Attach the desired accessory (e.g., floor brush, nozzle) to the steam hose or extension wands. Ensure it clicks securely into place.



Image: A visual guide demonstrating the proper method for attaching accessories to the steam cleaner's nozzle.

3. **Fill Water Tank:** Unscrew the safety cap on the main unit. Using the provided measuring cup and funnel, carefully fill the 1.5-liter water tank with clean tap water or distilled water. Do not overfill. Securely screw the safety cap back on.
4. **Connect Power:** Plug the power cord into a grounded electrical outlet.

OPERATING INSTRUCTIONS

Once set up, your steam cleaner is ready for operation:

1. **Power On:** The indicator light will illuminate, signaling that the unit is heating up. This typically takes less than 5 minutes. The light will turn off or change color when the unit is ready to produce steam.
2. **Adjust Steam Volume:** Use the steam volume adjustment dial on the handle to select your desired steam intensity (Min to Max).



Image: A close-up of the steam cleaner's handle, showing the dial for adjusting steam volume from minimum to maximum output.

3. **Activate Steam:** Press the steam trigger on the handle to release steam. For continuous steam, push the steam lock switch to the right.



Image: A detailed view of the steam cleaner's handle, highlighting the steam lock switch for continuous steam operation.

4. **Cleaning:** Move the steam cleaner slowly over the surface to be cleaned. For stubborn dirt, hold the steam over the area for a few seconds. The steam effectively loosens dirt and grime, making it easy to wipe away.
5. **Refilling:** If steam output decreases or stops, the water tank may be empty. Unplug the unit, allow it to cool down for 5-10 minutes, and release any remaining pressure by pressing the steam trigger until no steam comes out. Then, carefully unscrew the safety cap and refill the tank.

6. **Power Off:** When finished, release the steam trigger, unplug the unit from the power outlet, and allow it to cool completely before storing.



Image: A woman demonstrating the use of the MLMLANT steam cleaner on a floor, with a child playing nearby, illustrating the product's child and pet-safe cleaning capabilities.



Image: A visual guide showcasing various surfaces suitable for cleaning with the MLMLANT steam cleaner, including marble, well-sealed hardwood, tiles, sealed stone, and carpet.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your steam cleaner:

- **Empty Water Tank:** After each use, ensure the unit is cool and depressurized, then carefully empty any remaining water from the tank.
- **Clean Accessories:** Wash cleaning cloths and brushes with mild soap and water. Allow them to air dry completely before storing.
- **Descaling:** Depending on water hardness in your area, periodic descaling may be necessary to prevent mineral buildup. Consult the full manual for detailed descaling instructions, typically involving a vinegar solution.
- **Storage:** Store the steam cleaner and its accessories in a cool, dry place. Utilize the integrated cable management system for neat storage of the power cord.



Image: A close-up view of the steam cleaner's integrated cable management system, designed for tidy storage of the power cord.

TROUBLESHOOTING

If you encounter issues with your MLMLANT SC541 Steam Cleaner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No steam or low steam output	Water tank empty; Unit not heated sufficiently; Mineral buildup (limescale); Nozzle/accessory clogged.	Refill water tank; Allow unit to heat up completely; Perform descaling procedure; Clean or replace nozzle/accessory.
Water leaking from unit/accessories	Accessories not securely attached; Overfilled water tank; Damaged seals/gaskets.	Ensure accessories are firmly connected; Do not overfill water tank; Contact customer support for seal replacement.
Unit not turning on	Not plugged in; Power outlet fault; Internal electrical issue.	Check power connection; Test outlet with another appliance; Contact customer support.
Safety cap difficult to open	Unit is still pressurized or hot.	Unplug the unit and allow it to cool down completely. Release any residual pressure by pressing the steam trigger until no steam is emitted.

If the problem persists after attempting these solutions, please contact MLMLANT customer support.

SPECIFICATIONS

Detailed technical specifications for the MLMLANT SC541 Steam Cleaner:

Specification	Value
Brand	MLMLANT
Model Name	SC541
Model Number	2
Colour	Blue
Capacity (Water Tank)	1.5 litres
Power / Wattage	2000 watts
Voltage	230 Volts

Specification	Value
Material	Stainless Steel
Item Weight	5.4 kg
Surface Recommendation	Hard Floor, Upholstery, Carpet
Special Features	1.5L Capacity of water tank, 2000W super heat system, 20 Accessories and safety lock protection
Date First Available	14 Jan. 2019

WARRANTY AND SUPPORT

MLMLANT products are designed for reliability and performance. For any inquiries or assistance, please refer to the following information:

Warranty Information:

MLMLANT brand products are covered by an after-sales warranty for **1 year** from the date of purchase (subject to the invoice date). Please retain your proof of purchase for warranty claims.

Customer Support:

For technical support, troubleshooting assistance, or warranty claims, please visit the official MLMLANT brand store or contact their customer service department. Contact details can typically be found on the MLMLANT website or within your product packaging.

You can visit the MLMLANT Store for more information and support: [MLMLANT Official Store](#)