Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- TecTake /
- > TecTake Children's Desk with Storage and Adjustable Tilting Desktop, Model 800117

TecTake 800117

TecTake Children's Desk with Storage and Adjustable Tilting Desktop

Brand: TecTake | Model: 800117

1. SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Retain this manual for future reference.

- **Assembly Required:** This desk requires self-assembly. Follow the provided assembly instructions meticulously to prevent injuries.
- Weight Limit: This desk is not designed to carry heavy objects. The maximum weight capacity is approximately 17 kg (37.5 lbs) to ensure stability.
- Supervision: Children should be supervised while using the desk, especially during adjustments.
- Placement: Place the desk on a flat, stable surface.

2. PRODUCT OVERVIEW

The TecTake Children's Desk is designed to provide a comfortable and adaptable workspace for various activities such as drawing, homework, and crafts. Its thoughtful design allows for height and tilt adjustments to suit the user's needs.

Key Features:

- Tilting Desktop: The work surface can be tilted to provide an ergonomic position for different tasks.
- Adjustable Height: The desk legs are adjustable in 7 steps, allowing the desk to grow with your child.
- **Integrated Drawer:** A convenient drawer provides storage for school supplies, drawing materials, and other items.
- **Removable Stopper Strips:** Two removable stopper strips on the lower edge of the desktop prevent materials from sliding off when the surface is tilted.
- Stable Construction: Built with robust materials for durability and stability during daily use.
- Rounded Corners: The desktop features rounded corners for enhanced safety.
- Easy to Clean: The surface is washable with a damp cloth.



Figure 1: TecTake Children's Desk, showcasing its design and features.



Figure 2: Overview of key features including adjustable height, tilting desktop, and storage.

3. SETUP

The desk comes with detailed assembly instructions in the package. Please refer to the included manual for step-by-step guidance on assembling your TecTake Children's Desk.

General Assembly Steps:

- 1. Unpack all components and verify against the parts list in the included manual.
- 2. Assemble the main frame structure using the provided hardware.
- 3. Attach the desktop to the frame, ensuring the tilting mechanism is correctly installed.
- 4. Install the storage drawer and stopper strips.
- 5. Ensure all screws and fasteners are securely tightened before use.



Figure 3: The desk's flexible design allows for various adjustments to suit user needs.

4. OPERATING INSTRUCTIONS

4.1 Adjusting Desk Height

- Locate the height adjustment mechanisms on the desk legs.
- Carefully loosen the fasteners or pins that secure the legs at their current height.
- Adjust the desk to one of the 7 available height positions (from approximately 63 cm to 94 cm).
- Ensure both sides are adjusted to the same height and securely fasten the mechanisms before use.

4.2 Tilting the Desktop

- The desktop features a tilting mechanism for ergonomic positioning.
- To tilt, lift the desktop slightly and adjust it to the desired angle.
- Ensure the desktop is securely locked into place at the chosen angle.
- Utilize the two removable stopper strips to prevent items from sliding off the tilted surface.

4.3 Using the Storage Drawer

- The integrated drawer provides convenient storage.
- Pull the drawer out to access its contents.
- Push the drawer back in until it is fully closed to keep items secure and maintain a tidy workspace.



Figure 4: Close-up of the height adjustment and tilting mechanism.

5. MAINTENANCE

- Cleaning: Wipe the desk surfaces with a damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Inspection:** Periodically check all screws and fasteners to ensure they remain tight. Retighten as necessary.
- Avoid Excessive Moisture: Do not expose the desk to excessive moisture or direct sunlight for prolonged periods to prevent warping or discoloration.

6. TROUBLESHOOTING

If you encounter any issues with your TecTake Children's Desk, please refer to the following common solutions:

- **Desk Wobbles:** Ensure the desk is placed on a level surface. Check that all assembly screws and bolts are securely tightened.
- **Difficulty Adjusting Height/Tilt:** Verify that no obstructions are present in the adjustment mechanisms. Ensure fasteners are sufficiently loosened before attempting to adjust.
- Parts Missing or Damaged: If any parts are missing or damaged upon arrival, please contact TecTake customer support for assistance.

7. SPECIFICATIONS

Feature	Specification
Brand	TecTake
Model Number	800117
Work Surface Dimensions	Approx. 109 x 55 cm (43 x 21.7 inches)
Height Adjustment Range	Approx. 63 cm to 94 cm (24.8 to 37 inches) in 7 steps
Drawer Interior Dimensions (HxWxD)	Approx. 6 x 27 x 22 cm (2.4 x 10.6 x 8.7 inches)
Weight	Approx. 17 kg (37.5 lbs)
Material	Plywood (lacquered) / Metal
Special Feature	Adjustable, Tilting Desktop
Care Instructions	Wipe with a damp cloth



Figure 5: Detailed dimensions and technical specifications of the desk.

8. WARRANTY AND SUPPORT

For warranty information, product support, or to order replacement parts, please refer to the documentation included with your purchase or visit the official TecTake website. Please have your model number (800117) and purchase date ready when contacting support.

