

[Manuals.plus](#) /

› [Progress Lighting](#) /

› Progress Lighting Westport Collection P560135-031 2-Light Outdoor Wall Lantern Instruction Manual

Progress Lighting P560135-031

Progress Lighting Westport Collection 2-Light Outdoor Wall Lantern

Model: P560135-031

IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before beginning installation. Failure to do so may result in electric shock, fire, or other injuries that could be fatal or cause property damage. All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). If you are unfamiliar with proper electrical wiring connections, consult a qualified electrician.

- **WARNING:** Risk of electric shock. Disconnect power at the circuit breaker or fuse box before installation or servicing.
- **WARNING:** This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.
- Do not install this fixture in a location where it is exposed to direct water spray from a hose or sprinkler.
- Ensure all connections are secure and properly insulated.
- This fixture is rated for wet locations.

PACKAGE CONTENTS

Verify that all components are present before discarding packaging materials.

- Westport Collection 2-Light Outdoor Wall Lantern (1)
- Installation Sheet (1)

SETUP AND INSTALLATION

This section provides general guidance for installing your outdoor wall lantern. Refer to the included Installation Sheet for detailed, step-by-step instructions specific to your model. Always ensure power is disconnected at the circuit breaker before beginning any electrical work.

General Installation Steps:

1. Turn off power at the main circuit breaker.
2. Attach the mounting bracket to the junction box using the provided screws.
3. Make electrical connections: connect the fixture's black wire to the house's black wire, the fixture's white wire to the house's white wire, and the ground wire to the house's ground wire. Secure connections with wire nuts.
4. Carefully tuck all wires into the junction box.
5. Mount the fixture to the mounting bracket, securing it with the decorative nuts or screws.
6. Install the recommended bulbs (see Operating Instructions).
7. Restore power at the circuit breaker and test the fixture.



This image shows the complete Progress Lighting Westport Collection 2-Light Outdoor Wall Lantern. It features a textured black finish, clear seeded glass panels, and two candelabra-style bulb sockets. The design is traditional, suitable for various architectural exteriors.



A detailed view of the lantern's clear seeded glass, which provides a diffused light effect. A candelabra-style bulb is visible within one of the two sockets, demonstrating the light source type.



This image displays a side profile of the outdoor wall lantern, highlighting the sturdy die-cast aluminum mounting arm and the decorative

finial at the bottom. The textured black finish is clearly visible.

Helpful Video Resource:

Your browser does not support the video tag.

Video: Outdoor Lighting - Sizing and Selection Guide by Progress Lighting. This official video from Progress Lighting provides guidance on selecting and sizing outdoor lighting fixtures. While not specific to installation of this exact model, it offers valuable insights into general outdoor lighting considerations that can aid in proper placement and aesthetic integration of your Westport Collection lantern.

OPERATING INSTRUCTIONS

The Westport Collection outdoor wall lantern operates via a standard wall switch (not included). Ensure the fixture is properly installed and wired before attempting to operate.

- **Bulb Requirements:** This fixture requires two (2) Candelabra (B11) base bulbs.
- **Maximum Wattage:** Do not exceed 60 watts per bulb. Using higher wattage bulbs can cause overheating and damage the fixture or create a fire hazard.
- **Bulb Replacement:** To replace bulbs, ensure power is turned off at the circuit breaker. Allow bulbs to cool completely before touching. Carefully unscrew old bulbs and screw in new ones.

MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your outdoor wall lantern.

- **Cleaning:** Clean the fixture with a soft, damp cloth. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish or glass.
- **Glass Care:** The clear seeded glass can be cleaned with a mild glass cleaner applied to a cloth, not directly to the fixture.
- **Inspection:** Periodically inspect the fixture for any signs of wear, loose connections, or damage. Address any issues promptly.

TROUBLESHOOTING

If your fixture is not operating correctly, refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	Power is off at the circuit breaker. Loose wire connections. Defective bulb. Faulty wall switch.	Check and reset the circuit breaker. Ensure power is off, then check all wire connections. Replace the bulb with a new one. Test the switch or consult an electrician.
Light flickers.	Loose bulb. Loose wire connections. Incorrect bulb type/wattage.	Tighten the bulb. Ensure power is off, then check all wire connections. Verify bulbs meet specifications (Candelabra, B11, max 60W).

SPECIFICATIONS

- **Model Number:** P560135-031
- **Brand:** Progress Lighting
- **Light Source Type:** Candelabra
- **Number of Light Sources:** 2
- **Maximum Compatible Light Source Wattage:** 60 watts per bulb
- **Voltage:** 120 volts
- **Power Source:** AC
- **Material:** Aluminum (frame), Glass (shade)
- **Finish:** Textured Black
- **Mounting Type:** Protruding (Wall Mount)
- **Item Dimensions (L x W x H):** 11" x 12.88" x 19.38"
- **Item Weight:** 1.6 pounds
- **Specification Met:** Wet location rated
- **UPC:** 785247229352

WARRANTY AND SUPPORT

This Progress Lighting product is backed by a **1-year Limited Warranty**. This warranty guarantees your complete satisfaction with your purchase and includes professional after-sales customer service support.

For warranty claims, technical assistance, or further inquiries, please contact Progress Lighting customer service. You can also visit the official Progress Lighting store on Amazon for more information and products: [Progress Lighting Store](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

