

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Infantino](#) /

> [Infantino 3-in-1 Grow-with-Me Discovery Seat and Booster \(Model 203-004\) Instruction Manual](#)

Infantino 203-004

Infantino 3-in-1 Grow-with-Me Discovery Seat and Booster (Model 203-004)

Instruction Manual

INTRODUCTION

The Infantino 3-in-1 Grow-with-Me Discovery Seat and Booster is designed to adapt as your child grows, offering three primary functions: an interactive activity seat, a convenient snack-time seat, and a secure booster seat for dining. This versatile product supports sensory development and provides a safe space for your child during various activities.

SAFETY INFORMATION

WARNING: Always use the restraint system. Never leave child unattended. Always secure the booster seat to an adult chair using the provided straps. Child must have unassisted head and neck control to use this product.

- Maximum weight recommendation: 33 Pounds.
- Ensure all components are securely fastened before each use.
- Do not use on elevated surfaces unless securely attached to an adult chair.
- Regularly inspect the product for any signs of wear or damage. Discontinue use if damaged.

PARTS LIST

- Main Seat Unit
- Removable Activity Tray with Toys (Monkey, Lion, Turtle, Mirror)
- Removable Snack Tray
- Seat Cushion
- Chair Attachment Straps
- Internal Child Harness

SETUP AND ASSEMBLY

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that all items listed in the Parts List are present.

2. **Insert Seat Cushion:** Place the striped seat cushion into the main seat unit. Ensure the internal child harness straps are threaded through the designated slots in the cushion.
3. **Attach Activity Tray:** Align the activity tray with the slots on the main seat unit. Press down firmly on both sides until it clicks securely into place. The activity tray features various toys like a monkey, lion, and turtle with crinkle sounds, rattles, and a mirror to engage your child.
4. **Attach Snack Tray (Optional):** The activity tray can be removed by sliding the white side pieces outwards. Once removed, the red snack tray is revealed, which includes a cup holder. The white side pieces can also be detached from the snack tray for cleaning or to use the snack tray independently.
5. **Secure Child Harness:** Fasten the internal child harness around your baby and adjust the straps for a snug and secure fit.



Image: Baby seated in the Infantino 3-in-1 Discovery Seat with activity tray attached.



Image: Close-up of baby playing with the activity toys on the Infantino 3-in-1 Discovery Seat.

OPERATING MODES

- **Activity Seat:** Use the main seat unit with the activity tray attached on the floor. This mode is suitable for babies who have developed unassisted head control. The interactive toys are designed to stimulate sensory development and keep your child entertained.
- **Snack-Time Seat:** Remove the activity tray to utilize the built-in snack tray. This tray features a cup holder and a flat surface for food, making it convenient for feeding times.
- **Booster Seat:** For older babies and toddlers, the main seat unit can be securely attached to an adult dining chair. Use the provided chair attachment straps to fasten the booster seat firmly to the adult chair's backrest and base. Ensure all straps are tightened to prevent any movement.



Image: Baby eating snacks in the Infantino 3-in-1 Discovery Seat used as a booster on a dining chair.



Image: Toddler seated in the Infantino 3-in-1 Discovery Seat used as a booster on a dining chair.

MAINTENANCE AND CLEANING

The Discovery Booster Seat is designed for easy cleaning to maintain hygiene.

- **Seat Cushion:** The seat cushion is washable and wipeable. It can be removed and machine washed on a gentle cycle with cold water. Air dry or tumble dry on low heat.
- **Plastic Components:** All plastic parts, including the main seat unit, activity tray, and snack tray, should be wiped down with a damp cloth and mild soap. Rinse thoroughly and ensure all parts are completely dry before reassembly or next use.
- Do not use abrasive cleaners or harsh chemicals, as these may damage the product.

TROUBLESHOOTING

- **Problem:** The activity tray or snack tray does not attach securely.
Solution: Ensure the tray is correctly aligned with the slots on the main seat unit and press firmly until a click is heard. Check for any obstructions in the attachment mechanism.
- **Problem:** The booster seat slides or moves on the adult chair.
Solution: Verify that all chair attachment straps are properly routed and tightened around the adult

chair's backrest and base. The seat should not move when secured. Adjust straps as necessary.

- **Problem:** Child is uncomfortable or not properly supported.

Solution: Ensure the child meets the minimum age and developmental requirements (unassisted head control). Adjust the internal child harness for a snug but comfortable fit.

SPECIFICATIONS

Product Dimensions	17 x 9.38 x 17 inches
Item Model Number	203-004
Maximum Weight Recommendation	33 Pounds
Material Type	Foam, Plastic
Care Instructions	Washable & wipeable seat cushion for easy cleaning
Number Of Items	1
Style	Booster & Hook-On Seats
Batteries Required	No
Is Portable	Yes
Brand	Infantino
Color	Multi



Image: Diagram showing the dimensions of the Infantino 3-in-1 Discovery Seat.

PRODUCT OVERVIEW VIDEO

Video: Official Infantino product overview showcasing various baby products, including the 3-in-1 Discovery Seat.

WARRANTY AND SUPPORT

For warranty information or customer support regarding your Infantino 3-in-1 Grow-with-Me Discovery Seat and Booster, please refer to the manufacturer's official website or contact their customer service directly. Keep your proof of purchase for any warranty claims.