

[Manuals.plus](#) /

› [Pic Solution](#) /

› Pic Solution Vedofamily Digital Thermometer User Manual

Pic Solution 02023030200000

Pic Solution Vedofamily Digital Thermometer User Manual

Model: 02023030200000

INTRODUCTION

The Pic Solution Vedofamily Digital Thermometer is designed for simple and accurate temperature measurement for the entire family. This device features a rigid probe and essential functions for reliable body temperature readings. It is suitable for oral, rectal, or axillary use.

Key features include:

- Fast measurement times, typically between 60 and 180 seconds.
- Easy-to-read digital display.
- Memory function for the last measured reading.
- Audible alert upon completion of measurement, with a distinct sound for temperatures above 37.5°C (99.5°F).
- Long-lasting batteries (approximately 1000 measurements) that are easy to replace.
- Comes with a protective transparent case for hygienic storage.

WHAT'S IN THE BOX

Your Pic Solution Vedofamily Digital Thermometer package includes:

- One (1) Pic Solution Vedofamily Digital Thermometer
- One (1) Transparent Protective Case
- One (1) LR44 Battery (pre-installed)
- User Manual (this document)



Image: The Pic Solution Vedofamily Digital Thermometer stored within its transparent protective case.

SETUP

Battery Installation

The thermometer comes with one LR44 battery pre-installed. If replacement is needed:

1. Locate the battery compartment cover, usually at the end opposite the probe.
2. Carefully slide or unclip the cover to open the compartment.
3. Remove the old LR44 battery.
4. Insert a new LR44 battery, ensuring the positive (+) side faces upwards.
5. Replace the battery compartment cover securely.



Image: A detailed view of the thermometer's power button and the battery compartment area.

OPERATING INSTRUCTIONS

Taking a Measurement

1. **Clean the Probe:** Before each use, clean the thermometer probe with alcohol or soap and water.
2. **Power On:** Press the power button. The display will show the last measured temperature for a few seconds, followed by 'L°C' (or 'L°F') indicating it's ready for measurement.
3. **Positioning:**
 - **Oral Use:** Place the probe tip under the tongue, close to the heat pocket. Keep the mouth closed.
 - **Axillary (Armpit) Use:** Place the probe tip in the center of the armpit. Hold the arm firmly against the body.
 - **Rectal Use:** Gently insert the probe tip into the rectum (for infants and young children, consult a medical professional for proper technique).
4. **Measurement:** Keep the thermometer in position until you hear a series of beeps, indicating the measurement is complete. This typically takes 60 to 180 seconds.
5. **Read Result:** The measured temperature will be displayed on the screen.

6. **Fever Alert:** If the temperature is 37.5°C (99.5°F) or higher, the thermometer will emit a different, more rapid beeping sound to indicate a potential fever.
7. **Power Off:** The thermometer will automatically shut off after approximately 10 minutes of inactivity to conserve battery life. You can also manually turn it off by pressing the power button again.



Image: The thermometer display showing a temperature of 37.5°C, indicating a potential fever.



Image: Proper technique for taking an axillary temperature reading.

MAINTENANCE AND CARE

Cleaning

To ensure hygiene and accurate readings, clean the thermometer after each use:

- Wipe the probe and the entire thermometer body with a soft cloth dampened with 70% isopropyl alcohol or soap and water.
- Do not immerse the entire thermometer in water or any cleaning solution. The device is not waterproof.
- Allow the thermometer to air dry completely before storing.

Storage

Store the thermometer in its transparent protective case in a cool, dry place, away from direct sunlight and extreme temperatures. Keep it out of reach of children.

Battery Replacement

When the battery is low, a battery symbol will appear on the display. Replace the LR44 battery as described in the 'Setup' section. Dispose of used batteries according to local regulations.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Thermometer does not turn on.	Dead battery or incorrect battery installation.	Replace the LR44 battery, ensuring correct polarity.
Inaccurate or inconsistent readings.	Improper placement of the probe; movement during measurement; external factors (e.g., recent eating/drinking for oral, recent activity for axillary).	Ensure correct probe placement and stillness during measurement. Wait 15-30 minutes after eating, drinking, or strenuous activity before taking oral/axillary temperature. Axillary readings are typically lower than oral or rectal readings.
Measurement takes too long.	Normal operation for certain measurement sites (e.g., axillary can be longer).	Ensure proper contact and wait for the audible signal. Measurement times can vary between 60-180 seconds depending on the site.
Display shows 'Err'.	Measurement outside the operating range or internal error.	Ensure the ambient temperature is within the operating range. If the error persists, contact customer support.

SPECIFICATIONS

Feature	Detail
Model Number	02023030200000
Power Source	1 x LR44 Battery (included)
Display Type	Digital
Measurement Range	Typically 32.0°C to 42.9°C (90.0°F to 109.9°F)
Resolution	0.1°C (0.1°F)
Response Time	60-180 seconds
Dimensions (L x W x H)	4.6 x 13 x 2.1 cm (1.8 x 5.1 x 0.8 inches)
Weight	30 grams (1.06 ounces)
Material	Plastic
Country of Origin	Italy
Compliance	CE certified

WARRANTY INFORMATION

Specific warranty details are not provided in the product information. Please refer to the packaging or contact Pic Solution customer support for information regarding warranty coverage and terms.

SUPPORT

For further assistance, product inquiries, or technical support, please visit the official Pic Solution website or contact their customer service department.

Official Brand Store: [Pic Solution Amazon Store](#)

Always consult a medical professional for health concerns or if you have questions about temperature readings.

© 2024 Pic Solution. All rights reserved.

This device is a medical device. Read the instructions for use carefully.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07MP8MGLT>

More documents and user manuals: <https://manuals.plus/>