

[Manuals.plus](#) /

› [GSParts](#) /

› Victor SR450D Oxygen Regulator Rebuild/Repair Parts Kit 0790-0102

GSParts SR450D

Victor SR450D Oxygen Regulator Rebuild/Repair Parts Kit

Model: SR450D | Part Number: 0790-0102

INTRODUCTION

This manual provides essential information for the proper installation and maintenance of the GSParts Victor SR450D Oxygen Regulator Rebuild/Repair Parts Kit. This kit is designed to restore the functionality of your Victor SR450D oxygen regulator by replacing critical internal components.

Warning: These parts must be installed by a qualified technician. If these parts are installed incorrectly, serious injury or death may occur. Always follow all applicable safety standards and manufacturer guidelines when working with high-pressure gas systems.

SAFETY INFORMATION

- **Professional Installation Required:** Installation of these parts requires specialized knowledge and tools. Attempting installation without proper qualifications can lead to equipment failure, personal injury, or death.
- **Oxygen Safety:** Oxygen is a powerful oxidizer. Ensure all tools and components are free of oil, grease, or any combustible materials before handling. Contamination can lead to spontaneous combustion or explosion.
- **Pressure Release:** Always ensure the oxygen cylinder valve is closed and all pressure is safely bled from the regulator and lines before beginning any repair work.
- **Leak Testing:** After installation, thoroughly leak test all connections using an approved leak detection solution. Never use an open flame for leak detection.
- **Personal Protective Equipment (PPE):** Always wear appropriate PPE, including safety glasses, gloves, and protective clothing, when working with gas regulators.
- **Ventilation:** Work in a well-ventilated area to prevent accumulation of gases.

KIT COMPONENTS

The GSParts Victor SR450D Oxygen Regulator Rebuild/Repair Parts Kit includes the following components:




Image: Components of the Victor SR450D Oxygen Regulator Rebuild Kit. The kit typically includes a main diaphragm, various O-rings, and a seat assembly (often brass with a red seal and a metal pin).

- **Diaphragm:** The primary flexible membrane that controls pressure regulation.
- **Seat Assembly:** The component that seals against the inlet pressure, controlling gas flow.
- **O-Rings/Seals:** Various rubber or synthetic rings and seals for ensuring gas-tight connections within the regulator.
- **Springs (if included):** Internal springs that provide tension for pressure adjustment. (Note: Specific springs may or may not be included in all kits, refer to your kit's contents.)

SETUP AND INSTALLATION

This section outlines the general steps for installing the rebuild kit. Refer to the specific service manual for your Victor SR450D regulator for detailed, step-by-step instructions and torque specifications. This is a general guide and not a substitute for professional training.

1. **Preparation:** Ensure the oxygen cylinder is closed and the regulator is completely depressurized. Disconnect the regulator from the cylinder and any hoses.
2. **Disassembly:** Carefully disassemble the regulator according to the manufacturer's service manual. Pay close attention to the order and orientation of all components.
3. **Cleaning:** Thoroughly clean all internal regulator components with a non-flammable, oxygen-compatible cleaning solution. Inspect for any damage, corrosion, or debris. Ensure all parts are completely dry before reassembly.
4. **Component Replacement:** Replace the old diaphragm, seat assembly, and all O-rings/seals with the new components from the kit. Lubricate O-rings with an oxygen-compatible lubricant if specified by the manufacturer.
5. **Reassembly:** Reassemble the regulator, ensuring all components are correctly seated and tightened to the manufacturer's specified torque values. Incorrect torque can lead to leaks or damage.

6. **Leak Testing:** After reassembly, connect the regulator to an oxygen cylinder and slowly open the cylinder valve. Apply an approved leak detection solution to all joints and connections. Look for bubbles, which indicate a leak. Do not use the regulator if any leaks are detected.
7. **Pressure Testing:** Gradually increase the outlet pressure to verify proper regulation and ensure there are no internal leaks or pressure creep.

OPERATING THE REBUILT REGULATOR

Once the rebuild kit has been successfully installed and tested, the regulator should operate as per its original specifications. Always follow standard operating procedures for oxygen regulators:

- **Connecting:** Ensure the regulator connection is clean and free of debris before attaching it to the oxygen cylinder valve.
- **Opening Cylinder Valve:** Slowly open the oxygen cylinder valve. The high-pressure gauge should indicate the cylinder pressure.
- **Setting Outlet Pressure:** Turn the regulator adjusting screw clockwise to increase the outlet pressure to the desired working pressure, as indicated on the low-pressure gauge.
- **Closing Down:** When finished, close the oxygen cylinder valve first. Then, open the torch valve or bleed the regulator to release all pressure from the regulator and hoses. Turn the regulator adjusting screw counter-clockwise until it is loose.

MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your rebuilt oxygen regulator:

- **Regular Inspection:** Periodically inspect the regulator for any signs of damage, leaks, or wear on hoses and connections.
- **Cleanliness:** Keep the regulator clean and free from oil, grease, and dirt.
- **Storage:** Store the regulator in a clean, dry place away from extreme temperatures and direct sunlight when not in use.
- **Professional Servicing:** Even after a rebuild, regulators should be professionally inspected and serviced at recommended intervals by a qualified technician.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Gas Leak	Improperly seated O-rings/seals, damaged threads, loose connections.	Re-check all connections for tightness. Re-disassemble and inspect O-rings/seals for proper seating or damage. Apply leak detection solution.
Inconsistent Pressure / Pressure Creep	Damaged or improperly installed seat assembly, diaphragm issues.	Ensure the seat assembly is clean, undamaged, and correctly installed. Verify diaphragm is not pinched or torn. Professional inspection recommended.
No Gas Flow	Cylinder valve closed, regulator adjusting screw not turned in, blockage.	Open cylinder valve. Turn regulator adjusting screw clockwise. Check for blockages in lines or regulator inlet.

If troubleshooting steps do not resolve the issue, discontinue use immediately and consult a qualified technician or the manufacturer.

SPECIFICATIONS

Brand:	GSParts
Model:	SR450D
Part Number:	0790-0102
Item Weight:	Approximately 0.16 ounces
Package Dimensions:	Approximately 3.5 x 3 x 0.2 inches
Compatibility:	Designed for Victor SR450D Oxygen Regulators

WARRANTY AND SUPPORT

For specific warranty information regarding your GSParts Victor SR450D Oxygen Regulator Rebuild/Repair Parts Kit, please refer to the product packaging or contact GSParts directly. As this is a repair kit, proper installation by a qualified technician is crucial for performance and safety.

For technical support or inquiries, please contact GSParts customer service through their official channels. Always provide your product model and part number when seeking support.

