

Coleshome B07MQDPP38

Coleshome 61 Inch L Shaped Desk with Drawers Instruction Manual

Model: B07MQDPP38

1. SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- **Warning:** Keep babies and children away from assembly parts. Small parts may pose a choking hazard.
- Ensure all connections are secure before using the desk.
- Do not exceed the maximum weight recommendation of 220 pounds (100 kg).

2. PACKAGE CONTENTS

Verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Desk panels (L-shaped top, side panels)
- Metal frame components
- 6 Fabric Drawers
- Recessed Power Outlet unit (3 AC outlets, 1 USB-A, 1 USB-C)
- Assembly hardware (screws, bolts, etc.)
- Assembly tools (Allen wrench, screwdriver)
- Instruction manual

3. SETUP AND ASSEMBLY

Assembly typically takes approximately 25-45 minutes for one person. All necessary tools are included.

3.1 Reversible Design

The L-shaped desk features a reversible design, allowing you to configure the longer or shorter side to your preferred orientation (left or right) to best fit your space. Follow the specific instructions in the included manual for your desired configuration.

3.2 Assembly Steps

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Assemble the metal frame according to the diagrams in the provided manual. Ensure all bolts are tightened securely.
3. Attach the desk panels to the assembled frame.
4. Install the 6 fabric drawers into their designated slots.
5. Mount the recessed power outlet unit into the pre-drilled hole on the desktop.
6. Attach the floor protection pads to the bottom of the desk legs to prevent scratching your floor.




Figure 1: Desk Dimensions and Structure.



Figure 2: Reversible Desk Configuration Example.

Video 1: A customer review showcasing the L-shaped desk's setup, including the sturdy supports and the optional computer base. The video highlights the desk's smooth finish and reversible design, allowing for flexible placement in an office room.

4. OPERATING INSTRUCTIONS

4.1 Power Outlets

The desk is equipped with a recessed power outlet unit for convenient access to power. It includes 3 standard AC outlets (120V/12A), 1 USB-A port (5V/2A), and 1 USB-C port (5V/2A). The power cord is 6.6 feet long.



Figure 3: Recessed Power Outlet Unit.

4.2 Storage Drawers

The desk includes 6 durable fabric drawers, providing ample storage space to keep your desktop tidy. These drawers are designed for lightweight items such as earphones, books, files, and laptops.



Figure 4: Durable Fabric Drawers for Storage.

4.3 Monitor Stand

The desk includes a wide shelf that can function as a monitor stand. Position your monitor(s) on this shelf for an elevated viewing experience. Ensure the weight of your equipment does not exceed the desk's capacity.




Figure 5: Desk in Use with Monitors and Storage.

5. MAINTENANCE

To ensure the longevity and appearance of your Coleshome desk, follow these maintenance guidelines:

- **Cleaning:** Clean the desk surfaces with a damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Scratches:** Be careful with scratches. Use coasters for drinks and mouse pads for computer mice to protect the surface.
- **Tighten Fasteners:** Periodically check and tighten all screws and bolts to maintain stability.

6. TROUBLESHOOTING

If you encounter any issues during assembly or use, refer to the following common solutions:

- **Wobbly Desk:** Ensure all screws and bolts are fully tightened. Check that the desk is on a flat, level surface. Adjust the leg pads if necessary.
- **Misaligned Parts:** If parts do not align, double-check the assembly steps and ensure you are using the

correct components for each section. The reversible design requires careful attention to orientation.

- **Missing Hardware:** If any hardware is missing, contact customer support for replacement parts. Do not attempt to substitute with incorrect hardware.

7. SPECIFICATIONS

Feature	Detail
Brand	Coleshome
Model	B07MQDPP38
Shape	L-Shape
Desk Design	Computer Desk
Product Dimensions (D x W x H)	60.8"D x 45"W x 29"H
Color	Black
Base Material	Alloy Steel
Top Material Type	Engineered Wood
Finish Type	Powder Coated
Special Feature	Reversible
Included Components	Wide Shelf, Reversible Tabletop, 6 Fabric Drawers, Recessed Power Outlet
Maximum Weight Recommendation	220 Pounds
Required Assembly	Yes
Includes All Assembly Tools	Yes
Power Outlet	3 AC Outlets (120V/12A), 1 USB Port (5V/2A), 1 Type-C Port (5V/2A)
Power Cord Length	6.6 FT

8. WARRANTY INFORMATION

This Coleshome desk comes with a **Limited Warranty**. For specific terms and conditions, please refer to the warranty documentation included with your purchase or contact customer support.

9. CUSTOMER SUPPORT

For any questions, assistance with assembly, or to report missing/damaged parts, please contact Coleshome customer support. Refer to the contact information provided in your product packaging or visit the official Coleshome website.



Coleshome Customer Support is available to assist you.