



Manuals.plus /

- › Evolved Novelties /
- › Evolved Novelties Mighty Mini Rechargeable Butt Plug User Manual (Model 360RS3206)

Evolved Novelties 360RS3206

Evolved Novelties Mighty Mini Rechargeable Butt Plug User Manual

Model: 360RS3206

1. INTRODUCTION

Thank you for choosing the Evolved Novelties Mighty Mini Rechargeable Butt Plug. This compact device is designed for personal use, featuring 20 vibration modes and a waterproof, submersible silicone construction. This manual provides essential information for safe and effective use, including setup, operation, maintenance, and specifications.



Image 1.1: The Mighty Mini Rechargeable Butt Plug shown in its retail packaging, highlighting the product's design and key features.

2. SAFETY INFORMATION

Please read all safety instructions before using this product. Failure to follow these instructions may result in injury or damage to the product.

- **CAUTION:** This product is waterproof and submersible. However, do not use it in water if it is damaged or if the battery compartment is not properly sealed.
- Always follow instructions for proper cleaning and storage to ensure safe usage.
- Do not use this product if you are allergic to silicone.
- Keep out of reach of children.
- Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

3. SETUP AND CHARGING

Before first use, and after each subsequent use, ensure the device is fully charged.

1. Locate the charging port on the device. This is typically a small, covered port on the base.
2. Connect the provided USB charging cable to the device and to a compatible USB power source (e.g., computer USB port, USB wall adapter).
3. The LED light on the button at the base will indicate charging status. Refer to the product packaging or manufacturer's website for specific LED indicators (e.g., solid light for charging, blinking for low battery, off for full charge).
4. Allow the device to charge completely before its first use.



Image 3.1: A close-up view of the power button, which also serves as the charging indicator and control interface.

4. OPERATION

The Mighty Mini Butt Plug features simple one-button control for ease of use.

1. **Preparation:** Apply a small amount of water-based lubricant to the tip of the device for comfortable insertion.
2. **Power On:** Press and hold the power button (refer to Image 3.1) for a few seconds until the device vibrates to turn it on.
3. **Change Modes:** Once powered on, short press the power button to cycle through the 20 available vibration modes.
4. **Power Off:** Press and hold the power button again for a few seconds until the device stops vibrating to turn it off.
5. **Water Use:** For use in water, ensure the device is fully submerged. Avoid use in saltwater or chlorinated water, as this may damage the device.



Image 4.1: The Mighty Mini Butt Plug, illustrating its ergonomic design for comfortable use.

5. CLEANING AND STORAGE

Proper cleaning and storage are essential for hygiene and product longevity.

- **Cleaning:** Clean the device thoroughly before and after each use with mild soap and warm water. Alternatively, use a specialized toy cleaner.
- Rinse the device completely to remove all soap residue.
- Dry the device thoroughly with a lint-free cloth before storing.
- **Storage:** Store the device in a clean, dry place, away from direct sunlight and extreme temperatures.
- Keep the device separate from other toys made of different materials to prevent material degradation.



Image 5.1: The Mighty Mini Butt Plug from a front perspective, highlighting its smooth, body-safe silicone material.

6. TROUBLESHOOTING

If you encounter issues with your Mighty Mini Butt Plug, refer to the following common solutions:

- **Device not turning on:** Ensure the device is fully charged. Connect it to the USB charger and check if the charging indicator light activates.
- **Vibrations are weak or inconsistent:** The battery may be low. Recharge the device completely.
- **Device not holding a charge:** Ensure the charging cable is securely connected and the power source is functional. If the issue persists after trying a different cable or power source, contact customer support.
- **Water leakage:** Discontinue use immediately. Ensure the charging port cover is securely sealed before water exposure. If leakage occurs, the device may be damaged.

7. SPECIFICATIONS

Model Number	360RS3206
Brand	Evolved Novelties
Material	Silicone
Color	Black
Dimensions (L x W x H)	5 x 2.83 x 0.89 inches
Weight	2.5 ounces
Battery	1 Lithium Ion battery (rechargeable)
Vibration Modes	20
Water Resistance	Waterproof and submersible

Note: Product specifications are subject to change without notice.

5 YEAR WARRANTY

This compact, creamy smooth butt plug is perfect for beginners and advanced anal players alike! Lube up the classic bulbous shape, and start with the tapered tip as you relax and enjoy the unique feeling and find the vibration level that helps bring you to a powerful climax. Clean with Evolved toy cleaner and a hot water rinse.



- Powerful vibrating butt plug
- Perfect for beginner or advanced anal play
- 20 vibrating functions & speeds
- Easy to use 1-button control
- Made from creamy smooth silicone
- Height: 3.5", Depth: 1", Width: 1"
- Weight: 1.3 oz
- LED light on button at base
- Waterproof and submersible
- Phthalate & latex free
- Rechargeable, USB cable included



MYEVOLVED.COM

Image 7.1: Packaging detail showing key features and the 5-year warranty information.

8. WARRANTY AND SUPPORT

The Evolved Novelties Mighty Mini Rechargeable Butt Plug comes with a **5-year warranty**. For warranty claims, technical support, or any inquiries regarding your product, please contact Evolved Novelties customer service.

Please visit the official Evolved Novelties website for the most up-to-date contact information and warranty details: www.myevolved.com