

[Manuals.plus](#) /

› [Soundstream](#) /

› Soundstream H2S-BL Portable Bluetooth Speaker Instruction Manual

Soundstream H2S-BL

Soundstream H2S-BL Portable Bluetooth Speaker Instruction Manual

Model: H2S-BL | Brand: Soundstream

1. INTRODUCTION AND OVERVIEW

Thank you for choosing the Soundstream H2S-BL Portable Bluetooth Speaker. This manual provides essential information for the safe and efficient operation of your device. This speaker is designed for portability and durability, featuring IPX7 waterproofing and a rugged design, making it suitable for various outdoor activities.



Image 1.1: Front view of the Soundstream H2S-BL Portable Bluetooth Speaker.

2. PRODUCT FEATURES

- **Portable Design:** Compact and lightweight for easy transport.
- **Bluetooth Connectivity:** Seamless wireless audio streaming.
- **IPX7 Waterproof:** Designed to withstand immersion in water up to 1 meter for 30 minutes.
- **Rugged Construction:** Durable build for outdoor and travel use.
- **Integrated Clamp:** Allows for secure attachment to bikes, bags, or other objects.
- **Rechargeable Battery:** Provides extended playback time.
- **LED Lighting:** Features dynamic LED lights for enhanced ambiance.



Image 2.1: The speaker demonstrating its IPX7 waterproof capability, partially submerged in water.

3. PACKAGE CONTENTS

Ensure all items are present upon unboxing:

- Soundstream H2S-BL Portable Bluetooth Speaker
- Charging Cable (USB-C)
- User Manual (this document)

4. SETUP

4.1 Charging the Speaker

Before first use, fully charge the speaker. The charging port is located under a protective rubber flap on the side of the speaker.

1. Locate the rubber flap on the side of the speaker.
2. Gently open the flap to reveal the USB-C charging port.
3. Connect the provided USB-C charging cable to the speaker and a compatible USB power source (e.g., wall adapter, computer USB port).
4. The LED indicator will show charging status. A full charge typically takes approximately 4.5 hours.
5. Once fully charged, disconnect the cable and securely close the rubber flap to maintain waterproofing.



Image 4.1: The speaker connected via its charging port, illustrating the location of the port under the protective flap.

4.2 Bluetooth Pairing

To connect your speaker to a Bluetooth-enabled device:

1. Ensure the speaker is charged and powered off.
2. Press and hold the Power button () for a few seconds until you hear an audible prompt and the LED indicator begins to flash, indicating pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
4. Select "Soundstream H2S-BL" from the list of available devices.
5. Once connected, you will hear a confirmation tone, and the LED indicator will change to a solid color or a specific pattern.

5. OPERATING INSTRUCTIONS

The control buttons are located on the side of the speaker, beneath the integrated clamp.





5.1 Power On/Off

- **Power On:** Press and hold the Power button () for approximately 3 seconds.
- **Power Off:** Press and hold the Power button () for approximately 3 seconds.

5.2 Volume Control

- **Increase Volume:** Press the Volume Up button (+).
- **Decrease Volume:** Press the Volume Down button (-).

5.3 Play/Pause

- **Play/Pause:** Press the Play/Pause button (▶||) to toggle playback.

5.4 LED Lights

The speaker features LED lights that can be customized. Refer to the product's quick start guide or packaging for specific instructions on changing light modes or colors, as this functionality may vary.

5.5 Auxiliary Input

For devices without Bluetooth, use the auxiliary input:

1. Open the protective rubber flap on the side of the speaker.
2. Connect a 3.5mm audio cable (not included) from your audio source to the AUX-in port on the speaker.
3. The speaker will automatically switch to AUX mode.
4. Adjust volume from both your audio source and the speaker.

6. MAINTENANCE

6.1 Waterproofing (IPX7)

The speaker is rated IPX7, meaning it can be immersed in water up to 1 meter (3 feet) for up to 30 minutes. To maintain this rating:

- Ensure the rubber flap covering the charging and auxiliary ports is securely closed before exposing the speaker to water.
- Do not expose the speaker to saltwater or other chemicals, as this may degrade the seals.
- After exposure to water, especially chlorinated or saltwater, rinse the speaker with fresh water and allow it to air dry completely before charging or opening the port flap.

6.2 Cleaning

Wipe the speaker with a soft, damp cloth. Do not use abrasive cleaners or solvents.

7. TROUBLESHOOTING

Issue	Possible Solution
Speaker does not power on	Ensure the battery is charged. Connect to a power source and try again.
Cannot pair via Bluetooth	Ensure the speaker is in pairing mode (flashing LED). Turn off and on Bluetooth on your device. Move closer to the speaker.

Issue	Possible Solution
No sound or low volume	Check volume levels on both the speaker and your connected device. Ensure the speaker is not muted.
Sound distortion	Lower the volume on both the speaker and your device. Ensure the speaker is not too far from the connected device.
Charging issues	Verify the charging cable is securely connected. Try a different USB power source.

8. SPECIFICATIONS

- **Model Name:** H2GO
- **Item Model Number:** H2S-BL
- **Connectivity Technology:** Bluetooth
- **Wireless Communication Technology:** Bluetooth
- **Bluetooth Range:** 20 Meters
- **Water Resistance Level:** Waterproof (IPX7)
- **Speaker Maximum Output Power:** 10 Watts
- **Frequency Response:** 20 KHz
- **Impedance:** 4 Ohm
- **Input Voltage:** 5 Volts
- **Battery Capacity:** 4000 Milliamp Hours
- **Charging Time:** 4.5 Hours
- **Power Source:** Battery Powered
- **Speaker Size:** 2 Inches
- **Woofer Diameter:** 2 Inches
- **Product Dimensions:** 3.75 x 2.5 x 6.5 inches
- **Item Weight:** 1.9 pounds
- **Indoor/Outdoor Usage:** Outdoor
- **Mounting Type:** Boat Mount, Freestanding
- **Compatible Devices:** Smartphone, Tablet

9. WARRANTY AND SUPPORT

This product comes with a Limited Warranty. For detailed warranty information, please refer to the warranty card included in your product packaging or visit the official Soundstream website. For technical support or customer service, please contact Soundstream customer support through their official channels.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question