

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Xech](#) /

› [Xech A8 Wireless Bluetooth Over-Ear Headphones User Manual](#)

## Xech A8

# Xech A8 Wireless Bluetooth Over-Ear Headphones User Manual

## WELCOME

Thank you for choosing the Xech A8 Wireless Bluetooth Over-Ear Headphones. This manual provides essential information for setting up, operating, and maintaining your headphones. Please read it carefully before use to ensure optimal performance and longevity of your device.

## PACKAGE CONTENTS

Please verify that all items are present in your package:

- Xech A8 Headphones
- AUX Cable
- Airplane Audio Adapter
- Micro USB Charging Cable
- EVA Carrying Case
- User Manual



Included accessories: Xech A8 Headphones, AUX Cable, Airplane Audio Adapter, Micro USB Charging Cable, EVA Case, and User Manual.

## PRODUCT OVERVIEW AND CONTROLS

---

Familiarize yourself with the headphone's features and control buttons for easy operation.



Premium Sound



Inbuilt Mic



Passive Noise  
Cancellation



Over Ear  
Headphone



Xech A8 Headphones with key features: Premium Sound, Inbuilt Mic, Passive Noise Cancellation, Over-Ear design.



① Vol - / Previous	⑤ Vol - / Previous
② Power On-Off / Mode Button	⑥ Power On-Off / Mode Button
③ Vol + / Next	⑦ Vol + / Next
④ Play-Pause / Call Receive & Reject	⑨ Play-Pause / Call Receive & Reject

Detailed view of the Xech A8 headphone controls and ports.

## Control Functions

No.	Button/Port	Function
1	Vol - / Previous	Decrease volume / Skip to previous track (long press)
2	Power On-Off / Mode Button	Power on/off, switch modes (Bluetooth/AUX/TF Card)
3	Vol + / Next	Increase volume / Skip to next track (long press)
4	Play-Pause / Call Receive & Reject	Play/pause music, answer/end/reject calls
5	USB Port	Charging port for Micro USB cable
6	LED Indicator	Shows power, charging, and pairing status
7	Microphone	For hands-free calls
8	AUX Port	For wired audio connection using 3.5mm cable

No.	Button/Port	Function
9	TF Card Slot	Insert a TF (MicroSD) card for direct music playback

## SETUP GUIDE

### Charging the Headphones

Before first use, fully charge your headphones to ensure maximum battery life.

- Connect the Micro USB charging cable to the USB port on the headphones and to a compatible USB power source (e.g., computer, wall adapter).
- The LED indicator will glow red during charging.
- The LED indicator will turn off when the headphones are fully charged.
- Charging time is approximately 2-3 hours.

### Powering On/Off

- To Power On:** Press and hold the Power On-Off / Mode Button until the LED indicator flashes blue.
- To Power Off:** Press and hold the Power On-Off / Mode Button until the LED indicator turns off.

### Bluetooth Pairing

To connect your headphones wirelessly to a device:

- Ensure the headphones are powered off.
- Press and hold the Power On-Off / Mode Button for approximately 5-7 seconds until the LED indicator flashes blue and red alternately. This indicates pairing mode.
- On your device (smartphone, tablet, etc.), enable Bluetooth and search for new devices.
- Select "Xech A8" from the list of available devices.
- Once successfully paired, the LED indicator will flash blue slowly.

### Wired Connection (AUX Mode)

To use the headphones with a wired connection:

- Connect one end of the provided 3.5mm AUX cable to the AUX port on the headphones.
- Connect the other end to the 3.5mm audio jack of your device.
- The headphones will automatically switch to AUX mode. No battery power is required in this mode.

### Using the Airplane Audio Adapter

For in-flight entertainment systems with dual-prong audio jacks:

- Connect the AUX cable to your headphones.
- Plug the AUX cable into the airplane audio adapter.
- Insert the airplane audio adapter into the dual-prong audio jack on the airplane seat.

## OPERATING INSTRUCTIONS

### Music Playback

- **Play/Pause:** Press the Play-Pause button once.
- **Next Track:** Long press the Vol + / Next button.
- **Previous Track:** Long press the Vol - / Previous button.
- **Volume Up:** Short press the Vol + / Next button.
- **Volume Down:** Short press the Vol - / Previous button.

## Call Management

- **Answer Call:** Press the Play-Pause / Call button once when a call comes in.
- **End Call:** Press the Play-Pause / Call button once during an active call.
- **Reject Call:** Press and hold the Play-Pause / Call button for 2 seconds when a call comes in.
- **Redial Last Number:** Double-press the Play-Pause / Call button.

## Voice Assistant

The Xech A8 headphones are optimized for voice assistants like Siri and Google Assistant.

- **To Activate:** Double-press the Play-Pause / Call button quickly.
- Once activated, you can issue commands through the headphone's built-in microphone.



Xech A8 Headphones are optimized for voice assistants like Siri and Google Assistant.

## Maintenance and Care

Proper care will extend the life of your Xech A8 headphones.

- Clean the headphones with a soft, dry cloth. Do not use abrasive cleaners, solvents, or harsh chemicals.
- Avoid exposing the headphones to extreme temperatures, high humidity, or direct sunlight.
- Store the headphones in the provided EVA carrying case when not in use to protect them from dust, scratches, and impacts.
- Do not attempt to disassemble or modify the headphones, as this will void the warranty and may cause damage.
- Keep the headphones away from water and other liquids.

## Troubleshooting

If you encounter issues with your Xech A8 headphones, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Headphones do not power on	Low battery	Charge the headphones fully using the provided Micro USB cable.
Cannot pair via Bluetooth	Headphones not in pairing mode / Device Bluetooth off / Too far from device	Ensure headphones are in pairing mode (LED flashing blue/red). Turn on Bluetooth on your device. Move headphones closer to the device (within 10 meters).
No sound in Bluetooth mode	Volume too low / Headphones not paired / Incorrect audio output selected on device	Increase headphone and device volume. Re-pair the headphones. Check your device's audio output settings.
No sound in AUX mode	AUX cable not fully inserted / Cable damaged	Ensure the AUX cable is securely connected at both ends. Try a different AUX cable if available.
Poor call quality	Microphone obstructed / Weak Bluetooth signal	Ensure the microphone is clear of obstructions. Move closer to the connected device to improve signal strength.
Voice Assistant not responding	Not activated correctly / Device not supporting voice assistant	Double-press the Play-Pause / Call button to activate. Ensure your connected device supports Siri or Google Assistant.

## Technical Specifications

Feature	Detail
Model	A8
Connectivity	Bluetooth 5.0, 3.5mm AUX

Feature	Detail
Play Time	8-9 hours (at 60% volume)
Charging Time	Approx. 2-3 hours
Battery	1 Lithium Ion (included)
Microphone	Built-in
Control Method	Buttons, Voice
Form Factor	Over-Ear, Foldable
Material	Plastic, Rubber
Dimensions (LxWxH)	19.5 x 8 x 17 cm
Weight	449 g
Noise Control	Sound Isolation
Special Features	Adjustable Headband, Premium Rubber Finish, Travel EVA Case, Voice Assist

## WARRANTY INFORMATION

---

The Xech A8 Wireless Bluetooth Over-Ear Headphones come with a 1-year limited warranty from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, improper storage, or normal wear and tear. Please retain your proof of purchase for all warranty claims.

## CUSTOMER SUPPORT

---

For further assistance, technical support, or warranty inquiries regarding your Xech A8 headphones, please contact Xech customer service. Refer to the contact information provided on the product packaging or visit the official Xech website for the most up-to-date support details.

You can also find more information and products from Xech by visiting their store on Amazon:

[Visit the Xech Store on Amazon](#)