

Akai Professional Force

AKAI Professional FORCE Standalone Music Production System User Manual

Model: Force

Brand: Akai Professional

1. INTRODUCTION

The AKAI Professional FORCE is a standalone music production and DJ performance system designed for comprehensive end-to-end workflows. It integrates clip-launching, a linear arranger, MIDI Multi capability, step sequencing, sampling, and advanced synth engines, all within a single device. This manual provides instructions for setting up, operating, and maintaining your FORCE unit.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- FORCE Unit
- User Manual (this document)
- APC Live Software Download Card
- Safety and Warranty Manual
- USB Cable
- (3) 1/8" to 5-pin DIN MIDI Cables

3. SETUP

3.1. Power Connection

Connect the included power adapter to the FORCE unit and then to a power outlet. Ensure the power switch is in the OFF position before connecting the power supply.

3.2. Audio Connections

The FORCE unit offers versatile audio input and output options:

- **Inputs:** Two XLR / 1/4-inch combo inputs with phantom power. These inputs are switchable between line and instrument levels.

- **Outputs:** Two stereo ¼-inch outputs and a dedicated headphone output.

Connect your audio sources (microphones, instruments) to the inputs and your monitoring system (speakers, headphones) to the outputs.



THE INS AND OUTS

- | | |
|--|--|
| <p>1 (2) XLR / ¼-INCH COMBO INPUTS
With phantom power, switchable to line/instrument level</p> | <p>2 (2) STEREO ¼-INCH OUTPUTS AND HEADPHONE OUTPUT</p> |
| <p>3 4 CONFIGURABLE CV/GATE OUTPUTS</p> | <p>4 MIDI IN / OUT / THRU
With MIDI multi capability</p> |

Image: Rear panel connections of the AKAI Professional FORCE, highlighting the XLR/¼-inch combo inputs, stereo ¼-inch outputs, headphone output, CV/Gate outputs, and MIDI In/Out/Thru ports.

3.3. MIDI and CV/Gate Connections

Integrate the FORCE with your studio equipment using its MIDI and CV/Gate capabilities:

- **MIDI:** MIDI In, Out, and Thru ports with MIDI multi capability. Use the included 1/8" to 5-pin DIN MIDI cables for connecting external MIDI devices.
- **CV/Gate:** Four configurable CV/Gate outputs for connecting to modular synthesizers and other compatible equipment.



AKAI
PROFESSIONAL

FORCE

Image: The AKAI Professional FORCE connected to external audio interfaces and MIDI devices, demonstrating its integration capabilities within a studio setup.

3.4. Storage Expansion

The FORCE includes 16GB of internal storage. You can expand this using:

- **SD Card Slot:** A full-size SD card slot for additional media.
- **USB 3.0 Slots:** Two USB 3.0 slots for thumb drives or MIDI controllers.
- **SATA Drive Connector:** A user-expandable 2.5" SATA drive connector for SSD or HDD, enabling disk streaming of audio files.

NOW FEATURING
DISK STREAMING

Audio files can now be streamed from 2.5" SATA drive (SSD or HDD)



AND EXPAND YOUR PALETTE OF SOUNDS VIA

16GB OF ON-BOARD STORAGE

FULL-SIZE SD CARD SLOT & 2 USB 3.0 SLOTS

For thumb drives or MIDI controllers

Image: A user inserting an SD card into the dedicated slot on the AKAI Professional FORCE, with the USB 3.0 ports also visible, illustrating storage expansion options.

4. OPERATING INSTRUCTIONS

4.1. User Interface Overview

The FORCE features a 7-inch, full-color, capacitive multi-touch display, which serves as the central interface for clip launching, sound browsing, MIDI editing, sample manipulation, and composition arrangement. Tactile controls include an 8x8 clip launch matrix with RGB LEDs and 360-degree rotary encoders with OLED feedback for real-time parameter access.



STANDALONE MUSIC PRODUCTION AND DJ PERFORMANCE SYSTEM



7" full colour capacitive
multi-touch display



8x8 clip launch
matrix with RGB LEDs

Image: A user's hands operating the AKAI Professional FORCE, demonstrating interaction with the multi-touch display and the illuminated 8x8 clip launch matrix.

4.2. Basic Workflow

The FORCE supports a comprehensive production workflow:

1. **Clip Launching:** Use the 8x8 matrix to trigger scenes and clips for performance and arrangement.
2. **Step Sequencing:** Create and edit patterns using the step sequencer.
3. **Sampling:** Record and manipulate samples directly on the device.
4. **Synth Engines:** Utilize the 8 built-in synthesizer engines for sound design.
5. **Arrangement:** Arrange your compositions using the linear song arranger.
6. **Mixing and Effects:** Apply XYFX and other effects, and mix your tracks using the tactile controls and touch display.

REMIX, MASH-UP, DJ & PRODUCE WITH



8 Synthesizer
Engines



6 Track Types



A Linear
Song Arranger



Complete Audio/MIDI/
CV Performance
Capability




Image: A detailed view of the AKAI Professional FORCE in use, with a hand adjusting a rotary encoder while the multi-touch display shows a waveform, illustrating the device's production capabilities.

4.3. Sound Content and Splice Integration

The FORCE comes preloaded with over 10GB of sounds from various providers. It also features native Splice integration, allowing direct Wi-Fi access to your Splice library for browsing and auditioning millions of royalty-free samples, sounds, presets, and loops.



AKAI
PROFESSIONAL

FORCE

STANDALONE MUSIC PRODUCTION/ DJ PERFORMANCE SYSTEM

Image: The AKAI Professional FORCE's touch screen displaying a sound library browser, indicating the integration with Splice for accessing extensive sound content.

5. MAINTENANCE

5.1. Cleaning

To clean the FORCE, use a soft, dry cloth. For the display, use a microfiber cloth specifically designed for screens. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish or electronic components.

5.2. Software Updates

Regularly check the Akai Professional website for firmware updates. Updates can introduce new features, improve performance, and fix bugs. Follow the instructions provided with each update carefully.

5.3. Storage

When not in use, store the FORCE in a cool, dry environment, away from direct sunlight and extreme temperatures. Protect the unit from dust and moisture. If transporting, use a dedicated case to prevent physical damage.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your AKAI Professional FORCE. For more detailed troubleshooting, refer to the official Akai Professional support resources.

6.1. No Power

- Ensure the power adapter is securely connected to both the FORCE and a working power outlet.
- Verify that the power switch on the FORCE is in the ON position.
- Test the power outlet with another device to confirm it is functional.

6.2. No Sound Output

- Check all audio cable connections from the FORCE outputs to your speakers or headphones.
- Ensure the master volume knob on the FORCE is turned up.
- Verify that individual track volumes and mixer levels within the FORCE software are not muted or set too low.
- Confirm that your monitoring system (speakers, headphones) is powered on and functioning correctly.

6.3. MIDI Device Not Responding

- Check MIDI cable connections between the FORCE and your external MIDI device.
- Ensure the MIDI settings within the FORCE are correctly configured to send and receive data from the connected device.
- Verify that the external MIDI device is powered on and its MIDI settings are compatible with the FORCE.

6.4. Display Issues

- If the display is unresponsive, try restarting the FORCE unit.
- Ensure your fingers are clean and dry when interacting with the multi-touch display.

7. SPECIFICATIONS

Feature	Detail
Item Weight	9.9 pounds
Product Dimensions	15.16"D x 13.78"W x 2.95"H (38.5cm D x 35cm W x 7.5cm H)
Model Name	Force
Brand	Akai Professional
Display	7-inch Multi-Touch Display
Pads	8x8 Clip Launch Matrix with RGB LEDs
Inputs	(2) XLR / ¼-inch Combo Inputs (with phantom power, switchable line/instrument)
Outputs	(2) Stereo ¼-inch Outputs, Headphone Output
MIDI Connectivity	MIDI In / Out / Thru (with MIDI multi capability)
CV/Gate Outputs	(4) Configurable CV/Gate Outputs



Storage	16GB On-board, Full-Size SD Card Slot, (2) USB 3.0 Slots, 2.5" SATA Drive Connector (SSD or HDD)
Connectivity Technology	USB
Hardware Interface	USB 3.0
Compatible Devices	Laptop
Supported Software	Ableton Live
Body Material	Plastic
Color Name	Black
Date First Available	January 17, 2019


8. WARRANTY AND SUPPORT

For detailed warranty information and technical support, please refer to the included Safety and Warranty Manual or visit the official Akai Professional website. Product registration is recommended to receive updates and support.


Akai Professional Website: www.akaiapro.com

Related Documents - Force

	Akai Professional MPC ONE Quickstart Guide A concise guide to getting started with the Akai Professional MPC ONE, covering its features, box contents, connection diagram, and basic controls for music production.
	Akai MPC One User Guide: Navigation, Controls, and Connectivity Comprehensive guide to the Akai MPC One, detailing its top panel controls, navigation, data entry, Q-Link knobs, and rear panel connections for music production.
	Akai MPC Live III User Guide: Music Production System Manual Comprehensive user guide for the Akai MPC Live III, detailing its MPC 3 operating system features, setup, operation, recording, editing, and advanced music production workflows. Includes links to Akai Professional support.

	Akai Professional MPC User Guide: MPC X, Live, One, Key, Studio, Touch A comprehensive user guide for Akai Professional's MPC series, covering setup, operation, and features for MPC X, MPC X Special Edition, MPC Live, MPC Live II, MPC One, MPC One+, MPC Key 61, MPC Key 37, MPC Studio mk2, and MPC Touch.
	Akai MPC One Quickstart Guide A quickstart guide for the Akai MPC One, detailing its features, navigation, controls, and connections. This guide is available in multiple languages.
	Akai MPC Studio mk2 Quickstart Guide A comprehensive guide to setting up and using the Akai MPC Studio mk2, covering features, software installation, hardware connections, and control descriptions for music production.

Documents - Akai Professional – Force




[pdf] User Manual Guide Diagram

MPK261 User Guide Akai Professional Manual markertek Attachments Manuals |||

User Guide English Manual Version 1.0 Table of Contents Click a chapter/section to jump to it. I ... elocities, becoming flatter at high velocities. At the maximum setting of 50, it takes very little **force** to generate a velocity value of 127. Gain: An offset to keyboard s overall velocity sensitivit...

lang:nl score:44 filesize: 1.92 M page_count: 46 document date: 2018-01-25



[\[pdf\]](#) User Manual Guide Diagram

MPK249 User Guide Akai Professional Guidempk249 user guide v1 0synthmanuals manuals akai mpk249 |||

User Guide English Manual Version 1.0 Table of Contents Click a chapter/section to jump to it. I ... elocities, becoming flatter at high velocities. At the maximum setting of 50, it takes very little **force** to generate a velocity value of 127. Gain: An offset to keyboard s overall velocity sensitivit...


lang:nl **score:42** filesize: 1.91 M page_count: 45 document date: 2014-03-10



[Akai MPC Studio mk2 Quickstart Guide](#)

A comprehensive guide to setting up and using the Akai MPC Studio mk2, covering features, software installation, hardware connections, and control descriptions for music production.

lang:en **score:41** filesize: 5.34 M page_count: 36 document date: 2021-01-27



[\[pdf\]](#) User Manual Guide

Force User Guide Akai Professional Recordcase de recordcase media Manual c6 34 47 |||

User Guide English Manual Version 1.0 Table of Contents Introduction demarks Licenses257 5 Introduction Thank you for purchasing the **Force**. At Akai Professional, we know how serious music is to you. That s why we design our equipment...

lang:en **score:41** filesize: 46.27 M page_count: 259 document date: 2022-02-08




[\[pdf\]](#) User Manual Quick Start Guide Guide

MPC Touch User Guide Akai Professional AKA MPCTOUCH manual media americanmusical ItemFiles Manual |||

User Guide English Manual Version 1.0 Table of Contents

Introduction..... e pads will always trigger their samples at the maximum velocity 127 , regardless of the amount of **force** you use. Press and hold Shift and then press this button to activate/deactivate Half Level. Wh...

lang:tl **score:40** filesize: 12.85 M page_count: 301 document date: 2017-01-12




[\[pdf\]](#) User Manual Quick Start Guide Guide

User Guide MPC Software Akai Professional Touch v2 2mpcsoftwaremanualmidimanuals manuals akai mpc touch software user guide 2 mpcsoftwaremanual |||

User Guide English Manual Version 2.2 Table of Contents Introduction

..... her buttons. Display: This determines how the display functions for a connected MPC Touch. Applied **Force** Screen Dimming: This determines how much time must pass before your MPC hardware automaticall...

lang:en **score:40** filesize: 10.66 M page_count: 236 document date: 2018-04-04




[\[pdf\]](#) User Manual Quick Start Guide Guide

User Guide MPC X Live Touch Akai Professional Guidempctuimanualsynthmanuals manuals akai mpc x user guide mpctuimanual |||

User Guide English Manual Version 2.2 Table of Contents Introduction

..... ilable for MPC X only, not for MPC Live or MPC Touch, which do not have footswitch inputs. Applied **Force** MIDI Control Mode Output: This determines which MIDI port the MPC hardware is using to send M...

lang:nl **score:39** filesize: 47.76 M page_count: 336 document date: 2018-04-04




[\[pdf\]](#) User Manual Guide Warranty Diagram

MPK249 Quickstart Guide Akai Professional Italianmpk249 quickstart guide v1 0synthmanuals manuals akai mpk249 italian |||

Quickstart Guide English 3 9 Gua de inicio rpido Espaol 10 16 Guide d utilisation simplifi ... ue le mode Full Level est activ, les pads jouent toujours la vlocit maximale 127 , peu importe la **force** laquelle ils sont frappes. 19. 16 Level : Lorsque le mode 16 Level est activ, le dernier pad d...

lang:en **score:39** filesize: 3.51 M page_count: 44 document date: 2014-02-10




[\[pdf\]](#) User Manual Guide

Advance 61 User Guide Akai Professional 560158 01U imagescdn junco co uk manual |||

User Guide English Manual Version 1.0 Table of Contents Click a chapter/section to skip to it. I ... city sensitivity of Advance 61 s keyboard. The available range is 110. At 1, it would take a lot of **force** to generate the maximum velocity value of 127. At 10, it is fairly easy to generate a maximum-...

lang:en **score:38** filesize: 3.09 M page_count: 48 document date: 2017-08-11




[\[pdf\]](#) User Manual Documentation Guide Warranty

MPD232 User Guide Akai Professional akai mpd232 manuals coolblue be c7 |||

User Guide English 3 16 Gua del usuario Espaol 17 30 Guide d utilisation Franais 31 44 ... n: The pads overall velocity sensitivity. The available range is 110. At 1, it would take a lot of **force** to generate a velocity value of 127. At 10, the opposite is true. Tempo Tempo: The global temp...


lang:en **score:37** filesize: 3.36 M page_count: 76 document date: 2016-09-08



[Akai MPC Live III User Guide: Music Production System Manual](#)

Comprehensive user guide for the Akai MPC Live III, detailing its MPC 3 operating system features, setup, operation, recording, editing, and advanced music production workflows. Includes links to Akai Professional support.

lang:en **score:37** filesize: 30.51 M page_count: 513 document date: 2025-10-20




[\[pdf\] User Manual Guide Diagram](#)

MPD26 Quickstart Guide RevA Akai Professional Mpd 26 Manual Pdf Operator s aka mpd26 quickstart americanmusical ItemFiles |||

QUICKSTART GUIDE ENGLISH 1 - 10 GUA DE INICIO RPIDO ESPAOL 11 - 20 GUIDE D UTILISATION RAPID ... ow sensitive the pads are to the touch. Adjust how the pads will output MIDI velocity, based on the **force** applied to them. Adjust the threshold of minimum **force** required to activate a pad. Select Inte...

lang:en **score:37** filesize: 7.05 M page_count: 52 document date: 2014-01-28




[\[pdf\] User Manual Quick Start Guide Guide](#)

MPC Touch User Guide Akai Professional AKAI Manual EN recordcase de media 86 8a 88 |||

User Guide English Manual Version 1.0 Table of Contents

Introduction..... e pads will always trigger their samples at the maximum velocity 127 , regardless of the amount of **force** you use. Press and hold Shift and then press this button to activate/deactivate Half Level. Wh...

lang:tl **score:36** filesize: 41.45 M page_count: 301 document date: 2019-08-05




[\[pdf\]](#) User Manual Quick Start Guide Guide

MPC Live User Guide Akai Professional AKAI Manual EN recordcase de media e1 5f 82

User Guide English Manual Version 1.0 Table of Contents Introduction

..... e pads will always trigger their samples at the maximum velocity 127 , regardless of the amount of **force** you use. Press and hold Shift and then press this button to activate/deactivate Half Level. Wh...

lang:en **score:36** filesize: 47.08 M page_count: 211 document date: 2019-05-17



[\[pdf\]](#) User Manual Guide

MPC Software User Guide Akai Professional AKAI Studio Manual EN recordcase de media 8b b4 37

User Guide English Manual Version 1.9 Table of Contents

Introduction..... ally linear, while the B, C, and D pad curves are exponential. See diagram to the right. Applied **Force** 103 o Footswitch 1 and Footswitch 2: Click these drop-down menus to select the functionalit...

lang:en **score:36** filesize: 19.13 M page_count: 373 document date: 2019-06-03



[\[pdf\]](#) User Manual Quick Start Guide Instructions Guide

User Guide MPC Software Akai Professional Table of Contents Introduction 7 System Requirements

Product Support About This 8 Important MpcSoftwareManual 8f294c9386a3c4c402eectb29b9800cf


b8e57dc469f9d8f4cea5 1e3c2cee90259c12021d38ebd8ad6f0f r79 cf2 rackcdn Documents Rackcdn

Follow the on screen instructions to complete installation Note By default software will be installed in your hard drive Program Files mpcsoftwaremanual synthmanuals manuals akai mpc touch user guide v2 2 manual describes features 1 application For consistency terminology throughout is based parameter names akaipro amfile file 330 product 11

User Guide English Manual Version 2.2 Table of Contents Introduction

..... her buttons. Display: This determines how the display functions for a connected MPC Touch. Applied **Force** Screen Dimming: This determines how much time must pass before your MPC hardware automaticall...

lang:en **score:36** filesize: 10.66 M page_count: 236 document date: 2018-04-04




[\[pdf\]](#) User Manual Quick Start Guide Guide

User Guide MPC X Live Touch Akai Professional akai mpc x manuals coolblue nl 80 |||

User Guide English Manual Version 2.2 Table of Contents Introduction

..... ilable for MPC X only, not for MPC Live or MPC Touch, which do not have footswitch inputs. Applied **Force** MIDI Control Mode Output: This determines which MIDI port the MPC hardware is using to send M...

lang:nl **score:36** filesize: 6.34 M page_count: 336 document date: 2018-05-24




[\[pdf\]](#) Quick Start Guide Guide Warranty

EWI5000 Quickstart Guide Akai Professional Spanishewi5000 quickstartguide v1 0synthmanuals manuals akai ewi5000 quickstart guide spanish Spanish Italian 0 synthmanuals italian |||

Quickstart Guide English 3 - 9 Gu a de inicio r pido Espa ol 10 - 16 Guide d utilisation ... cessaire pour mettre un son . Secondaire : d finit le gain du capteur de souffle du EWI5000 la **force** n cessaire pour jouer ; un r glage plus lev diminue la plage dynamique . Primaire : d f...

lang:en **score:35** filesize: 3.34 M page_count: 40 document date: 2014-04-21



[\[pdf\]](#) User Manual Guide Diagram

MPK261 User Guide Akai Professional Download Manual » im Recordcase DJ Shop bestellen recordcase de media 07 98 a5 |||

User Guide English Manual Version 1.0 Table of Contents Click a chapter/section to jump to it. I ... elocities, becoming flatter at high velocities. At the maximum setting of 50, it takes very little **force** to generate a velocity value of 127. Gain: An offset to keyboard s overall velocity sensitivit...

lang:nl **score:35** filesize: 1.93 M page_count: 46 document date: 2019-05-15




[\[pdf\]](#) User Manual Specifications Documentation Guide Warranty

MPC Studio mk2 Quickstart Guide Akai Professional Download Il Bedienungsanleitung User Manual DE EN FR IT ES 2 » Online kopen in de Recordcase DJ Shop recordcase media b2 61 f5 |||

MPG STLJIIJICJ Quickstart Guide English 3 8 Gua de inicio rpido Espaol 9 14 Guide d utilis ... e pads will always trigger their samples at the maximum velocity 127 , regardless of the amount of **force** you use. Press and hold Shift and then press this button to activate/deactivate Half Level. Wh...

lang:en **score:34** filesize: 5.35 M page_count: 36 document date: 2021-11-23




[\[pdf\]](#) User Manual Guide

Advance 25 User Guide Akai Professional Download Advance25 Manual » im Recordcase DJ Shop bestellen UserGuide recordcase de media 69 87 c8 |||

User Guide English Manual Version 1.0 Table of Contents Click a chapter/section to skip to it. I ... city sensitivity of Advance 25 s keyboard. The available range is 110. At 1, it would take a lot of **force** to generate the maximum velocity value of 127. At 10, it is fairly easy to generate a maximum-...

lang:en **score:34** filesize: 3.32 M page_count: 48 document date: 2019-07-26




[\[pdf\]](#) User Manual Instructions Specifications Documentation Guide Warranty

MPC X Special Edition Quickstart Guide Akai Professional Instructions d utilisation 5 11 MB SE Magasin de musique 282736 m cdn korn eu documents product |||

Quickstart Guide English 2 10 Gua de inicio rpido Espaol 11 19 Guide d utilisation Franais ... d, the pads will always trigger their samples at the maximum velocity 127 , regardless of how much **force** you use. Press and hold Shift and then press this button to activate or deactivate the Half Le...

lang:en **score:33** filesize: 5.11 M page_count: 48 document date: 2022-10-18




[\[pdf\]](#) User Manual Guide Warranty

MPK mini User Guide Akai Professional Mini mkII Germanmpk user guide v1 0synthmanuals manuals akai mpk mkii german →Akai MK3 original SoundiumAkai German1000701mpk 0soundium dk cdn shop files 1000701 v 637893242110046067synthmanuals |||

User Guide English 3 5 Gua del usuario Espaol 6 8 Guide d utilisation Franais 9 11 Gu ... ue le mode Full Level est activ, les pads jouent toujours la vlocit maximale 127 , peu importe la **force** laquelle ils sont frapps. 13. Note Repeat : Maintenir cette touche tout en frappant un pad pe...

lang:en **score:33** filesize: 1.25 M page_count: 20 document date: 2014-03-24




[\[pdf\]](#) User Manual Specifications Documentation Guide Warranty

MPC X Quickstart Guide Akai Professional Italianmpc x quickstart guidesynthmanuals manuals akai mpc guide italian ItalianAkai Englishmpc guidempc english EnglishAkai Frenchmpc french FrenchAkai Spanishmpc spanish SpanishAkai Germanmpc german |||

Quickstart Guide English 2 10 Gua de inicio rpido Espaol 11 19 Guide d utilisation Franais ... d, the pads will always trigger their samples at the maximum velocity 127 , regardless of how much **force** you use. Press and hold Shift and then press this button to activate or deactivate the Half Le...

lang:en **score:33** filesize: 6.74 M page_count: 48 document date: 2016-11-30



[\[pdf\]](#) User Manual Quick Start Guide Specifications Documentation Guide Warranty

APC Live Quickstart Guide Akai Professional Users Manual 1 INMUSIC BRANDS INC ADA2 Clip Controller Y4O Y4OADA2 ada2

Quickstart Guide English 3 11 Gua de inicio rpido Espaol 12 20 Guide d utilisation rapide ... uide for more information. 5. USB-B Port: Use the included USB cable to connect this high-retention-**force** USB port to an available USB port on your computer. 6. USB-A Ports: Connect USB flash drives t...

lang:en **score:33** filesize: 4.16 M page_count: 30 document date: 2018-06-15




[\[pdf\]](#) User Manual Specifications Documentation Guide Warranty

MPC Studio mk2 Quickstart Guide Akai Professional akai mpc studio trovaprezzi it manuali |||

Questo manuale d'istruzione fornito da trovaprezzi.it. Scopri tutte le offerte per Akai MPC Studio ... e pads will always trigger their samples at the maximum velocity 127 , regardless of the amount of **force** you use. Press and hold Shift and then press this button to activate/deactivate Half Level. Wh...

lang:en **score:33** filesize: 5.39 M page_count: 36 document date: 2021-06-25



[\[pdf\]](#) User Manual Guide

Force User Guide Akai Professional 0213c09433a8fcc0e4191f6f080ec98a pult ru upload iblock 021 |||


User Guide English Manual Version 1.1 Table of Contents Introduction

.....257 Addendum258

Updates in **Force** 3.0.2258 New

Features.....

lang:en **score:32** filesize: 28.61 M page_count: 260 document date: 2019-04-04



[\[pdf\]](#) User Manual Instructions Frequently Asked Questions Troubleshooting Guide Specifications Guide Diagram


MPK49 Multilingual Quickstart Manual Rev1 2 Akai Professional QUICKSTART MANUAL GUÍA DE INICIO RÁPIDO GUIDE D UTILISATION This is intended to give you a brief overview of the functionality and features In this manual will find instructions on how connect use its basic For detailed information we recommend reading Operator s included software CD Enjoy! HOOKUP DIAGRAM VERSION 1 PROGRAM CHANGE MODE 15 INTRODUCTION way can avoid having manually switch between different programs your DAW or external device mpk49 quickstart guide v1 00

52cdb19c1789589a9e72789afe03bb0c home httpd data media b AKAI IT b8e57dc469f9d8f4cea5

1e3c2cee90259c12021d38ebd8ad6f0f r79 cf2 rackcdn Product Documents akaipro amfile file 582 product 62 c3 zzounds ba2658d7e87a2681c9ae959cd379e84c strumentimusicali net manuali 80 stuff contentmgr files 0 130f3826e453c93d1020f9581e9e131b

QUICKSTART MANUAL ENGLISH 5 - 15 GUA DE INICIO RPIDO ESPAOL 19 - 29 GUIDE D UTILISATION RAPI ... ow sensitive the pads are to the touch. Adjust how the pads will output MIDI velocity, based on the **force** applied to them. Adjust the threshold of minimum **force** required to activate a pad. Transpose t...

lang:en **score:32** filesize: 2.31 M page_count: 76 document date: 2007-10-01



[\[pdf\]](#) User Manual Guide Warranty

MPC Live II Quickstart Guide Akai Professional Download User Manual DE EN FR ES IT » Online kopen in de Recordcase DJ Shop recordcase media 43 c3 f6 |||

PROFESSIONAL MFELIVE II Quickstart Guide English 2 7 Gua de inicio rpido Espaol 8 14 Guide ... e pads will always trigger their samples at the maximum velocity 127 , regardless of the amount of **force** you use. Press and hold Shift and then press this button to activate/deactivate Half Level. Wh...

lang:en **score:31** filesize: 6.99 M page_count: 36 document date: 2022-02-08




[\[pdf\]](#) User Manual Specifications Documentation Guide Warranty

MPC Studio mk2 Quickstart Guide Akai Professional home httpd data media 0 cf3 zzounds 09e55d01612b12663ac9118e22baba2f |||

Quickstart Guide English 3 8 Gua de inicio rpido Espaol 9 14 Guide d utilisation rapide Fr ... e pads will always trigger their samples at the maximum velocity 127 , regardless of the amount of **force** you use. Press and hold Shift and then press this button to activate/deactivate Half Level. Wh...

lang:en **score:31** filesize: 5.34 M page_count: 36 document date: 2021-06-25




[\[pdf\]](#) User Manual Quick Start Guide Specifications Documentation Guide

LPD8 mk2 Program Editor User Guide Akai Professional Manual AKAI USB MIDI Controller with 8 Responsive RGB MPC Drum Pads for Mac and PC Assignable Knobs Music Production Software Black A1yK5U5D2DL m media amazon images I |||

Program Editor User Guide English Manual Version 1.1 Table of Contents Introduction , the pads will always trigger their samples at the maximum velocity 127 , regardless of how much **force** you use. Global MIDI Channel: When a pad or knob is set to the Global MIDI channel, it will us...

lang:en **score:31** filesize: 1.06 M page_count: 11 document date: 2021-08-31



[\[pdf\]](#) User Manual Guide

MPC Software User Guide Akai Professional 8 About This Manual manual was written to help you get familiar with the hardware and software To avoid confusion terminology in this is based on parameter names v1 5 6be54c364949b623a3c0 4409a68c214f3a9eeca8d0265e9266c0 r0 cf2 rackcdn 450 documents |||

User Guide English Manual Version 1.5 Table of Contents Welcome to the MPC nce s power on/off. 4. Computer USB Port: Use the included USB cable to connect this high-retention-**force** USB port to an available USB port on your computer. This connection allows MPC Renaissance to ...

lang:it **score:31** filesize: 6.34 M page_count: 219 document date: 2014-06-10



[\[pdf\]](#) User Manual Specifications Documentation Guide Warranty

MPC Studio mk2 Quickstart Guide Akai Professional Manual de usuario Controlador MIDI caja ritmos con 16 pads RGB sensibles a la velocidad software banda táctil asignable y pantalla LCD Amazon es Instrumentos musicales C1gsX1RArAL m media amazon images I |||

Quickstart Guide English 3 8 Gua de inicio rpido Espaol 9 14 Guide d utilisation rapide Fr ... e pads will always trigger their samples at the maximum velocity 127 , regardless of the amount of **force** you use. Press and hold Shift and then press this button to activate/deactivate Half Level. Wh...

lang:en **score:31** filesize: 5.35 M page_count: 36 document date: 2023-04-17



[\[pdf\]](#) User Manual Installation Guide Guide Warranty Accessories

AFX User Guide Akai Professional USB Cable Software Download Card Safety Warranty Manual Important is an Official Serato Accessory and requires a supported DJ interface controller or mixer to control EN recordcase de media ba 77 72

User Guide English 3 9 Gua del usuario Espaol 10 16 Guide d utilisation Franais 17 23 ... uf qu ils sont sensibles la dynamique et le volume des chantillons dclenchs sera proportionnel la **force** avec laquelle les pads sont frapps. Ce mode peut vous aider obtenir une performance plus rali...

lang:en **score:31** filesize: 2.62 M page_count: 40 document date: 2019-05-24




[\[pdf\] User Manual Quick Start Guide Guide](#)

User Guide MPC X Live One Touch Akai Professional small v2 7 2 akai pro jp mpc one data ||| ||| User Guide English Manual Version 2.7.2 Table of Contents Introduction 7 System Requirements Product Support . 7 About This User Guide . 7 Important Notes 8 Setup 8 1. Connection 8

User Guide English Manual Version 2.7.2 Table of Contents Introduction

..... r MPC X only, not for MPC Live, MPC One or MPC Touch, which do not have footswitch inputs. Applied **Force** MIDI Control Mode Output: This determines which MIDI port the MPC hardware is using to send M...

lang:nl **score:31** filesize: 11.35 M page_count: 394 document date: 2020-03-23



[Akai MPC Key 61 Quickstart Guide](#)

Get started with the Akai MPC Key 61, a powerful production and synthesizer keyboard. This guide covers essential features, connections, and basic operation for the MPC Key 61.

lang:en **score:31** filesize: 2.1 M page_count: 52 document date: 2022-01-26




[\[pdf\] User Manual Quick Start Guide Specifications Documentation Guide Warranty](#)

Force Quickstart Guide Akai Professional Full Compass Systems English Introduction Thank you for purchasing the At we know how serious music is to That s why design 447626 d1aeri3ty3izns cloudfront net media 44 For this tutorial tap Deep House Colors Demo project load it Download full User more information 5 716904 01U imagescdn junco co uk manual Español 12 20 Safety Warranty Manual Important Visit akaipro and find webpage complete user guide Support latest about product documentation technical specifications system requirements compatibility etc registration visit kraftmusic ownersmanual

Quickstart Guide English 3 11 Gua de inicio rpido Espaol 12 20 Guide d utilisation rapide Franais 21 29 Guida rapida Italiano 30 38 Schnellstart-Anleitung Deutsch 39 47 Appendix English 49 50 2 Quickstart Guide English Introduction Thank you for purchasing the For...

lang:en **score:31** filesize: 5.81 M page_count: 52 document date: 2018-11-06




[\[pdf\]](#) User Manual Guide

Force User Guide Akai Professional muzcentre.ru 2 Table of Contents Introduction 6 Support AKAI PRO FORCE |||

<https://muzcentre.ru> User Guide English Manual Version 1.0 Table of Contents Introduction demarks Licenses257 5 Introduction Thank you for purchasing the **Force**. At Akai Professional, we know how serious music is to you. That's why we design our equipment...

lang:en score:31 filesize: 5.66 M page_count: 259 document date: 2023-11-12




[\[pdf\]](#) User Manual Quick Start Guide Guide

User Guide MPC Software Akai Professional This manual describes features in the and Beats software applications For consistency terminology throughout is based on parameter names MPCSoftware UserGuide v2.8 akaipro amfile file 1020 product 85

User Guide English Manual Version 2.8 Table of Contents Introduction her buttons. Display: This determines how the display functions for a connected MPC Touch. Applied **Force** Screen Dimming: This determines how much time must pass before your MPC hardware automaticall...

lang:en score:31 filesize: 13.81 M page_count: 272 document date: 2020-05-11



[\[pdf\]](#) User Manual Specifications Documentation Guide Warranty Diagram

MPC Key 61 Quickstart Guide Akai Professional Microsoft Users Manual INMUSIC BRANDS INC ACVM Y4O Y4OACVM acvm

Quickstart Guide English 3 11 Gua de inicio rpido Espaol 12 20 Guide d utilisation rapide ... e pads will always trigger their samples at the maximum velocity 127 , regardless of the amount of **force** you use. Press and hold Shift and press this button to activate/deactivate Half Level. When ac...

lang:en score:31 filesize: 4.2 M page_count: 52 document date: 2021-05-20



[\[pdf\]](#) User Manual Documentation Guide Warranty


MPD226 User Guide Akai Professional Download AKAI Manual MPD 226 » im Recordcase DJ Shop

bestellen EN recordcase de media dc 18 82 |||

User Guide English 3 12 Gua del usuario Espaol 13 22 Guide d utilisation Franais 23 32 ... n: The pads overall velocity sensitivity. The available range is 110. At 1, it would take a lot of **force** to generate a velocity value of 127. At 10, the opposite is true.

Tempo Tempo: The global temp...

lang:en **score:31** filesize: 2.4 M page_count: 56 document date: 2019-05-20



[\[pdf\]](#) User Manual Documentation Guide Warranty

MPC Live II Quickstart Guide Akai Professional American Musical Supply 4 8 Full Level Half Press this

button to activate deactivate When activated the pads will always trigger their samples at maximum

velocity 127 regardless of amount force you use and hold Shift then press half 64 AKA MPCLIVE2XL


manual americanmusical media manuals rebates |||

Quickstart Guide English 2 7 Gua de inicio rpido Espaol 8 14 Guide d utilisation rapide

Fr ... e pads will always trigger their samples at the maximum velocity 127 ,

regardless of the amount of **force** you use. Press and hold Shift and then press this button to activate/deactivate Half Level. Wh...

lang:en **score:30** filesize: 7.01 M page_count: 36 document date: 2020-05-12



[\[pdf\]](#) User Manual Specifications Documentation Guide Warranty

MPK mini Play mk3 User Guide Akai Professional akai mpk play trovaprezzi it manuali |||


Questo manuale d istruzione fornito da trovaprezzi.it. Scopri tutte le offerte per Akai

MPK Mini PI ... t de dsactiver le mode Full Level qui fait jouer les pads la vlocit

maximale 127 , peu importe la **force** laquelle ils sont frapps. 8. Note Repeat :

Maintenir cette touche enfonce tout en frappant un...

lang:en **score:30** filesize: 2.12 M page_count: 28 document date: 2022-06-21




[\[pdf\]](#) User Manual Specifications Documentation Guide Warranty

MPC Studio mk2 Quickstart Guide Akai Professional Go to akaipro and register your product If you don't have an account yet will be prompted create one v1 1 |||

Quickstart Guide English 3 8 Guía de inicio rápido Español 9 14 Guide d'utilisation rapide Fr ... e pads will always trigger their samples at the maximum velocity 127 , regardless of the amount of **force** you use. Press and hold Shift and then press this button to activate/deactivate Half Level. Wh...

lang:en **score:30** filesize: 5.34 M page_count: 36 document date: 2021-01-27




[\[pdf\]](#) User Manual Guide Warranty Diagram

MPK225 User Guide Akai Professional recordcase de 5 Introduction Box Contents USB Cable Quickstart Safety Warranty Manual Support For the latest information about this product system requirements compatibility AKAI media 61 ab d0 |||

User Guide English Manual Version 1.0 Table of Contents Click a chapter/section to jump to it. I ... elocities, becoming flatter at high velocities. At the maximum setting of 50, it takes very little **force** to generate a velocity value of 127. Gain: An offset to keyboard's overall velocity sensitivit...

lang:nl **score:30** filesize: 1.86 M page_count: 44 document date: 2019-08-05



[\[pdf\]](#) User Manual Guide

Force User Guide Akai Professional 3 0 6 akaipro amfile file 1122 product 7147


User Guide English Manual Version v3.0.6 Table of Contents Introduction

..... 19 5 Addenda..... 320

Updates in **Force** 3.0.2 320 New

Features.....

lang:en **score:30** filesize: 65.24 M page_count: 369 document date: 2020-10-22



[\[pdf\]](#) User Manual Guide

Force User Guide Akai Professional v3 0 5 akaipro amfile file 1101 product 7147


User Guide English Manual Version v3.0.5 Table of Contents Introduction

..... 15 5 Addenda..... 316

Updates in **Force** 3.0.2 316 New

Features.....

lang:en **score:30** filesize: 65.21 M page_count: 361 document date: 2020-09-11



[\[pdf\]](#) User Manual Specifications Documentation Guide Warranty


MPC Live Quickstart Guide Akai Professional Software Download Card Power Adapter USB Cable Safety

Warranty Manual Important Visit akaipro and find the webpage 232413 d1aeri3ty3izns cloudfront net media 23

Quickstart Guide English 2 6 Gua de inicio rpido Espaol 7 11 Guide d utilisation

Franais ... e pads will always trigger their samples at the maximum velocity 127 , regardless of the amount of **force** you use. Press and hold Shift and then press this button to activate/deactivate Half Level. Wh...

lang:en **score:30** filesize: 4.13 M page_count: 28 document date: 2016-08-23



[\[pdf\]](#) User Manual Guide

Force User Guide Akai Professional Sound Productions 25 août 2020 — UG soundpro content product documents


User Guide English Manual Version v3.0.4 Table of Contents Introduction

..... 259 Addenda 260

Updates in **Force** 3.0.2260 New

Features.....

lang:en **score:30** filesize: 48.14 M page_count: 275 document date: 2019-10-29



[\[pdf\]](#) User Manual Documentation Guide Warranty

MPD218 User Guide Akai Professional 217099 d1aeri3ty3izns cloudfront net media 21 |||

User Guide English 3 5 Gua del usuario Espaol 6 8 Guide d utilisation Franais 9 11

Gu ... ue le mode Full Level est activ, les pads jouent toujours la vlocit maximale 127 , peu importe la **force** laquelle ils sont frapps. 10 8. Note Repeat : Maintenir cette touche tout en frappant un pa...

lang:en **score:30** filesize: 1.25 M page_count: 20 document date: 2016-09-08

