



Manuals.plus /

> Arofa /

> Arofa A03LY Kitchen Sink Faucet Instruction Manual

Arofa A03LY

Arofa A03LY Kitchen Sink Faucet Instruction Manual

Model: A03LY | Brand: Arofa

1. INTRODUCTION

Thank you for choosing the Arofa A03LY Kitchen Sink Faucet. This manual provides detailed instructions for the proper installation, operation, and maintenance of your new faucet. Please read this manual thoroughly before installation and keep it for future reference to ensure optimal performance and longevity of your product.

2. PRODUCT OVERVIEW

The Arofa A03LY Kitchen Sink Faucet is designed for convenience and durability, featuring a pull-down spray wand and a single-handle design for easy control.

Key Features:

- **High Arch 360-Degree Rotatable Spout:** Provides wide range clearance for your sink.
- **Three-Function Sprayer Head:** Offers stream, spray, and pause modes for versatile use.
- **Durable Finish:** Designed to prevent dirt and corrosion from daily use.
- **Solid High-Quality Brass Body:** Ensures robustness and health for everyday use.
- **Single Handle Design:** Easy operation for temperature and volume control.
- **Long-Life Cartridge:** Tested for 500,000 cycles, equivalent to 27 years of typical use.
- **Pull-Down Spray Wand:** Flexible hose extends up to 20 inches for extended reach.
- **Easy Clean Nozzle:** Silicone nozzles allow for easy wiping away of mineral buildup.

Product Dimensions and Components:



Figure 1: Arofa A03LY Faucet with key dimensions.




Figure 2: Exploded view of faucet components and features.

3. SETUP AND INSTALLATION

Follow these steps for a straightforward installation. Ensure all necessary tools are available before beginning.

Installation Steps:



1. Put all hoses of faucet through sink or countertop hole.

2. Screw black nut with rubber gasket and steel gasket in counter-clockwise by hand until faucet does not wobble.

3. Take the black weight ball from box, open in counterclockwise, then clasp it to white label place of the black pull out hose.

4. Connect hot and cold water line hose to valve separately by wrench, but BE SURE DO NOT OVER-TIGHTEN TO DAMAGE INTERNAL PARTS.

Figure 3: Visual guide for faucet installation.

1. **Prepare the Sink Hole:** Ensure the sink or countertop hole is clean and clear.
2. **Insert Faucet:** Pass all hoses of the faucet through the sink or countertop hole.
3. **Secure the Faucet:** From underneath the sink, screw the black nut with the rubber gasket and steel gasket onto the faucet shank. Turn counter-clockwise by hand until the faucet does not wobble.
4. **Install Weight Ball:** Take the black weight ball from the box. Open it counter-clockwise, then clasp it to the white label place on the black pull-out hose. This weight ensures the spray head retracts smoothly.
5. **Connect Water Lines:** Connect the hot and cold water lines to the valve separately using a wrench. **DO NOT OVER-TIGHTEN TO DAMAGE INTERNAL PARTS.**
6. **Test for Leaks:** Turn on the water supply and check all connections for leaks.

4. OPERATING INSTRUCTIONS

Your Arofa A03LY faucet offers intuitive control for water flow and spray patterns.

Handle Operation:

- **Water Flow:** Lift the handle to turn on the water. The higher you lift, the greater the water flow.
- **Temperature Control:** Move the handle to the left for hot water and to the right for cold water.

Sprayer Head Functions:



Figure 4: Sprayer head features and movement.

- **Stream Mode:** Ideal for filling pots or general washing. Press the stream button on the spray head to activate.

SPRAYER OR STREAM MODE

Stream mode perfect for filling or washing.



Figure 5: Faucet in stream mode.

- **Sprayer Mode:** Perfect for rinsing dishes or cleaning the sink. Press the spray button on the spray head to activate.

SPRAYER OR STREAM MODE

Sprayer mode perfect for rinsing.



Figure 6: Faucet in sprayer mode.

- **Pause Function:** Temporarily stops water flow without turning off the main handle. Press the pause button on the spray head.
- **Retraction:** The weighted hose ensures the spray head retracts smoothly back into the spout after use.

5. MAINTENANCE

Regular cleaning and maintenance will keep your Arofa A03LY faucet looking new and functioning properly.

Cleaning the Faucet:

- Use a soft cloth and mild soap to clean the faucet's exterior.
- Avoid abrasive cleaners, steel wool, or harsh chemicals, as these can damage the finish.
- For the easy-clean nozzles, gently rub the silicone nozzles with your finger to remove any mineral buildup.

Cartridge Maintenance:

The ceramic disc cartridge is designed for long-lasting, drip-free performance. If you experience persistent drips or difficulty controlling water temperature/flow, the cartridge may need to be replaced. Contact customer support for assistance.

6. TROUBLESHOOTING

If you encounter any issues with your faucet, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|-----------------------------|--|---|
| Low Water Flow | Aerator clogged with debris; water supply valves not fully open. | Remove and clean the aerator; ensure hot and cold water supply valves are fully open. |
| Leaking from Spout | Worn cartridge; mineral buildup in cartridge. | Replace the ceramic disc cartridge (contact support); clean cartridge if possible. |
| Spray Head Does Not Retract | Weight ball improperly positioned or obstructed; hose kinked. | Check the position of the weight ball and ensure it moves freely; straighten any kinks in the hose. |
| Water Temperature Issues | Hot/cold water supply valves not fully open; faulty cartridge. | Ensure both hot and cold water supply valves are fully open; replace cartridge if issue persists. |

If these solutions do not resolve the issue, please contact Arofa customer support for further assistance.

7. SPECIFICATIONS

| Specification | Detail |
|--------------------|------------------------------|
| Brand | Arofa |
| Model Number | A03LY |
| Material | Stainless Steel |
| Finish Type | Stainless (A-Brush Nickel) |
| Mounting Type | Deck Mount |
| Number of Handles | 1 |
| Hole Count | 3 (with included deck plate) |
| Spout Design | Gooseneck Pull-down |
| Product Dimensions | 15.25"D x 10.4"W x 15.45"H |
| Item Weight | 6.98 pounds |

8. WARRANTY AND SUPPORT

Your Arofa A03LY Kitchen Sink Faucet comes with a limited warranty. For specific warranty details, claims, or technical support, please contact Arofa customer service.

Contact Information:

- **Website:** Visit the official Arofa website for support resources.
- **Email:** Refer to your product packaging or the official website for customer support email.
- **Phone:** Refer to your product packaging or the official website for customer support phone number.

Please have your model number (A03LY) and purchase date available when contacting support.