



Manuals.plus /

› KRGMNHR /

› KRGMNHR Coffee Mug Warmer (Model FF-66-2) Instruction Manual

## KRGMNHR FF-66-2

# KRGMNHR Coffee Mug Warmer (Model FF-66-2) Instruction Manual

Brand: KRGMNHR | Model: FF-66-2

## 1. INTRODUCTION

Thank you for purchasing the KRGMNHR Coffee Mug Warmer. This device is designed to keep your beverages at an optimal warm temperature, ensuring a pleasant drinking experience throughout the day. Please read this manual carefully before use to ensure safe and efficient operation.

## 2. SAFETY INSTRUCTIONS

- **CAUTION: HOT SURFACE.** The heating plate becomes hot during operation. Avoid direct contact with the heating surface to prevent burns.
- Keep the device out of reach of children and pets.
- Use only with appropriate mugs and cups. For best results, use flat-bottomed mugs made of steel, ceramic, or glass. Mugs with deep concave bottoms may not heat effectively.
- Do not immerse the unit, cord, or plug in water or other liquids.
- Despite its waterproof design, avoid intentionally spilling large amounts of liquid onto the heating plate. Wipe up any spills immediately.
- Unplug the unit when not in use or before cleaning.
- Do not operate the device if the cord or plug is damaged, or if the unit malfunctions or has been damaged in any way.

## 3. PACKAGE CONTENTS

- 1 x KRGMNHR Coffee Mug Warmer Unit
- 1 x Power Cord (integrated)
- 1 x Instruction Manual

## 4. PRODUCT FEATURES

- **2-Temperature Settings:** Choose between 104°F (40°C) for a warm beverage or 140°F (60°C) for a hotter drink.
- **4-Hour Auto Shut-off:** For safety and energy saving, the warmer automatically turns off after 4 hours of continuous operation.
- **Suitable for Most Cups:** The flat tempered glass surface accommodates various flat-bottomed cups, including stainless steel, ceramic, and glass mugs.
- **Waterproof Design:** The heating plate is made of tempered glass and aluminum alloy, allowing for easy cleaning of accidental spills.




Image: The KRGMNHR Coffee Mug Warmer keeping various beverages warm.

# Two Temperature Settings


Our coffee Warmer can warm Beverage in high-temp(140°F) and low-temp settings(104°F)



**ON/OFF Button**  
Adjustable temperature



Touch once: High - temp 


Touch twice: low - temp 

Touch 3 times: turn off

Image: Illustration of the two temperature settings (High and Low) and the touch ON/OFF button.

# Auto shutoff-More Safer

Automatic shut off after 4 hours, even if you forget to shut down, there is no safety hazard



Our warmer

VS

Others

Image: Visual representation of the 4-hour auto shut-off safety feature.

## 5. SETUP

1. Place the KRGMNHR Coffee Mug Warmer on a flat, stable, and heat-resistant surface.
2. Ensure the power cord is securely plugged into a standard 120V electrical outlet.
3. The unit is now ready for use.



Image: The KRGMNHR Coffee Mug Warmer unit, ready for placement.

## 6. OPERATING INSTRUCTIONS

---

- 1. Power On/Off:** Gently touch the power button icon on the heating plate to turn the unit on. The indicator light will illuminate. Touch again to cycle through temperature settings or turn off.
- 2. Temperature Selection:**
  - Touch once for High Temperature (Red light): Keeps beverages at approximately 140°F (60°C).
  - Touch twice for Low Temperature (Blue light): Keeps beverages at approximately 104°F (40°C).
  - Touch a third time to turn the unit off.
- 3. Placement of Mug:** Place your flat-bottomed mug containing the beverage directly onto the center of the heating plate. The warmer will begin to heat or maintain the temperature of your drink.
- 4. Auto Shut-off:** The warmer is equipped with a 4-hour auto shut-off feature. If left unattended, the unit will power down automatically after 4 hours.



Image: A mug of coffee being kept warm on the KRGMNHR Coffee Mug Warmer.

Video: Demonstration of the KRGMNHR Coffee Mug Warmer's ease of use and functionality.

## 7. MAINTENANCE AND CLEANING

---

- Always unplug the warmer from the power outlet before cleaning.
- Allow the heating plate to cool completely before touching or cleaning.
- Wipe the heating plate and body with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
- Do not immerse the unit in water.

## 8. TROUBLESHOOTING

---

- **Unit not turning on:** Ensure the power cord is securely plugged into a working outlet. Check if the power button is being pressed correctly.
- **Beverage not heating sufficiently:** Ensure the mug has a flat bottom and is making full contact with the heating plate. Thicker mugs or mugs with concave bottoms may reduce heating efficiency. Ensure the correct temperature setting (red for high, blue for low) is selected.

- **Unit automatically turns off:** This is likely due to the 4-hour auto shut-off feature. Simply turn the unit back on if you wish to continue use.

## 9. SPECIFICATIONS

Specification	Value
Brand	KRGMNHR
Model Number	FF-66-2
Voltage	120 Volts
Wattage	18 watts
Maximum Temperature	140°F (60°C)
Low Temperature	104°F (40°C)
Auto Shut-off	4 Hours
Material	Aluminum, Tempered Glass
Item Weight	9.6 ounces
Package Dimensions	6.46 x 5.08 x 1.34 inches

## 10. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the product packaging or contact KRGMNHR customer service directly. Keep your purchase receipt for any warranty claims.