

GreatPowerDirect GPD090117-28720

GreatPowerDirect AC Adapter and PC Cord Cable User Manual

For Insignia NS-P11W7100 Tablet PC 11.6"

1. INTRODUCTION

This manual provides essential instructions for the safe and effective use of your GreatPowerDirect AC Adapter and PC Cord Cable, designed for the Insignia NS-P11W7100 Tablet PC 11.6". Please read this manual thoroughly before use and retain it for future reference.

2. PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x AC Power Adapter
- 1 x USB to Micro USB Cable



Figure 1: The GreatPowerDirect AC Adapter and accompanying USB to Micro USB Cable. The adapter is a black rectangular block with two flat prongs for wall outlets, and the cable is black with a standard USB-A connector on one end and a Micro USB connector on the other.

3. SETUP INSTRUCTIONS

Follow these steps to set up your AC adapter and cable for charging:

1. **Connect the USB Cable to the AC Adapter:** Insert the standard USB-A end of the cable into the USB port on the AC power adapter. Ensure it is firmly seated.



Figure 2: The black GreatPowerDirect AC Adapter, showing the two flat prongs for power outlets and the USB port for cable connection.

2. **Connect the Micro USB End to Your Tablet:** Insert the Micro USB end of the cable into the charging port of

your Insignia NS-P11W7100 Tablet PC. The charging port is typically located on the side or bottom edge of the tablet.



Figure 3: The black USB to Micro USB Cable. One end features a standard USB-A connector, and the other end has a Micro USB connector, used for connecting to the tablet.

3. **Plug the AC Adapter into a Power Outlet:** Insert the prongs of the AC power adapter into a standard wall power outlet.

Important Safety Note:

- Only use the adapter and cable in dry indoor environments.
- Do not expose to water or excessive moisture.
- Ensure the power outlet is easily accessible.

4. OPERATING INSTRUCTIONS

Once connected as described in the Setup section, your tablet should begin charging automatically. A charging indicator (usually an icon on the screen or an LED light) on your tablet will confirm that it is receiving power.

- **Charging Time:** Charging time may vary depending on the tablet's battery level and usage during charging.
- **Disconnecting:** To disconnect, first unplug the AC adapter from the wall outlet, then remove the Micro USB cable from your tablet, and finally, disconnect the USB cable from the adapter.

5. MAINTENANCE AND CARE

Proper care will extend the life of your AC adapter and cable:

- **Cleaning:** Disconnect from power before cleaning. Use a soft, dry cloth to wipe the adapter and cable. Do not use liquid cleaners or aerosols.
- **Storage:** Store the adapter and cable in a cool, dry place when not in use. Avoid tightly coiling the cable to prevent damage.
- **Handling:** Do not pull the cable by the cord itself; always grasp the plug when disconnecting. Avoid placing heavy objects on the cable.

6. TROUBLESHOOTING

If you encounter issues, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Tablet is not charging.	<ul style="list-style-type: none">◦ Loose connection.◦ Faulty power outlet.◦ Damaged cable or adapter.	<ul style="list-style-type: none">◦ Ensure all connections are secure.◦ Try a different power outlet.◦ Inspect the cable and adapter for visible damage. If damaged, discontinue use and replace.
Slow charging.	<ul style="list-style-type: none">◦ Tablet in heavy use during charging.◦ Background applications consuming power.	<ul style="list-style-type: none">◦ Close unnecessary applications.◦ Avoid using the tablet for demanding tasks while charging.

7. SPECIFICATIONS

Feature	Detail
Brand	GreatPowerDirect
Model Number	GPD090117-28720
Compatible Devices	Insignia NS-P11W7100 Tablet PC 11.6"
Connector Type	USB (Type-A to Micro USB)
Power Source	Corded Electric
Material	Plastic
Color	Black
Item Weight	6 ounces
Certifications	CE

8. WARRANTY INFORMATION

This product is covered by a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the documentation provided with your purchase or contact GreatPowerDirect customer support. Keep your proof of purchase for warranty claims.

9. CUSTOMER SUPPORT

For further assistance, technical support, or inquiries regarding your GreatPowerDirect AC Adapter and PC Cord Cable, please contact your retailer or visit the GreatPowerDirect official website for contact information.



Documents - GreatPowerDirect – GPD090117-28720

no relevant documents