

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Valberg](#) /
- › [Valberg FRS-32 KL Fire Resistant Safe User Manual](#)

Valberg FRS-32 KL

Valberg FRS-32 KL Fire Resistant Safe User Manual

Model: FRS-32 KL | Brand: Valberg

PRODUCT OVERVIEW

The Valberg FRS-32 KL is a compact, fire-resistant safe designed for secure storage of valuable documents and items. It features a robust metal construction and is equipped with two key locks for enhanced security. Its fireproof capabilities provide protection against high temperatures, making it suitable for safeguarding important papers and digital media.



Image: Valberg FRS-32 KL Fire Resistant Safe with its door open, revealing the interior storage space and the dual key lock mechanism on the door. The safe is designed to protect contents from fire.

Key features include a 21-liter capacity, a weight of 38 kg, and internal dimensions suitable for various items. The safe also includes one removable tray for organized storage. Anchoring points are available for securing the safe to the floor, providing additional theft deterrence.

SETUP INSTRUCTIONS

1. **Unpacking:** Carefully remove the safe from its packaging. Inspect for any signs of damage during transit. Retain packaging materials for potential future transport or returns.

2. **Placement:** Choose a suitable location for the safe. Consider a discreet, secure, and stable area. Ensure the surface can support the safe's weight (38 kg) and its contents.
3. **Anchoring (Optional but Recommended):** The Valberg FRS-32 KL safe is designed with anchoring points for securing it to the floor.
 - Locate the pre-drilled holes at the bottom of the safe.
 - Mark the drilling points on the floor through these holes.
 - Drill appropriate holes in the floor using a suitable drill bit for your floor type.
 - Secure the safe using appropriate anchor bolts (not included) through the safe's base into the floor. Ensure the safe is firmly attached.
4. **Initial Key Operation:** The safe comes with two sets of keys for its dual key locks. Insert one key into each lock and turn to the open position. The door should now open.
5. **Interior Setup:** Place the removable tray inside the safe as desired for organizing your items.

OPERATING INSTRUCTIONS

Opening the Safe

1. Ensure the safe door is closed and the locks are engaged.
2. Insert the first key into the upper keyhole. Turn the key clockwise until it stops.
3. Insert the second key into the lower keyhole. Turn the key clockwise until it stops.
4. Gently pull the door open.

Closing and Locking the Safe

1. Push the safe door firmly shut until it is flush with the safe body.
2. Turn both keys counter-clockwise until they stop, ensuring the locking bolts are fully extended.
3. Remove both keys. Store them in a secure location away from the safe.

Key Management

It is crucial to manage your keys responsibly. Keep one set of keys in a secure, separate location as a backup. Avoid storing keys inside the safe itself. Do not duplicate keys unless absolutely necessary, and only through authorized locksmiths.

MAINTENANCE

- **Cleaning:** Wipe the exterior of the safe with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish. For the interior, a dry cloth is usually sufficient.
- **Key Care:** Keep keys clean and free from debris. Do not force keys if they feel stiff; a small amount of graphite lubricant (not oil-based) can be applied to the keyhole if necessary, but consult a professional if issues persist.
- **Door Hinge and Bolt Inspection:** Periodically check the door hinges and locking bolts for any signs of wear or obstruction. Ensure they move smoothly. Do not attempt to lubricate fire-resistant door seals, as this may compromise their integrity.
- **Fire Seal Integrity:** The fire-resistant seal around the door is critical for its fire protection. Do not paint, scratch, or damage this seal. Ensure it remains clean and intact.

TROUBLESHOOTING

• **Keys are difficult to turn:**

Ensure the keys are fully inserted. Check for any debris in the keyhole. If the issue persists, a professional locksmith may be required. Do not force the key, as this can damage the lock.

• **Door does not open after unlocking:**

Ensure both keys have been turned fully to the open position. Gently pull the door. If the safe is anchored, ensure there is no obstruction around the door frame.

• **Door does not close or lock properly:**

Check for any items obstructing the door or the locking bolts. Ensure the safe is on a level surface. Verify that the locking bolts retract and extend smoothly when the keys are turned.

SPECIFICATIONS

Feature	Detail
Brand	Valberg
Model	FRS-32 KL
Type	Fire Resistant Safe
Locking Mechanism	2 Key Locks
External Dimensions (H x W x D)	315 x 445 x 425 mm
Internal Dimensions (H x W x D)	207 x 341 x 296 mm
Capacity	21 Liters
Weight	38 kg
Material	Metal
Special Features	Fireproof, Anchoring to floor available, 1 Removable Tray
ASIN	B07MWYZLB7
Date First Available	24 January 2019







WARRANTY AND SUPPORT

For specific warranty terms and conditions, please refer to the documentation provided at the time of purchase or contact your retailer. Warranty coverage typically varies by region and distributor.

Should you require technical assistance, spare parts, or have questions not covered in this manual, please contact Valberg customer support or your authorized dealer. Have your product model (FRS-32 KL) and ASIN (B07MWYZLB7) ready when contacting support to expedite assistance.

Note: Unauthorized modifications or repairs to the safe may void the warranty and compromise its security and fire-resistant properties.

Related Documents - FRS-32 KL

	<p>Consignes de sécurité et garantie aspirateur Valberg C3</p> <p>Guide complet des consignes de sécurité et des conditions de garantie pour l'aspirateur Valberg C3. Assurez une utilisation sûre et prolongée de votre appareil.</p>
	<p>Valberg Electric Heater User Manual and Specifications</p> <p>Comprehensive user manual and technical specifications for Valberg electric heaters, models 10008792, 10008793, and 10008794, including installation, operation, and maintenance instructions.</p>
	<p>Valberg Floorwasher FL5 V2: Regulatory and Safety Instructions</p> <p>This document provides essential regulatory and safety instructions for the Valberg Floorwasher FL5 V2. It covers safe operation, handling, maintenance, and disposal guidelines to ensure user safety and product longevity. The information is presented in multiple languages for broad accessibility.</p>
	<p>Valberg WF814A-10W180C Washing Machine Exploded Parts Diagram and Guide</p> <p>Detailed exploded view diagrams and part listings for the Valberg WF814A-10W180C washing machine, covering all major components for identification and service.</p>
	<p>Valberg VALFM65PBMSC Oven Spare Parts Diagram</p> <p>Exploded view diagram and parts list for the Valberg VALFM65PBMSC oven, detailing all components for maintenance and repair. Includes part numbers and assembly descriptions.</p>
	<p>Aspirateurs Balais et à Main - Instructions Réglementaires et de Sécurité</p> <p>Instructions réglementaires et de sécurité complètes pour les aspirateurs balais et à main Valberg. Ce guide couvre l'utilisation sûre, l'entretien, la manipulation des batteries et les directives de mise au rebut. Essentiel pour une utilisation correcte et sécurisée de votre appareil Valberg.</p>



[\[pdf\]](#)

Прайс каталог ПРОМЕТ сейфы 27 02 2014 R1 2 xls Admin prom st Темпокасы VALBERG

НОВИНКА!!! FRS 32 В ес 51 67 75 Предназначены для сохранности документов и promet sejfy 14 storage ua 272098 |||

S C , A D : : : : FRS 20 ; - : : KL - ; EL - ; H - . .

CH 5 . . . - , . **FRS-32 KL** FRS-49 L FRS-51 L FRS-67 , , * FRS-75 L FRS-120 L FRS-30 FRS-32 FR...

lang:i-klingson score:18 filesize: 1.16 M page_count: 26 document date: 2014-03-04