

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Pets Alive](#) /

› [Pets Alive My Magical Unicorn and Stable Instruction Manual Model 9502A](#)

Pets Alive 9502A

Pets Alive My Magical Unicorn and Stable Instruction Manual

Model: 9502A | Brand: Pets Alive by ZURU

1. INTRODUCTION

This manual provides instructions for the safe and proper use of your Pets Alive My Magical Unicorn and Stable. This interactive robotic toy offers over 20 different ways to interact, including lights, sounds, and movements. Please read this manual thoroughly before use and retain it for future reference.



Image: The pink Pets Alive My Magical Unicorn, featuring a blue bow, a star-themed necklace, and a light-up horn.

2. SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small Parts. Not for children under 3 years.

- Always supervise children during play.
- Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Remove batteries if the toy is not used for an extended period to prevent leakage.
- Dispose of used batteries responsibly.
- Keep the toy away from water and excessive moisture.
- Do not attempt to disassemble or modify the toy.

3. PACKAGE CONTENTS

Verify that all items listed below are present in your package:

- 1 x My Magical Unicorn (Pink)
- 1 x Stable Playset
- Batteries (3 x AA batteries, included)



Image: The retail packaging for the Pets Alive My Magical Unicorn, displaying the pink unicorn and its stable.

4. SETUP

4.1 Battery Installation

1. Locate the battery compartment on the underside of the unicorn.
2. Using a small Phillips head screwdriver, open the battery compartment cover.
3. Insert 3 x AA batteries, ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.
5. Locate the ON/OFF switch, usually on the unicorn's belly or side, and switch it to the "ON" position.

4.2 Stable Assembly

The stable playset typically requires minimal assembly. Follow any visual guides on the packaging or included quick-start sheet to connect the stable pieces securely.

5. OPERATING INSTRUCTIONS

Your My Magical Unicorn offers over 20 interactive features. Here are some key ways to interact:

5.1 Voice Recording and Repeat

To make your unicorn repeat what you say:

- Locate the star button on the unicorn's leg.
- Press and hold the star button.
- Speak a sentence clearly into the unicorn's microphone (located near its mouth).
- Release the star button. The unicorn will repeat your recorded message.



Image: A child interacting with the pink unicorn, demonstrating the voice recording feature by pressing the star on its leg.

5.2 Feeding Interaction

Use the included carrot accessory to feed your unicorn:

- Bring the carrot close to the unicorn's mouth.
- The unicorn will make eating sounds and movements.
- If fed too much, the unicorn may make a "neigh" sound.



Image: A child feeding the purple unicorn with its carrot accessory, illustrating the feeding interaction.

5.3 Kiss Interaction

Blow a kiss to your unicorn, and it will kiss you back:

- Lean in and blow a gentle kiss towards the unicorn's nose.
- The unicorn will respond with a kissing sound and movement.



Image: A child blowing a kiss to the white unicorn, which will respond with a kiss back.

5.4 Nose Touch and Horn Lights

Touching the unicorn's nose activates sounds and lights:

- Gently touch the unicorn's nose.
- It will neigh and make magical unicorn sounds.
- The unicorn's horn will light up during these interactions.



Image: A hand touching the white unicorn's nose, activating its light-up horn and sounds.

5.5 Brushing and Petting

The unicorn reacts to touch and can be styled:

- Gently brush the unicorn's mane and tail (brush not included, but implied by image).
- Petting the unicorn may elicit various sounds and movements.



Image: A hand brushing the mane of a purple unicorn, demonstrating hair styling interaction.

5.6 Music and Sounds

The unicorn plays music and makes various magical sounds during interaction.



Image: The pink unicorn with musical notes, illustrating its ability to play music and sounds.

5.7 Sleep Mode

After a period of inactivity, the unicorn may enter a sleep mode, indicated by soft snoring sounds and closed eyes. To wake it up, interact with it again (e.g., touch its nose, press the star button).

5.8 Official Product Video

Your browser does not support the video tag.

Video: An official product video from ZURU LLC demonstrating various interactive features of the Pets Alive My Magical Unicorn, including feeding, kissing, voice repeat, and horn lights.

6. MAINTENANCE

6.1 Cleaning

To clean your unicorn, gently wipe it with a damp cloth. Do not immerse the toy in water. Avoid using harsh chemicals or abrasive cleaners.

6.2 Storage

When not in use, store the unicorn and stable in a clean, dry place, away from direct sunlight and extreme temperatures. Remove batteries if storing for an extended period.

7. TROUBLESHOOTING

- **Unicorn not responding:**
 - Ensure the ON/OFF switch is in the "ON" position.
 - Check if the batteries are correctly installed and not depleted. Replace with fresh AA batteries if necessary.
- **Sounds or lights not working:**
 - Verify battery status.
 - Ensure interactions (e.g., touching nose, pressing star) are performed correctly.
- **Voice repeat function unclear:**
 - Speak clearly and close to the unicorn's mouth.
 - Ensure there is no excessive background noise during recording.

8. SPECIFICATIONS

Feature	Detail
Model Number	9502A
Product Dimensions	9.06 x 6.5 x 12.4 inches
Item Weight	1.32 pounds
Manufacturer Recommended Age	36 months - 10 years

Batteries Required	3 x AA batteries (included)
Manufacturer	ZURU

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official ZURU website. Keep your purchase receipt as proof of purchase.



© 2024 Pets Alive. All rights reserved.