

LOZ 1607

LOZ Mini Block Street Mini Series Fast Food Burger Building Set - Model 1607

Instruction Manual

1. INTRODUCTION

This instruction manual provides detailed guidance for assembling and understanding your LOZ Mini Block Street Mini Series Fast Food Burger Building Set, Model 1607. This set is designed to create a miniature fast-food burger restaurant model using 333 high-quality plastic building blocks. It offers an engaging and rewarding construction experience, suitable for display.

2. SAFETY INFORMATION

Important Warning: This product contains small parts. These parts may pose a choking hazard to young children. It is not suitable for children under 3 years of age.

- Always ensure adult supervision during assembly and play, especially with younger children (recommended age 6+).
- Keep all small parts away from infants and toddlers.
- Do not ingest any parts of the building set.
- The plastic materials used are non-toxic.

3. PACKAGE CONTENTS

Before beginning assembly, please verify that all components are present in your package. The LOZ Mini Block Street Mini Series Fast Food Burger Building Set (Model 1607) includes:

- 333 assorted plastic building blocks.
- One instruction manual with step-by-step assembly diagrams.



Image 3.1: The product packaging for the LOZ Mini Block Street Mini Series Fast Food Burger Building Set, Model 1607.




Image 3.2: A collection of assorted LOZ Mini Block pieces included in the set.

4. SETUP AND ASSEMBLY

Assembly of the LOZ Mini Block Fast Food Burger set requires careful attention to detail and following the provided step-by-step instructions. No special tools are required.

4.1 Preparation

- Unpack all building blocks and the instruction manual from the box.
- Sort the blocks by color or shape to facilitate easier assembly.
- Ensure you have a clean, flat, and well-lit surface for construction.

4.2 Assembly Steps

1. Refer to the included instruction manual for detailed diagrams and piece counts for each step.
2. Begin by identifying the base plate and the initial pieces as shown in the first step of the manual.

3. Carefully connect the blocks, ensuring they fit snugly. The smooth surfaces of the blocks are designed for precise interlocking.
4. Proceed through each step sequentially, paying close attention to the orientation and placement of each block.
5. If a block does not fit easily, do not force it. Recheck the instructions to ensure correct piece selection and orientation.
6. The assembly process builds the structure layer by layer, forming the fast-food restaurant.



Image 4.1: A detailed view of the assembled Fast Food Burger restaurant, showing its dimensions.



Image 4.2: An aerial view showcasing the interior layout of the Fast Food Burger restaurant model.

5. OPERATING AND DISPLAY

Once assembled, the LOZ Mini Block Fast Food Burger set is primarily intended for display. While it can withstand gentle handling, it is not designed for rough play.

- Place the completed model on a stable, flat surface to prevent accidental falls.
- The model can be gently moved for repositioning or viewing from different angles.
- Avoid applying excessive force or dropping the model, as this may cause parts to detach.

6. MAINTENANCE

To ensure the longevity and appearance of your LOZ Mini Block set, follow these simple maintenance guidelines:

- **Cleaning:** Dust the model regularly with a soft, dry cloth or a soft brush. For more thorough cleaning, gently wipe with a slightly damp cloth and then dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** If disassembling for storage, keep all pieces in a sealed container to prevent loss and protect them from dust and damage. Store in a cool, dry place away from direct sunlight to prevent material degradation or color fading.
- **Part Replacement:** In case of lost or damaged parts, contact the retailer or manufacturer for potential replacement options.

7. TROUBLESHOOTING

This section addresses common issues you might encounter during assembly or use.

Problem	Possible Cause	Solution
Blocks do not fit together easily.	Incorrect block orientation or selection.	Recheck the instruction manual for the correct piece and its orientation. Ensure the blocks are aligned properly before pressing them together.
Missing pieces.	Pieces may have been overlooked during unpacking or lost.	Carefully check the packaging and surrounding area. If still missing, contact customer support.
Assembled model is unstable.	Blocks not fully pressed together or incorrect assembly step.	Review previous assembly steps to ensure all blocks are securely connected. Press down firmly on each layer.

8. SPECIFICATIONS

Feature	Detail
Brand	LOZ
Model Number	1607
Number of Pieces	333
Material	High-Quality Plastic
Product Dimensions (L x W x H)	50 x 196 x 164 mm (approx. 5 x 19.6 x 16.4 cm)
Product Weight	200 grams
Recommended Age	6 years and up (Manufacturer recommended age: 3 years and up)
Batteries Required	No
Special Feature	Non-toxic materials
Theme	Fast Food / Street Mini Series
ASIN	B07MXH445X
Date First Available	January 24, 2019

9. WARRANTY AND SUPPORT

Specific warranty information for this LOZ Mini Block set is not provided in the product details. For any inquiries regarding product defects, missing parts, or general support, please contact the retailer from whom the product was purchased. They will be able to assist you with their return and support policies.