

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [LUTEC](#) /

› [Lutec Alice LED Outdoor Wall Light with House Number IP44 800lm Anthracite - Instruction Manual](#)

LUTEC 5194301118

Lutec Alice LED Outdoor Wall Light with House Number

Model: 5194301118 | Brand: LUTEC

INTRODUCTION

Thank you for choosing the Lutec Alice LED Outdoor Wall Light. This modern and energy-efficient luminaire is designed to provide reliable illumination for your home's exterior, featuring integrated house number functionality. This manual provides essential information for safe installation, operation, and maintenance of your new light fixture.



Image: The Lutec Alice LED Outdoor Wall Light, showcasing its sleek design and how it appears when mounted on an exterior wall.

SAFETY INFORMATION

Please read all safety instructions carefully before installation and use. Failure to follow these instructions may result in electric shock, fire, or other injuries.

- Always disconnect power at the circuit breaker before installing, servicing, or cleaning the fixture.
- Installation must be performed by a qualified electrician in accordance with all local and national electrical codes.
- Do not connect this fixture to an ungrounded electrical system.
- Ensure all connections are secure and properly insulated.
- Do not exceed the specified voltage and wattage ratings.
- This product is designed for outdoor use and is rated IP44 for protection against splashing water.

Suitable for **Wet Location**



Image: The light fixture shown enduring rainfall, highlighting its suitability for wet outdoor locations and its IP44 rating.

PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Light fixture (Leuchte)
- House number set (Hausnummern-Set)
- Mounting hardware (screws, wall anchors)
- Instruction manual (this document)

Note: 3 x E12 bulbs are **NOT** included and must be purchased separately.

Suitable for **Wet Location**



Image: A view of the light fixture's interior, indicating the type of bulbs required (E12) and clarifying that they are not supplied with the product.

SPECIFICATIONS

Feature	Detail
Model Number	5194301118
Brand	LUTEC
Dimensions (L x W x H)	21 x 21 x 3.5 cm
Weight	750 Grams
Material	Stainless Steel

Feature	Detail
Color	Silver (Anthracite finish)
Protection Class	IP44
Light Output	800lm (lumens)
Bulb Type	E12 (3 bulbs, not included)
Assembly Required	Yes



Image: A detailed view emphasizing the light's construction materials, specifically aluminum and glass, which contribute to its durability and aesthetic.

SETUP AND INSTALLATION

Follow these steps for safe and proper installation of your Lutec Alice LED Outdoor Wall Light:

1. Preparation:

- Turn off power at the main circuit breaker to the location where the fixture will be installed.
- Unpack all components and inspect for any damage.
- Gather necessary tools: screwdriver, wire strippers, drill, level, pencil.

2. Mounting the Fixture:

- Mark the desired mounting location on the wall.
- Attach the mounting bracket to the wall using appropriate screws and wall anchors. Ensure it is level and secure.
- Carefully pull the electrical wires through the center hole of the mounting bracket.

3. Electrical Connection:

- Connect the fixture's wires to your household electrical wires:
 - Connect the **black** (live) wire from the fixture to the **black** (live) wire from the wall.
 - Connect the **white** (neutral) wire from the fixture to the **white** (neutral) wire from the wall.
 - Connect the **green** or **bare copper** (ground) wire from the fixture to the **green** or **bare copper** (ground) wire from the wall.
- Secure connections with wire nuts and wrap with electrical tape for added insulation.
- Carefully tuck all wires into the junction box.

4. Securing the Fixture:

- Align the fixture with the mounting bracket and secure it with the provided screws.
- Ensure the fixture is flush against the wall to prevent water ingress.

5. Installing Bulbs:

- Insert three E12 base LED bulbs (not included) into the sockets. Do not overtighten.

6. Applying House Numbers:

- The house number set includes adhesive numbers. Clean the designated area on the fixture's surface.
- Carefully peel and apply the numbers to create your house address. Ensure they are straight and well-adhered.

7. Final Step:

- Restore power at the circuit breaker and test the light fixture.

OPERATION

The Lutec Alice LED Outdoor Wall Light operates like a standard outdoor light fixture. Once installed and powered, it will illuminate according to the control mechanism connected to its circuit (e.g., a wall switch, photocell, or timer).

- **Manual Operation:** Use a standard wall switch to turn the light on or off.
- **Automated Operation:** If connected to a photocell (dusk-to-dawn sensor) or timer (not included), the light will automatically turn on and off based on ambient light levels or programmed schedules.



Image: The light fixture shown at night, fully illuminated, demonstrating its "charming light" effect and functionality.

MAINTENANCE

Regular maintenance will ensure the longevity and optimal performance of your light fixture.

- **Cleaning:**

- Before cleaning, ensure the power to the fixture is turned off at the circuit breaker.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish or glass.
- For the glass panels, a mild glass cleaner can be used, applied to the cloth first, not directly to the fixture.

- **Bulb Replacement:**

- Ensure power is off before replacing bulbs.
- Allow bulbs to cool completely before handling.

- Replace with E12 base LED bulbs of appropriate wattage.

- **Inspection:**

- Periodically inspect the fixture for any signs of wear, damage, or loose connections. Address any issues promptly.



Image: A detailed shot of the light fixture's seeded glass, illustrating the texture that contributes to its aesthetic and light diffusion.

TROUBLESHOOTING

If you encounter issues with your Lutec Alice LED Outdoor Wall Light, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture, loose wiring, faulty bulb, tripped circuit breaker.	Check circuit breaker. Ensure all wire connections are secure. Replace bulbs. Test power at the fixture with a voltage tester.
Light flickers.	Loose bulb, incompatible dimmer switch (if applicable), unstable power supply.	Tighten bulbs. Ensure dimmer switch is compatible with LED bulbs. Consult an electrician if power supply is suspected.
Light turns on/off randomly.	Faulty photocell or timer (if installed), external light interference.	Check for obstructions blocking the photocell. Test or replace the photocell/timer.
House numbers not adhering.	Surface not clean or dry, numbers applied incorrectly.	Clean and dry the surface thoroughly before application. Apply firm, even pressure.

WARRANTY

The Lutec Alice LED Outdoor Wall Light is covered by a **5-year warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from improper installation, misuse, abuse, accidents, or unauthorized repairs.

For warranty claims, please retain your proof of purchase and contact Lutec customer support.

SUPPORT

For further assistance, technical support, or inquiries regarding your Lutec Alice LED Outdoor Wall Light, please visit the official LUTEC website or contact their customer service department.

You can also find more information and products from LUTEC on their Amazon store page [LUTEC Amazon Store](#).





Image: A wide shot showcasing various outdoor lighting products from LUTEC, emphasizing their range and design philosophy.

Related Documents - 5194301118

	<p>LUTEC Doblo Outdoor Wall Luminaire - User Manual & Specifications</p> <p>Comprehensive user manual and technical specifications for the LUTEC Doblo outdoor wall luminaire (models 5105001125, 5105002125), including safety instructions, warranty information, and installation guide.</p>
	<p>LUTEC 7632802053/7632802012 Wet Location Installation Guide</p> <p>This document provides installation instructions for the LUTEC 7632802053/7632802012 wet location light fixture. It includes safety warnings and step-by-step assembly guidance.</p>
	<p>LUTEC P6221B/P6221W LED Floodlight Owners Manual and Installation Guide</p> <p>Comprehensive owners manual for LUTEC P6221B and P6221W LED Floodlights. Includes safety warnings, installation steps, troubleshooting, and 3-year limited warranty information.</p>
	<p>LUTEC ST5109T Outdoor Wall Light Installation Guide</p> <p>Step-by-step installation instructions for the LUTEC ST5109T outdoor wall light. Includes wiring, mounting, and safety information. Features CE, IP44 rating, and GU10 bulb compatibility.</p>
	<p>LUTEC Flair Outdoor Wall Light User Manual and Installation Guide</p> <p>Comprehensive user manual and installation guide for the LUTEC Flair outdoor wall light (model 5288802012). Features technical specifications, safety guidelines, installation steps, sensor functionality, and warranty information.</p>

