

[Manuals.plus](#) /

› [Brightech](#) /

› Brightech Artichoke Design 68-Inch Tall LED Floor Lamp User Manual

Brightech Y6-C7HP-D5UM

Brightech Artichoke Design 68-Inch Tall LED Floor Lamp User Manual

Model: Y6-C7HP-D5UM

[Introduction](#) [What's in the Box](#) [Assembly Instructions](#) [Operating Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

INTRODUCTION

This manual provides comprehensive instructions for the safe and efficient use of your Brightech Artichoke Design 68-Inch Tall LED Floor Lamp. This lamp features a unique multi-panel wooden shade and is designed to provide warm, inviting illumination. It is equipped with a long-lasting, energy-saving LED bulb and includes a convenient on/off pedal switch. The lamp is also compatible with smart home devices when used with a suitable smart outlet (sold separately).



Figure 1: Fully assembled Brightech Artichoke Design LED Floor Lamp.

WHAT'S IN THE BOX

Please ensure all components are present before beginning assembly. If any parts are missing or damaged, contact Brightech customer support.

- Lamp Pole Sections
- Weighted Base
- Artichoke Shade Panels (multiple pieces)
- Shade Frame/Supports
- LED Bulb (10W, 1100 lumens, 2700K warm white)
- Power Cord with On/Off Pedal Switch
- Assembly Instructions (this manual)

ASSEMBLY INSTRUCTIONS

Assembly of the Brightech Artichoke Floor Lamp requires careful attention, particularly for the shade components. It is recommended to assemble the lamp on a soft, clean surface to prevent scratches.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out and identify each piece.

2. **Assemble the Lamp Pole:**

- Attach the bottom pole section to the weighted base by screwing it clockwise until secure.
- Connect the remaining pole sections, screwing them together firmly. Ensure the power cord passes through the pole sections without twisting.
- The top pole section will have the lamp socket attached.

3. **Assemble the Artichoke Shade:** This step requires patience. The shade consists of multiple wooden panels that interlock.

- Identify the central rings or supports for the shade.
- Carefully insert the individual wooden panels into the designated slots on the shade frame. The panels are designed to fit snugly. Apply gentle, even pressure to avoid damaging the wood.
- Work systematically, layer by layer, ensuring each panel is fully seated. Some force and wiggling may be required to interlock the pieces completely.
- Once all panels are assembled, the shade should form a stable, artichoke-like structure.



Figure 2: Detailed view of the multi-panel wooden shade.

4. **Attach the Shade to the Lamp Pole:** Carefully place the assembled shade onto the lamp socket assembly at the top of the pole. Secure it according to the specific design (e.g., with a retaining ring or by screwing it onto the socket).
5. **Install the LED Bulb:** Screw the provided LED bulb into the lamp socket. Do not overtighten.
6. **Position the Lamp:** Place the lamp in your desired location. Ensure the power cord is not pinched or a tripping hazard.

OPERATING INSTRUCTIONS

The Brightech Artichoke Floor Lamp is designed for simple operation.

1. **Power Connection:** Plug the lamp's power cord into a standard 110V electrical outlet.
2. **Turning On/Off:** Use the integrated pedal switch on the power cord to turn the lamp on or off. Press the pedal once to turn it on, and press it again to turn it off.
3. **Smart Home Compatibility:** This lamp can be integrated with smart home systems (e.g., Amazon Alexa, Google Home Assistant, Apple HomeKit) by connecting it to a compatible smart outlet (sold separately). Follow the instructions provided with your smart outlet for setup. Note that the included bulb is not dimmable, but it can be

replaced with a dimmable smart bulb if desired.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your lamp.

- **Cleaning:**
 - Ensure the lamp is unplugged before cleaning.
 - Wipe the lamp pole and base with a soft, dry cloth.
 - For the wooden shade panels, use a soft, slightly damp cloth to gently wipe away dust. Avoid abrasive cleaners or excessive moisture, which can damage the wood finish.
- **Bulb Replacement:**
 - Always unplug the lamp and allow the bulb to cool completely before attempting to replace it.
 - Unscrew the old bulb counter-clockwise.
 - Screw in a new E26 base LED bulb. The lamp is designed for a 10W LED bulb, but compatible LED bulbs with similar specifications can be used.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	Lamp is unplugged. Bulb is loose or faulty. Power outlet is not functioning.	Ensure the power cord is securely plugged into a working outlet. Tighten the bulb or replace it with a new one. Test the outlet with another appliance.
Light flickers.	Bulb is loose or incompatible. Loose connection in the lamp.	Tighten the bulb. If flickering persists, try a different compatible LED bulb. Unplug the lamp and check all connections, if accessible. If the issue persists, contact customer support.
Shade panels are loose.	Panels not fully seated during assembly.	Gently re-seat the loose panels into their slots, applying firm but even pressure until they interlock securely.

SPECIFICATIONS

- **Model Number:** Y6-C7HP-D5UM
- **Brand:** Brightech
- **Product Dimensions:** 16"D x 16"W x 66"H
- **Item Weight:** 12.5 Pounds
- **Material Type:** Wood (Shade), Metal (Pole), Wood (Base)
- **Finish Type:** Painted
- **Light Source Type:** LED
- **Wattage:** 10W
- **Lumen Output:** 1100 lumens
- **Color Temperature:** 2700K (Warm White)

- **Bulb Base:** E26
- **Voltage:** 110 Volts
- **Switch Type:** Pedal Switch
- **Control Method:** App, Voice (via compatible smart outlet)
- **Indoor/Outdoor Usage:** Indoor Only




Figure 3: Product dimensions.

WARRANTY & SUPPORT

Brightech USA offers an industry-leading **3-year warranty** covering defects, malfunctions, or sudden failures to your standing lamp when purchased through authorized channels. For warranty claims or technical support, please contact Brightech USA's customer service team. You can find more information and contact details on the official Brightech website or through their Amazon store: [Brightech Amazon Store](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question