

[manuals.plus](#) /

› [SVAKOM](#) /

› [Svakom Tammy Double Ring Couples Cock Ring User Manual](#)

SVAKOM 3133385

SVAKOM Tammy Double Ring Couples Cock Ring User Manual

Brand: SVAKOM | Model: 3133385

1. INTRODUCTION AND OVERVIEW

Thank you for choosing the SVAKOM Tammy Double Ring Couples Cock Ring. This device is designed to enhance intimate experiences for couples. Crafted from body-safe silicone, it features a unique double-ring design and provides powerful vibrations. Please read this manual thoroughly before first use to ensure proper operation, maintenance, and safety.



Figure 1: Front view of the SVAKOM Tammy Double Ring Couples Cock Ring, showcasing its ergonomic design and control button.

2. PRODUCT FEATURES

- **Double Ring Design:** Ergonomically shaped for comfortable and secure fit for both partners.
- **Powerful Vibrations:** Equipped with a motor to provide stimulating vibrations.
- **Body-Safe Silicone:** Made from high-quality, soft, and flexible silicone material.
- **Waterproof:** Designed with a waterproof rating for easy cleaning and versatile use.
- **Rechargeable:** Features a built-in Lithium Polymer battery for convenient charging.



Figure 2: Back view of the device, highlighting the textured surface for enhanced sensation.

3. SETUP

3.1 Initial Charging

Before first use, fully charge the device. Locate the charging port, typically a small magnetic or covered port on the device. Connect the provided USB charging cable to the device and a USB power source (e.g., computer USB port, wall adapter). The indicator light will typically show charging status (e.g., blinking while charging, solid when fully charged). A full charge may take approximately 2-3 hours.

3.2 Cleaning Before First Use

Clean the device thoroughly with warm water and a mild, toy-safe soap before its initial use. Rinse thoroughly and allow it to air dry completely or gently pat dry with a lint-free cloth.



Figure 3: Side profile of the device, illustrating the textured stimulator head.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

To power on the device, press and hold the power button (usually indicated by a symbol or a distinct button on the device) for 2-3 seconds until the vibration begins. To power off, press and hold the power button again for 2-3 seconds until the vibration stops.

4.2 Changing Vibration Modes

Once the device is powered on, short press the power button to cycle through the available vibration modes. The device typically offers multiple patterns and intensities. Continue pressing until you find your preferred setting.

4.3 Application

The SVAKOM Tammy features a double-ring design. One ring is intended for placement around the base of the penis, and the other around the testicles, to help maintain erection and enhance sensation. The vibrating element should be positioned to provide clitoral stimulation for the partner during intercourse. Apply a generous amount of water-based lubricant to both the device and yourself for comfortable application and use.

5. MAINTENANCE

5.1 Cleaning After Use

After each use, clean the device immediately. Wash it with warm water and a mild, toy-safe soap. Rinse thoroughly to remove all soap residue. Ensure the charging port is dry before storing or recharging.

5.2 Storage

Store the device in a clean, dry, and cool place, away from direct sunlight and extreme temperatures. Keep it separate from other sex toys made of different materials (e.g., silicone with silicone, avoid silicone with TPE/TPR) to prevent material degradation.

5.3 Charging

Recharge the device when the vibrations weaken or the indicator light signals low battery. Avoid overcharging by disconnecting the charger once the battery is full.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on or vibrate.	Battery is depleted.	Charge the device fully. Ensure the charging cable is securely connected.
Vibrations are weak.	Low battery.	Recharge the device.
Device not responding to button presses.	Device may be in a locked state or requires a reset.	Try holding the power button for a longer duration (e.g., 5-10 seconds) to reset. If issues persist, contact customer support.

If you encounter problems not listed here or if the suggested solutions do not resolve the issue, please contact SVAKOM customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	SVAKOM
Model Number	3133385
Material	Silicone
Product Dimensions (L x W x H)	2.76 x 2.24 x 2.36 inches

Feature	Detail
Item Weight	6.35 ounces
Batteries	1 Lithium Polymer battery required
Water Resistance Level	Waterproof
Product Care Instructions	Hand Wash
Date First Available	January 21, 2019

8. WARRANTY AND SUPPORT

Specific warranty details for the SVAKOM Tammy Double Ring Couples Cock Ring are typically provided with the product packaging or available on the official SVAKOM website. Please refer to these resources for comprehensive warranty information.

For technical support, product inquiries, or warranty claims, please visit the official SVAKOM website or contact their customer service department through the contact information provided on their site.

9. IMPORTANT SAFETY INFORMATION

Legal Disclaimer: Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

General Safety Precautions:

- Do not use if the device appears damaged or defective.
- Discontinue use immediately if you experience any discomfort, pain, or irritation.
- Keep out of reach of children.
- Use only water-based lubricants with this silicone product. Oil-based lubricants can damage silicone.
- Consult a healthcare professional if you have any pre-existing medical conditions or concerns before using this product.