

Armitron 20/5351BKSV

Armitron Men's Multi-Function Bracelet Watch 20/5351BKSV User Manual

Model: 20/5351BKSV

1. INTRODUCTION

This user manual provides detailed instructions for the proper setup, operation, maintenance, and troubleshooting of your Armitron Men's Multi-Function Bracelet Watch, model 20/5351BKSV. Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece.

2. PRODUCT OVERVIEW

The Armitron Men's Multi-Function Bracelet Watch is a sophisticated timepiece designed for daily wear. It features a durable stainless steel case and bracelet, a matte black dial, and a mineral crystal lens for enhanced scratch resistance. The watch incorporates three functional subdials for day, date, and 24-hour tracking, along with luminous hands and markers for visibility in low light conditions.



Front view of the Armitron Men's Multi-Function Bracelet Watch, showcasing the black dial, silver-tone case, and bracelet.



The Armitron watch displayed on a wrist, illustrating its size and fit.

3. SETUP INSTRUCTIONS

3.1 Setting the Time

1. Pull the crown (the knob on the side of the watch) out to the second click position.
2. Turn the crown clockwise or counter-clockwise to set the hour and minute hands to the desired time.
3. Push the crown back in to the normal position to start the watch.

3.2 Setting the Day and Date

The watch features separate subdials for day and date. These are typically adjusted using the pushers located on the

side of the watch case, adjacent to the crown. Refer to the specific markings on your watch for precise pusher functions.

- **Date Subdial:** Use the upper pusher to advance the date.
- **Day Subdial:** Use the lower pusher to advance the day of the week.
- **24-Hour Subdial:** This subdial typically synchronizes with the main hour hand and does not require separate adjustment.

Note: Avoid adjusting the date between 9 PM and 3 AM, as this can interfere with the automatic date change mechanism.

3.3 Adjusting the Bracelet

The silver-tone adjustable link bracelet can be sized for a comfortable fit. For precise adjustment, it is recommended to visit a professional jeweler or watch repair service to add or remove links. The bracelet features a fold-over clasp with a safety mechanism for secure wearing.

4. OPERATING INSTRUCTIONS

4.1 Water Resistance

Your Armitron watch is water resistant to 50 meters (165 feet). This rating indicates that the watch is generally suitable for short periods of recreational swimming. It is **not** suitable for diving or snorkeling. Avoid operating the crown or pushers while the watch is wet or submerged.

WATER RESISTANT CHART	
 NOT WATER RESISTANT	NOT WATER RESISTANT
 ACCIDENTAL SPLASHES	WATER RESISTANT TO 30M (100FT): In general, withstands splashes or brief immersion in water, but not suitable for swimming or bathing
 SWIMMING	WATER RESISTANT TO 50M (165FT): In general, suitable for short periods of recreational swimming, but not diving or snorkeling
 SNORKELING	WATER RESISTANT TO 100 M (330 FT): In general, suitable for swimming and snorkeling, but not scuba diving

Official water resistance chart, indicating that 50M (165FT) is suitable for swimming but not diving or snorkeling.

5. MAINTENANCE

5.1 Cleaning Your Watch

To maintain the appearance of your watch, wipe the case and bracelet regularly with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Avoid using harsh chemicals or abrasive materials, as these can damage the finish.

5.2 Battery Replacement

The watch is powered by a Japanese-quartz movement, which requires a battery. When the watch stops or the timekeeping becomes erratic, it indicates that the battery needs replacement. It is highly recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and maintain water resistance.

5.3 Storage

When not wearing your watch, store it in a cool, dry place, away from direct sunlight and extreme temperatures. The original watch box provides excellent protection for storage.

6. TROUBLESHOOTING

If you encounter issues with your Armitron watch, please refer to the following common problems and solutions:

- **Watch Not Running:** This is most commonly due to a depleted battery. Refer to section 5.2 for battery replacement.
- **Incorrect Time/Date:** Ensure the crown is fully pushed in after setting. If the time or date frequently resets, check if the crown or pushers are accidentally being engaged.
- **Condensation Under Crystal:** If condensation appears under the crystal, it may indicate a breach in the water resistance. Avoid further exposure to water and seek professional service immediately.

Your browser does not support the video tag.

Official product video demonstrating the Armitron Men's Multi-Function Bracelet Watch. This video provides a visual overview of the watch's design and features.

7. SPECIFICATIONS

Feature	Detail
Model Number	20/5351BKSV
Case Diameter	52.5mm
Movement	Japanese-quartz Movement
Lens Material	Mineral Crystal

Water Resistance	50m (165ft)
Material	Stainless-steel
Dial Features	Matte black dial with day, date and 24 hour subdials; silver-tone luminous hands and markers; printed outer minute track

8. WARRANTY AND SUPPORT

Armitron watches are manufactured to high standards and come with a manufacturer's warranty. For specific warranty details, including coverage and duration, please refer to the warranty card included with your purchase or visit the official Armitron website. For technical support or service inquiries, please contact Armitron customer service directly. You can visit the official Armitron store on Amazon for more information:[Armitron Store](#)

© 2025 Armitron. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

