

[Manuals.plus](#) /

› [Harman Kardon](#) /

› Harman Kardon Esquire Mini 2 Portable Bluetooth Speaker User Manual

Harman Kardon HKESQUIREM2SILAM

Harman Kardon Esquire Mini 2 Portable Bluetooth Speaker User Manual

Model: HKESQUIREM2SILAM

1. PRODUCT OVERVIEW

The Harman Kardon Esquire Mini 2 is an ultra-slim and portable Bluetooth speaker designed for convenience and high-fidelity sound. Its compact size allows it to fit easily into briefcases or purses, making it an ideal travel companion. Despite its slim profile, it delivers powerful audio through specially tuned acoustics and super thin speaker drivers. The device also features a built-in conferencing system with noise cancellation for clear calls and a power bank function to charge other devices.

Key Features:

- Wireless Bluetooth Streaming
- High fidelity sound
- Conferencing system with noise cancellation
- Up to 10 hours of playtime
- Built-in power bank for device charging
- Included carrying pouch for portability



Figure 1: Front view of the Harman Kardon Esquire Mini 2 speaker.

2. PACKAGE CONTENTS

Please check the box for the following items:

- Esquire Mini 2 Speaker
- Pouch
- USB-C Cable
- Quick Guide



Figure 2: Harman Kardon Esquire Mini 2 with its included carrying pouch.

3. INITIAL SETUP

3.1 Charging the Speaker

Before first use, fully charge your Esquire Mini 2 speaker. Connect the supplied USB-C cable to the charging port on the speaker and the other end to a USB power adapter (not included) or a computer USB port. The charging time is approximately 3 hours for a full charge.

3.2 Powering On/Off

- To power on: Press and hold the Power button () located on the side of the speaker until the indicator lights illuminate.
- To power off: Press and hold the Power button () again until the indicator lights turn off.



Figure 3: Side view of the speaker showing the charging and power bank ports.

4. OPERATING INSTRUCTIONS

4.1 Bluetooth Pairing

To connect your Esquire Mini 2 to a Bluetooth-enabled device:

1. Power on the speaker.
2. Press the Bluetooth button () on the side of the speaker. The Bluetooth indicator light will flash, indicating it is in pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
4. Select "Harman Kardon Esquire Mini 2" from the list.
5. Once connected, the Bluetooth indicator light will glow solid blue.

4.2 Making and Receiving Calls (Conferencing System)

The Esquire Mini 2 features a built-in microphone and noise cancellation technology for clear conference calls.

- To answer a call: Press the Call button ().
- To end a call: Press the Call button () again.
- To reject a call: Press and hold the Call button ().

4.3 Using as a Power Bank

The speaker can charge your mobile devices. Connect your device to the USB-A output port on the Esquire Mini 2 using your device's charging cable.

4.4 Controls and Indicators



Figure 4: Side view of the speaker with control buttons.

- **Power Button** (): Powers the speaker on or off.
- **Bluetooth Button** (): Initiates Bluetooth pairing mode.
- **Call Button** (): Answers, ends, or rejects phone calls.
- **Volume Buttons** (+ / -): Adjusts the playback volume.
- **LED Indicators**: Show battery status and Bluetooth connection status.

5. CARE AND MAINTENANCE

- **Cleaning**: Use a soft, dry cloth to clean the speaker. Do not use abrasive cleaners or solvents.
- **Storage**: Store the speaker in a cool, dry place when not in use. Avoid extreme temperatures.
- **Battery Care**: To prolong battery life, fully charge the speaker before long periods of inactivity. Avoid completely draining the battery frequently.
- **Water Resistance**: This product is NOT waterproof. Avoid exposure to water or excessive moisture.

6. TROUBLESHOOTING GUIDE

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is depleted.	Charge the speaker using the supplied USB-C cable.
Cannot pair via Bluetooth.	Speaker is not in pairing mode or device Bluetooth is off.	Ensure speaker is in pairing mode (flashing Bluetooth light). Check Bluetooth settings on your device. Move speaker closer to device.
No sound from speaker.	Volume is too low or device is not connected.	Increase speaker and device volume. Ensure Bluetooth is connected.
Power bank not charging device.	Speaker battery is low or cable is faulty.	Ensure speaker has sufficient charge. Try a different USB cable.

7. TECHNICAL SPECIFICATIONS

Model Name	Harman Kardon Esquire Mini 2 - Silver
Item Model Number	HKESQUIREM2SILAM
Speaker Type	Bluetooth
Connectivity Technology	Bluetooth
Wireless Communication Technology	Bluetooth
Audio Output Mode	Stereo
Surround Sound Channel Configuration	2.0

Speaker Maximum Output Power	25 Watts
Power Source	Battery Powered
Battery Type	1 Lithium Polymer battery (included)
Charging Time	3 Hours
Playtime	Up to 10 hours
Color	Silver
Product Dimensions	7.6 x 2.28 x 4.33 inches
Item Weight	8.8 ounces (250 Grams)
Is Waterproof	FALSE
Manufacturer	Harman Kardon
UPC	028292284786

8. WARRANTY AND SUPPORT

The Harman Kardon Esquire Mini 2 comes with a Limited Warranty. Please refer to the Quick Guide included in your package for specific warranty terms and conditions.

For further assistance, technical support, or warranty claims, please visit the official Harman Kardon website or contact their customer service department. Contact information can typically be found on the manufacturer's website or in the product packaging.

© 2024 Harman Kardon. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07N12B8W3>

More documents and user manuals: <https://manuals.plus/>