



Manuals.plus /

- › Summer Infant /
- › Summer Infant Ingenuity 3Dlite Convenience Stroller User Manual

**Summer Infant 32843**

# Summer Infant Ingenuity 3Dlite Convenience Stroller User Manual

Model: 32843

## 1. INTRODUCTION

This manual provides essential instructions for the safe assembly, operation, and maintenance of your Summer Infant Ingenuity 3Dlite Convenience Stroller. Please read all instructions carefully before use and retain this manual for future reference. This stroller is designed for children from 6 months up to 50 pounds (approximately 43 inches in height).



Image 1.1: The Summer Infant Ingenuity 3Dlite Convenience Stroller, showcasing its overall design.

## 2. SAFETY INFORMATION

- **WARNING:** Never leave child unattended.
- **WARNING:** Always use the restraint system.
- **WARNING:** Ensure that all locking devices are engaged before use.
- **WARNING:** To avoid injury, ensure that your child is kept away when unfolding and folding this product.
- **WARNING:** Do not let your child play with this product.
- **WARNING:** Check that the stroller body or the seating unit attachment devices are correctly engaged before use.
- This stroller is suitable for children from 6 months up to a maximum weight of 50 pounds (22.7 kg) and a maximum height of 43 inches (109 cm).
- Do not overload the storage basket. Maximum weight for the storage basket is 10 lbs (4.5 kg).

- Do not hang bags or other items on the handle, as this may cause the stroller to become unstable.
- This stroller is not compatible with car seats.

### 3. PRODUCT FEATURES

The Summer Infant Ingenuity 3Dlite Convenience Stroller offers a range of features designed for convenience and comfort:

- **Lightweight Aluminum Frame:** Weighs approximately 13.0 lbs (5.9 kg) for easy portability.
- **Compact Fold:** Designed for easy storage and transport with an auto-lock feature and carry strap.
- **4-Position Recline:** Adjustable seat recline for child's comfort.
- **5-Point Safety Harness:** Ensures child security.
- **Adjustable Canopy:** Features a flip-out sun visor for sun protection.
- **Extra-Large Storage Basket:** Provides ample space for essentials.
- **Rear Storage Pocket:** Convenient for smaller items.
- **Cup Holder:** Attachable cup holder for beverages.
- **Anti-Shock Front Wheels:** For a smoother ride.
- **Lockable Rear Wheels:** For secure parking.



XL storage basket



cup holder

storage pocket

Image 3.1: Details of the storage basket, cup holder, and rear pocket.

#### 4. ASSEMBLY AND SETUP

The stroller comes partially assembled. Follow these steps to complete the setup:

##### 1. Unfolding the Stroller:

- Place the stroller on a flat surface.
- Release the auto-lock mechanism (if engaged).
- Pull the handles upwards until the frame locks into place. Ensure both side locks are fully engaged with an audible click.

##### 2. Attaching the Canopy:

- Align the canopy attachment points with the corresponding slots on the stroller frame.
- Securely fasten the canopy.

### **3. Attaching the Cup Holder:**

- Clip the cup holder onto the designated area on the stroller handle.

## **5. OPERATING INSTRUCTIONS**

### **5.1. Folding the Stroller**

To fold the stroller for storage or transport:

1. Ensure the child is removed from the stroller.
2. Engage the rear wheel brakes.
3. Retract the canopy.
4. Locate the folding mechanism, typically near the handles or on the side of the frame.
5. Follow the specific instructions for your model to release the frame locks and collapse the stroller.
6. Once folded, ensure the auto-lock engages to keep it compact. Use the carry strap for easy transport.



lightweight (13 lbs.)  
compact fold



Image 5.1: The stroller in its compact folded position, highlighting its portability.

## 5.2. Adjusting the Seat Recline

The stroller features a 4-position recline for your child's comfort:

1. Locate the recline adjustment lever or strap on the back of the seat.
2. Gently squeeze the lever or adjust the strap to release the recline mechanism.
3. Move the seat to the desired position (upright, semi-recline, or full recline).
4. Ensure the seat is securely locked into the chosen position before placing your child in the stroller.



Image 5.2: Illustration of the 4-position seat recline feature.

### 5.3. Securing the 5-Point Harness

Always use the 5-point safety harness to secure your child:

1. Place your child in the seat.
2. Bring the shoulder straps over your child's shoulders and the waist straps around their hips.
3. Insert the buckle tongues into the buckle housing until they click securely.
4. Adjust the straps to ensure a snug fit, without being too tight. The shoulder straps can be adjusted for height as your child grows.

### 5.4. Engaging the Brakes

To engage the rear wheel brakes:

1. Press down firmly on the brake levers located on the rear wheels.
2. Ensure both brakes are fully engaged before releasing the stroller.
3. To release, lift the brake levers upwards.

## 5.5. Adjusting the Canopy

The canopy provides shade and sun protection:

1. Pull the canopy forward to extend it.
2. Flip out the sun visor for additional coverage.
3. Push the canopy back to retract it.



canopy with pop  
out sun visor



Image 5.3: The adjustable canopy with its integrated pop-out sun visor.

## 6. MAINTENANCE

Proper maintenance ensures the longevity and safety of your stroller:

- **Cleaning Fabric:** Clean minor stains on fabric components with cold water and mild soap. Air dry thoroughly. Do not use bleach.



- **Cleaning Frame:** Clean plastic and metal surfaces with a soft, damp cloth. Air dry. Do not use abrasive cleaners or solvents.
- **Regular Checks:** Periodically check all fasteners, rivets, and moving parts to ensure they are secure and functioning correctly.
- **Storage:** Store the stroller in a dry, cool place away from direct sunlight when not in use.

## 7. TROUBLESHOOTING

If you encounter issues with your stroller, refer to the following common problems and solutions:

| Problem  | Possible Cause  | Solution   |
|--|---|--|
| Stroller will not unfold completely.           | Auto-lock engaged or frame not fully extended.          | Ensure auto-lock is disengaged. Pull handles firmly until all frame locks click into place.                    |
| Wheels are stiff or squeaky.                   | Dirt or debris in wheel mechanism; lack of lubrication. | Clean wheels and axles. Apply a small amount of silicone-based lubricant if necessary.                         |
| Brakes are not engaging or releasing properly. | Debris in brake mechanism or misalignment.              | Clear any debris from the brake area. Check for proper alignment. If issue persists, contact customer support. |
| Harness is difficult to buckle or unbuckle.    | Debris in buckle or misalignment.                       | Ensure buckle components are clean and free of obstructions.   |

## 8. SPECIFICATIONS

| Feature                       | Detail                                 |
|-------------------------------|--|
| Model Number                  | 32843                                  |
| UPC                           | 012914328439                           |
| Brand                         | Summer Infant                          |
| Color                         | Jet Blue                               |
| Material                      | Aluminum frame, Fabric seat, EVA tires |
| Age Range                     | 6 Months and Up                        |
| Maximum Weight Recommendation | 50 Pounds (22.7 kg)                    |
| Maximum Height Recommendation | 43 Inches (109 cm)                     |
| Item Weight                   | 13.0 lbs (5896.7 Grams)                |
| Item Dimensions (L x W x H)   | 40.5" x 10.2" x 42.5"                  |
| Folded Size                   | 44" x 9.5" x 13"                       |
| Harness Type                  | 5 Point                                |
| Number of Cup Holders         | 1                                      |
| Maximum Storage Basket Weight | 10 lbs                                 |
| Safety Standard               | ASTM                                   |

## 9. WARRANTY AND SUPPORT

**Manufacturer Warranty:** This product comes with a 90-Day Limited Warranty from the manufacturer, Kids2, Inc. Please refer to the warranty documentation included with your purchase for full details and terms.

**Additional Support:** For further assistance, please refer to the official user manual PDF available online or contact Summer Infant customer service. The PDF manual can be found at: <https://m.media-amazon.com/images//A1jGTjIHaRS.pdf>