



Manuals.plus /

- › [Ikea](#) /
- › [IKEA Hemnes 702.176.85 Tall Cabinet with Mirror Door User Manual](#)

Ikea 702.176.85

IKEA Hemnes 702.176.85 Tall Cabinet with Mirror Door User Manual

Model: 702.176.85

PRODUCT OVERVIEW

The IKEA Hemnes 702.176.85 is a tall cabinet designed for storage, featuring a mirror door. This unit is suitable for various rooms, including bathrooms, offering both storage and a reflective surface. It includes adjustable shelves for flexible storage solutions and a safety film on the mirror to reduce injury risk in case of breakage.



Image: The IKEA Hemnes tall cabinet integrated into a modern white bathroom environment, showcasing its design and utility alongside other bathroom furniture.

SETUP AND ASSEMBLY

This product requires assembly. Ensure all components are present before beginning. The cabinet includes one fixed shelf, four adjustable shelves, and a knob. Follow the detailed assembly instructions provided in the product packaging for proper construction.

Wall Anchoring Safety

Important Safety Notice: This furniture must be securely fixed to the wall using the included wall anchoring device to prevent tipping. Different wall materials require specific types of fasteners. Use fasteners appropriate for your home's wall materials. Consult a professional if you are unsure about the correct fasteners to use.





Image: A diagram illustrating the dimensions of the IKEA Hemnes tall cabinet, showing its height (200.03 cm), width (48.9 cm), and depth (31.12 cm).





Image: A clear front view of the IKEA Hemnes tall cabinet, highlighting its full-length mirror door and white finish.

Adjusting Shelves

The cabinet features four adjustable shelves, allowing you to customize the storage space according to your personal needs. To adjust a shelf, carefully remove any items, lift the shelf, and reposition the shelf supports to the desired height. Ensure the shelf is securely seated on the supports before placing items back.



Image: The IKEA Hemnes tall cabinet with its mirror door open, revealing the interior with multiple adjustable shelves and stored items.

Using the Mirror Door

The cabinet door features a mirror equipped with a safety film on the back. This film is designed to reduce the risk of injury in the event of glass breakage. Handle the mirror door with care to maintain its integrity and prevent damage.



Image: A close-up view of the black knob on the IKEA Hemnes cabinet door, showing its design and how it protrudes from the white door frame.

MAINTENANCE

To keep your IKEA Hemnes cabinet in optimal condition, follow these maintenance guidelines:

- Wipe the surfaces clean with a damp cloth.
- For the mirror and other surfaces, use only water or a window cleaner.
- After cleaning, wipe dry with a clean cloth to prevent water spots or streaks.



Image: A close-up of the adjustable leg at the base of the IKEA Hemnes cabinet, showing the leveling mechanism.

TROUBLESHOOTING

Damaged or Missing Parts

If you receive the product with damaged or missing components, do not proceed with assembly. Contact IKEA customer service immediately for assistance and replacement parts. Attempting to assemble with damaged parts may compromise the stability and safety of the unit.

Stability Issues

Ensure the cabinet is properly anchored to the wall as per the safety instructions. Verify that all screws and fasteners are tightened. If the floor is uneven, use the adjustable feet (if present) to level the cabinet and ensure stability.

SPECIFICATIONS

Feature	Detail
Model Number	702.176.85
Brand	Ikea
Color	White
Material	Engineered Wood (Fiberboard), Acrylic Paint, Glass
Dimensions (W x D x H)	49 cm x 31 cm x 200 cm (19 1/4" x 12 1/4" x 78 3/4")
Number of Shelves	1 fixed, 4 adjustable
Special Features	Adjustable shelves, Mirror door with safety film, Wall-mountable
Assembly Required	Yes
Components Included	Shelves, Mirror, Knob, Wall anchoring device

WARRANTY INFORMATION

For detailed information regarding the warranty for your IKEA Hemnes cabinet, please refer to the warranty documentation included with your purchase or visit the official IKEA website. Warranty terms and conditions may vary by region.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report damaged/missing parts, please contact IKEA customer service. You can find contact information on the official IKEA website or in the documentation provided with your product.