

## Graco 2081360

# Graco Floor2Table 7-in-1 High Chair Instruction Manual

Model: 2081360

## INTRODUCTION

The Graco Floor2Table 7-in-1 High Chair is designed to adapt to your child's growth, offering seven distinct stages from an infant floor seat to a big kid table and chair. This manual provides essential information for the safe and proper assembly, operation, maintenance, and care of your high chair.

## KEY FEATURES

- 7 growing stages: Infant Floor Seat, Full-Size Highchair, Infant Booster, Toddler Booster, Youth Stool, Big Kid Table and Chair, and Seating for Two Kids.
- Easy-clean materials, including a stain-resistant, wipe-clean foam seatback.
- Two trays: a snack-sized smaller tray and a larger full-size tray for versatile mealtime options.
- 3-position recline for infant comfort in the full-size highchair.

## SETUP

For detailed assembly instructions, please refer to the included assembly guide. The high chair components are designed for intuitive setup. Ensure all parts are securely fastened before use.

### Video: Graco Floor2Table 7-in-1 Highchair Overview

This video provides a general overview of the Graco Floor2Table 7-in-1 Highchair, demonstrating its various configurations and features. It can assist with initial setup and understanding the product's versatility.

## OPERATING MODES

The Graco Floor2Table High Chair offers 7 versatile modes to accommodate your child's growth:

1. **Infant Floor Seat:** The perfect first seat for playtime or early feedings.
2. **Full-Size Highchair:** Features easy-clean materials and a 3-position recline for comfort.

3. **Infant Booster:** Attaches to a dining chair, bringing your baby closer to the table.
4. **Toddler Booster:** Provides a secure seat as your child grows.
5. **Youth Stool:** Offers an elevated seat for older children at the table.
6. **Big Kid Table and Chair:** Transforms into a separate table and chair for snacks or play.
7. **Seats Two Kids at Once:** Utilize the youth stool and booster for mealtime, or the floor seat and table & chair for playtime.

# 7 GROWING STAGES



**Image: Seven Growing Stages**

This image illustrates the seven different configurations of the Graco Floor2Table High Chair, demonstrating its adaptability from infant to toddler stages.



# HIGHCHAIR CONVERTS TO FLOOR SEAT

**Image: Highchair Converts to Floor Seat**

This image displays the high chair in its infant floor seat configuration, suitable for early stages of feeding and play.



**Image: Floor Seat and Table Configuration**

This image shows the high chair separated into a floor seat and a small table, ideal for independent play or snack time for older children.



**Image: Booster Seat Configuration**

This image demonstrates the booster seat mode, where the seat unit is secured to a standard dining chair, allowing the child to join family meals at the table.

## **CLEANING AND MAINTENANCE**

The Graco Floor2Table High Chair is designed for easy cleaning:

- The seat pad is removable and machine-washable. Refer to the care tag for specific washing instructions.
- The foam seatback is stain-resistant and can be easily wiped clean with a damp cloth and mild soap.
- Both the snack-sized and full-size trays are removable and dishwasher-safe for thorough cleaning.
- Periodically check all parts for wear or damage. Replace any worn or broken components immediately.

# 2 TRAYS FOR MEALS & SNACKS



**Image: Two Removable Trays**

This image highlights the two removable trays, demonstrating their ease of detachment for cleaning after meals or snacks.

## TROUBLESHOOTING

If you encounter any issues with your Graco Floor2Table High Chair, please refer to the following common solutions:

- **Difficulty adjusting tray or seat:** Ensure no food debris or obstructions are blocking the adjustment mechanisms. Apply gentle, even pressure when adjusting.
- **Unstable chair:** Verify that all legs are fully extended and locked into place. Ensure the chair is on a flat, stable surface.
- **Straps not securing:** Check that the harness straps are correctly threaded through the seat and buckle, and adjust for a snug fit.

For persistent issues, contact Graco customer support.

## SPECIFICATIONS

- **Model Number:** 2081360
- **Item Weight:** 19.18 pounds
- **Product Dimensions:** 28.5 x 22.7 x 42.25 inches (D x W x H)
- **Material:** Foam (seatback)
- **Color:** Atwood



**Image: Product Dimensions**

This image provides a visual representation of the high chair with its key dimensions labeled.

## WARRANTY AND SUPPORT

---

For information regarding product warranty, registration, or customer support, please visit the official Graco website or refer to the warranty card included with your purchase. Keep your proof of purchase for warranty claims.

**Graco Customer Service:** For assistance, please refer to the contact information provided on the Graco website or in your product packaging.