

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Bialetti](#) /
- › [Bialetti Break Espresso Coffee Machine Instruction Manual](#)

## Bialetti 012670010

# Bialetti Break Espresso Coffee Machine Instruction Manual

Model: CF67 (012670010)

## INTRODUCTION

---

Thank you for choosing the Bialetti Break Espresso Coffee Machine. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and keep it for future reference.



*Image: The Bialetti Break Espresso Coffee Machine in red and black, featuring a compact design and a glass cup filled with espresso.*

## **IMPORTANT SAFETY INSTRUCTIONS**

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.

- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

## PRODUCT COMPONENTS

---

Familiarize yourself with the main parts of your Bialetti Break Espresso Coffee Machine:

1. Water Tank
2. Capsule Insertion Lever
3. Capsule Compartment
4. Used Capsule Drawer (capacity: 10 capsules)
5. Drip Tray
6. Coffee Dispenser Spout
7. Power Button / Indicator Light



*Image: A close-up view of the used capsule drawer, designed to hold up to 10 spent capsules.*



*Image: Detail of the power button, which also serves as an indicator light for machine status.*

## SETUP AND FIRST USE

---

1. **Unpacking:** Carefully remove the coffee machine from its packaging. Retain packaging for future transport or storage.
2. **Positioning:** Place the machine on a stable, flat, and heat-resistant surface, away from water sources and direct heat. Ensure adequate ventilation around the machine.
3. **Cleaning:** Before first use, wash the water tank and drip tray with warm water and a mild detergent. Rinse thoroughly and dry.
4. **Filling the Water Tank:** Fill the water tank with fresh, cold drinking water up to the MAX level. Do not exceed the MAX line.
5. **Initial Rinse Cycle:**
  - Place an empty cup under the coffee dispenser spout.
  - Plug the machine into a grounded electrical outlet. The power button will illuminate.
  - Press the power button to turn on the machine. Wait for the machine to heat up (indicator light will stop blinking and remain solid).
  - Press the coffee dispensing button without inserting a capsule. Allow water to flow through the system until the water tank is nearly empty. This primes the pump and cleans the internal circuits.
  - Refill the water tank. Your machine is now ready for use.

## OPERATING INSTRUCTIONS

---

The Bialetti Break machine is designed for use exclusively with Bialetti aluminum capsules.

# Sistema Bialetti Il Caffè d'Italia

Funziona esclusivamente con capsule Bialetti



*Image: The Bialetti Break machine shown with a box of Bialetti Il Caffè d'Italia Napoli capsules, emphasizing compatibility.*

1. **Power On:** Ensure the water tank is filled with fresh water. Plug in the machine and press the power button. Wait for the indicator light to become solid, indicating the machine is heated and ready. The thermoblock boiler ensures hot coffee from the first use.
2. **Insert Capsule:** Lift the capsule insertion lever. Insert one Bialetti aluminum capsule into the capsule compartment. Close the lever firmly. The machine features auto-expulsion of the capsule when the lever is opened after brewing.



*Image: A hand demonstrating the insertion of a Bialetti coffee capsule into the machine's designated slot.*

3. **Place Cup:** Place your desired coffee cup on the drip tray, directly under the coffee dispenser spout.
4. **Brew Coffee:** Press the coffee dispensing button. The machine will automatically brew your espresso. The 20-bar pump pressure ensures excellent extraction for an aromatic and thick coffee.
5. **Capsule Ejection:** Once brewing is complete, lift the capsule insertion lever. The used capsule will automatically eject into the internal used capsule drawer.
6. **Power Off:** To turn off the machine, press the power button. The machine also features an energy-saving auto-off function after 10 minutes of inactivity.

## MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your Bialetti Break machine.

- **Daily Cleaning:**
  - After each use, empty and rinse the drip tray and used capsule drawer.
  - Wipe the exterior of the machine with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Water Tank:** Clean the water tank regularly with warm water and mild detergent. Rinse thoroughly.
- **Descaling:** Depending on water hardness, descaling should be performed every 2-3 months. Use a descaling

solution specifically designed for coffee machines. Follow the descaling product's instructions carefully.

- **Storage:** If the machine will not be used for an extended period, empty the water tank and clean all removable parts. Store in a dry, dust-free place.



*Image: An exploded view diagram illustrating the components of a 100% recyclable Bialetti capsule, highlighting its aluminum lid and body for aroma preservation.*

## TROUBLESHOOTING

Before contacting customer support, please refer to the following common issues and their solutions:

Problem	Possible Cause	Solution
Machine does not turn on.	Not plugged in; power outlet issue.	Ensure plug is fully inserted. Check power outlet with another appliance.

Problem	Possible Cause	Solution
No coffee dispenses or only a few drops.	Water tank empty; machine not primed; machine needs descaling; capsule not inserted correctly.	Refill water tank. Perform initial rinse cycle. Descale the machine. Ensure capsule is correctly seated and lever is fully closed.
Coffee is not hot enough.	Machine not fully heated; machine needs descaling.	Wait for the indicator light to be solid. Descale the machine.
Water leaking from machine.	Water tank not seated correctly; drip tray overflowing.	Ensure water tank is properly seated. Empty the drip tray.

## TECHNICAL SPECIFICATIONS

- **Brand:** Bialetti
- **Model Name:** CF67
- **Model Number:** 012670010
- **Color:** Red
- **Product Dimensions (L x W x H):** 12.9 x 29.5 x 23.3 cm
- **Item Weight:** 3.86 Kilograms
- **Special Features:** Timer, Thermal (Thermoblock boiler)
- **Coffee Maker Type:** Espresso Machine
- **Operation Mode:** Fully Automatic
- **Pump Pressure:** 20 bars
- **Energy Saving:** Automatic shut-off after 10 minutes of inactivity
- **Capsule Compatibility:** Exclusively Bialetti aluminum capsules
- **Used Capsule Drawer Capacity:** 10 capsules

## WARRANTY AND SUPPORT

Bialetti products are manufactured to the highest quality standards. For information regarding warranty coverage, service, or spare parts availability, please refer to the warranty card included with your product or visit the official Bialetti website. Please note that information on spare parts availability was not provided in the product details.

For customer support, please contact Bialetti directly through their official channels. You can often find contact information on the product packaging or on the [Bialetti Brand Store on Amazon](#).