

[Manuals.plus](#) /

> [Bissell](#) /

> Bissell Perfect Sweep Turbo Cordless Floor Sweeper Instruction Manual

## Bissell Perfect Sweep Turbo

# Bissell Perfect Sweep Turbo Cordless Floor Sweeper Instruction Manual

Model: Perfect Sweep Turbo

## INTRODUCTION

---

This manual provides essential instructions for the safe and efficient use of your Bissell Perfect Sweep Turbo Cordless Floor Sweeper. This device is designed for quick clean-ups on various floor types, offering cordless convenience. Please read all instructions before operating your sweeper.

The Bissell Perfect Sweep Turbo is a motorized sweeper, not a vacuum. It operates without suction and is ideal for picking up dry debris from hard floors, carpets, and area rugs.





*Image: The Bissell Perfect Sweep Turbo in action, demonstrating its cordless cleaning capability on a rug.*

## SETUP AND CHARGING

---

Before first use, ensure the sweeper is fully charged.

1. **Initial Charge:** Connect the charger to the sweeper and a power outlet. The charging indicator light will illuminate.
2. **Charging Indicator:** The light will remain on while charging and when fully charged.
3. **Power On After Charging:** Once the charger is disconnected, the light will turn off, but the unit will be powered on and ready for use.

4. **Important Note:** The unit will not charge if the power switch is in the "on" position. Always ensure the power switch is in the "off" position when charging.

## OPERATING INSTRUCTIONS

---

The Bissell Perfect Sweep Turbo is designed for convenient, quick clean-ups.

- **Power On/Off:** Locate the power switch on the unit and slide it to the "on" position to begin sweeping.
- **Cordless Operation:** Enjoy up to 60 minutes of cordless cleaning time on a full charge.
- **Surface Compatibility:** This sweeper is safe for use on various surfaces, including carpets, area rugs, and hard floors. It is ideal for in-between cleanings.
- **Maneuverability:** The lightweight design and easy-glide rubber wheels allow for versatile cleaning, including under furniture.



### Powerful cordless cleaning

with a long-lasting battery and powered brush

*Image: A user operating the Bissell Perfect Sweep Turbo on a carpet, highlighting its powerful cordless cleaning.*



### Quiet operation


*Image: The sweeper in use, demonstrating its quiet operation suitable for various environments.*

## Lightweight and versatile



*Image: The lightweight and versatile design allows the sweeper to easily clean under furniture.*

## Multi-surface



*Image: Visual representation of the sweeper's multi-surface capability for hard floors, carpet, and area rugs.*

## MAINTENANCE

---

Regular maintenance ensures optimal performance of your sweeper.

- **Emptying the Dirt Container:** The sweeper features an easy-to-remove, top-loading dirt container. Empty it regularly to maintain cleaning efficiency.
- **Cleaning Brushes:** Hair and debris may get caught in the rotating brushes. Periodically inspect and clean the brushes to prevent entanglement and ensure effective sweeping.

# Easy-to-empty dirt cup



*Image: A hand demonstrating the easy-to-empty dirt cup of the Bissell Perfect Sweep Turbo.*

# Easy-glide rubber wheels



*Image: A close-up view of the easy-glide rubber wheels, which should be kept clean for smooth operation.*

## TROUBLESHOOTING

- **Unit Not Charging:** Ensure the power switch is in the "off" position when connecting the charger. The unit will not charge if the power switch is "on".
- **Reduced Sweeping Performance:**
  - Check if the dirt container is full and needs emptying.
  - Inspect the rotating brushes for tangled hair or debris and clean them thoroughly.
  - Ensure the unit is fully charged for optimal power.
- **Brushes Detaching:** If brushes frequently come out, ensure they are correctly seated in their designated slots after cleaning or maintenance.

## SPECIFICATIONS

Product Dimensions	8.25 x 12.75 x 43.5 inches
Item Weight	4 pounds

<b>Form Factor</b>	Stick
<b>Power Source</b>	Cordless (7.2 volts)
<b>Battery Requirement</b>	No (Integrated rechargeable battery)
<b>Manufacturer</b>	BISSELL Homecare International
<b>Model Number (ASIN)</b>	B07N49YXRF

## WARRANTY INFORMATION

---

This product comes with a **90-day limited warranty**. Please refer to the original purchase documentation or contact Bissell customer support for full details regarding warranty coverage and terms.

## CUSTOMER SUPPORT

---

For further assistance, questions, or to report issues with your Bissell Perfect Sweep Turbo, please contact BISSELL Homecare International customer support.

Contact information can typically be found on the manufacturer's official website or on the product packaging.