

## GreatPowerDirect GPD090126-30409

# USB Charging Cable User Manual

MODEL: GPD090126-30409

Brand: GreatPowerDirect

## 1. Introduction

---

This manual provides instructions for the safe and efficient use of your GreatPowerDirect USB Charging Cable, model GPD090126-30409. This cable is specifically designed to provide power and charge compatible devices, such as the Sony SRS-XB21 Portable Speaker, via a standard USB power source.

Please read this manual thoroughly before using the product and retain it for future reference.

## 2. Safety Information

---

- **Do not** expose the cable to water, moisture, or extreme temperatures.
- **Do not** attempt to modify, disassemble, or repair the cable. This may void the warranty and pose a safety risk.
- Ensure the cable is fully inserted into both the power source and the device to prevent poor connection or overheating.
- Keep out of reach of children and pets.
- Disconnect the cable from the power source when not in use or during electrical storms.
- Use only with compatible devices and power sources that meet the required voltage and current specifications.

## 3. Package Contents

---

The package contains the following item:

- 1 x GreatPowerDirect USB Charging Cable (Model: GPD090126-30409)



This image displays the black GreatPowerDirect USB charging cable. One end features a standard USB Type-A connector, typically used for power adapters or computer USB ports. The other end has a Micro-USB Type-B connector, designed to connect to compatible devices such as the Sony SRS-XB21 portable speaker.

#### 4. Setup

---

1. **Identify Connectors:** Locate the standard USB Type-A connector (the larger, rectangular end) and the Micro-USB Type-B connector (the smaller, trapezoidal end) on your cable.
2. **Connect to Power Source:** Insert the USB Type-A connector into a compatible USB power source. This can be a USB wall adapter (not included), a computer's USB port, or a portable power bank. Ensure the power source provides adequate power for your device.
3. **Connect to Device:** Carefully insert the Micro-USB Type-B connector into the charging port of your Sony SRS-XB21 Portable Speaker. Ensure it is oriented correctly and fully inserted to establish a secure connection. Do not force the connector.

#### 5. Operating Instructions

---

Once the cable is properly connected to both the power source and your Sony SRS-XB21 Portable Speaker, the speaker should begin charging. Refer to your speaker's user manual for specific charging indicators (e.g., LED lights) that confirm it is receiving power.

- Charging time may vary depending on the power source's output and the speaker's battery level.
- It is safe to use the speaker while it is charging, though charging may be slower.
- Always disconnect the cable by gently pulling on the connector housing, not the cable itself.

#### 6. Maintenance

---

- **Cleaning:** Use a soft, dry cloth to clean the cable and connectors. Do not use liquid cleaners or solvents.
- **Storage:** Store the cable in a cool, dry place away from direct sunlight and extreme temperatures.

Avoid tightly coiling or bending the cable sharply to prevent internal damage.

- **Handling:** Always handle the cable by the connectors when plugging or unplugging. Avoid pulling or tugging on the cable itself.

## 7. Troubleshooting

---

Problem	Possible Cause	Solution
Device not charging.	Loose connection, faulty power source, incompatible device, damaged cable.	Ensure both ends of the cable are securely connected. Try a different USB power source (e.g., another wall adapter or computer port). Verify the cable is compatible with your device (Sony SRS-XB21). Inspect the cable for visible damage. If damaged, discontinue use.
Slow charging.	Low power output from source, device in use while charging.	Use a USB power adapter with higher current output (e.g., 2A or more). Avoid using the device extensively while it is charging.

## 8. Specifications

---

- **Brand:** GreatPowerDirect
- **Model Number:** GPD090126-30409
- **Connector Type (Source):** USB Type A (Male)
- **Connector Type (Device):** Micro-USB Type B (Male)
- **Cable Type:** USB
- **Color:** Black
- **Compatible Devices:** Sony SRS-XB21 Portable Speaker and other devices with a Micro-USB charging port.
- **Special Feature:** Portable
- **Compliance:** FCC, CE, OEM (as per manufacturer)

## 9. Warranty Information

---

This product typically comes with a limited manufacturer's warranty against defects in materials and workmanship. Please refer to the product packaging or contact GreatPowerDirect customer support for specific warranty terms and conditions applicable to your purchase.

## 10. Customer Support

---

For technical assistance, troubleshooting, or warranty inquiries, please contact GreatPowerDirect customer support. Contact information can usually be found on the product packaging, the seller's website, or through your purchase platform.

