





Image: Complete kit including 10 LED deck lights, power adapter, and connecting cables.

## SETUP AND INSTALLATION

Follow these steps for proper installation of your LED deck lights:

- Planning:** Determine the desired locations for each of the 10 deck lights. Ensure the total cable length from the LED driver to the furthest light is sufficient.
- Drilling Holes:** Using an appropriate drill bit, create circular holes with a diameter of **22mm** (0.87 inches) at each planned light location. Ensure the depth is sufficient to accommodate the light fitting (approximately 1mm projection).
- Wiring:**
  - Feed the cable from each LED light fitting through its respective drilled hole.
  - Connect the cables from the individual light fittings to the provided extension lead or directly to the LED driver, ensuring secure connections. The system is designed for easy plug-and-play connection.

- Ensure all connections are tight and protected from moisture, especially in outdoor environments.

4. **Mounting Lights:** Gently push each LED light fitting into its drilled hole until it sits flush with the surface. The polished stainless steel finish should be visible.

5. **Power Connection:** Connect the 12V 3-pin plug LED driver to a suitable mains power outlet.

6. **Testing:** Turn on the power supply to test all lights. If any light does not illuminate, check its connection.

## OPERATING INSTRUCTIONS

Once installed and connected to a power source, the Saxby Lighting LED Deck Lights will illuminate when power is supplied to the LED driver. Operation is typically controlled via the mains power switch connected to the outlet where the driver is plugged in.

## MAINTENANCE

These LED deck lights require minimal maintenance:

- **Cleaning:** Periodically wipe the stainless steel and polycarbonate surfaces with a soft, damp cloth to remove dirt and debris. Avoid abrasive cleaners or solvents.
- **Inspection:** Regularly inspect cables and connections for any signs of wear, damage, or corrosion. Address any issues promptly to ensure safety and performance.
- **LED Longevity:** The integrated LED modules are designed for long life and are not user-replaceable.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Lights do not illuminate.	No power to the LED driver. Loose or incorrect wiring connection. Faulty LED driver.	Check the power outlet and switch. Verify all cable connections are secure. Test the LED driver with a multimeter or replace if necessary.
Some lights are off, others are on.	Loose connection to specific light fitting. Damaged individual light fitting.	Check connections for the non-working lights. If connections are secure, the light fitting may be faulty and require replacement.
Lights flicker.	Unstable power supply. Loose connection. Overloaded circuit (unlikely with low wattage LEDs).	Ensure stable power. Check all connections.

## SPECIFICATIONS

Feature	Detail
Product Dimensions	10 x 8 x 20 cm
Item Weight	0.4 Kilograms
Specific Uses	Garden lights, DIY lighting, Deck, Decking lights, Porch lighting

Feature	Detail
Finish Types	Brushed
Assembly Required	Yes
Batteries Required	No
Included Components	Cable
Item Model Number	75530
Brand	Saxby Lighting
Colour	White
Material	Stainless steel (304) & polycarbonate
Style	Modern
Light Fixture Form	Recessed
LED Module	10 x 0.45W LED module (SMD 2835)
Cut Hole Diameter	22mm
IP Rating	IP44
Class	3


## WARRANTY AND SUPPORT

This product comes with a **2-year warranty** from the date of purchase. Please retain your proof of purchase for warranty claims. For technical support or warranty inquiries, please contact Saxby Lighting customer service.

*Note: The warranty does not cover damage caused by improper installation, misuse, or unauthorized modifications.*

© 2024 Saxby Lighting. All rights reserved.

## Related Documents - 75530

	<p><a href="#">Spegel Shaver Mirror: Installation and Safety Guide</a></p> <p>This document provides installation, operation, and safety instructions for the Saxby Spegel Shaver Mirror, a bathroom light fixture with an integrated shaver socket and touch sensor.</p>
	<p><a href="#">Saxby Crystal Wall Light (39629) - Instruction Manual &amp; Installation Guide</a></p> <p>Comprehensive instruction manual for the Saxby Crystal Wall Light (39629). Learn about safety warnings, installation, wiring, and maintenance for this IP44 rated bathroom light.</p>

	<p><b>Saxby StratusPRO TPA/UGR19 LED Panel Light: Installation and User Manual</b></p> <p>Comprehensive guide for the Saxby StratusPRO TPA/UGR19 LED panel light, covering technical specifications, safety precautions, installation steps, and features like CCT selection. Suitable for suspended ceilings.</p>
	<p><b>Saxby Tango Post (13922) IP44 Instruction Manual - Installation Guide</b></p> <p>Comprehensive instruction manual for the Saxby Tango Post (13922) IP44 outdoor light fitting. Includes safety warnings, care information, and step-by-step assembly and wiring instructions.</p>
	<p><b>Saxby Palin Spike Outdoor Garden Light Installation and Care Instructions</b></p> <p>Comprehensive guide for the Saxby Palin Spike outdoor garden light, covering installation, bulb replacement, care, cleaning, safety, and wiring. Includes model numbers 13797, 13914, 75438.</p>
	<p><b>Saxby Rift Shaver Mirror 60895 - Installation and Operation Guide</b></p> <p>Comprehensive guide for the Saxby Rift Shaver Mirror (Model 60895), covering installation, operation, technical specifications, and safety precautions. Features include demister, shaver socket, and LED lighting.</p>