

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

- › [ReceiptRoll](#) /
- › ReceiptRoll Thermal Paper for Zebra QL220 & IMZ220 User Manual

ReceiptRoll T20080Z36

ReceiptRoll Thermal Paper User Manual

Model: T20080Z36



Receipt Rolls

Official brand logo for ReceiptRoll products.

PRODUCT OVERVIEW

This manual provides essential information for the proper use and maintenance of ReceiptRoll Thermal Paper, designed for compatibility with Zebra QL220 and IMZ220 mobile printers. This product consists of 36 rolls of 2-inch by 80-foot thermal paper, weighing 55 grams per square meter (GSM).



Image: Three individual rolls of ReceiptRoll thermal paper, showcasing the product's standard appearance.

SETUP AND INSTALLATION

Proper installation of thermal paper is crucial for optimal printer performance and print quality. Always refer to your specific printer's user manual (e.g., Zebra QL220 or IMZ220) for detailed loading instructions.

General Loading Procedure:

1. **Open Printer Cover:** Locate and open the paper compartment cover on your Zebra QL220 or IMZ220 printer.
2. **Insert Paper Roll:** Place the ReceiptRoll thermal paper roll into the compartment. Ensure the paper feeds from the bottom of the roll and the leading edge is positioned correctly for printing. The thermal side of the paper (usually the smoother, shinier side) should face the thermal print head.
3. **Close Cover:** Gently close the printer cover until it latches securely. Ensure no paper is caught or creased.
4. **Test Print:** Perform a test print to verify correct paper loading and print quality.



Image: A variety of ReceiptRoll products, including different sizes and colors of thermal paper, alongside printer accessories, illustrating the broader product range.

OPERATING INSTRUCTIONS

Once the thermal paper is correctly loaded, operation is managed through your compatible thermal printer. This paper is designed for direct thermal printing, meaning it reacts to heat from the printer's print head to create images and text without the need for ink or toner.

Key Considerations:

- **Print Quality:** Ensure your printer's settings are optimized for thermal paper to achieve clear, crisp prints.
- **Environmental Factors:** Avoid exposing printed receipts to direct sunlight, high heat, or certain chemicals (e.g., plasticizers found in PVC binders) as this can cause the print to fade over time.
- **Paper Feed:** Always ensure the paper feeds smoothly from the roll without resistance to prevent jams or misprints.

MAINTENANCE AND STORAGE

Proper handling and storage of ReceiptRoll thermal paper will extend its shelf life and preserve print quality.

Storage Guidelines:

- **Temperature:** Store in a cool, dry place, ideally between 20°C and 25°C (68°F and 77°F).
- **Humidity:** Maintain relative humidity between 40% and 60%.
- **Light Exposure:** Keep away from direct sunlight and strong fluorescent light. Store in original packaging or opaque containers.
- **Chemicals:** Avoid contact with chemicals such as alcohol, solvents, plasticizers (found in PVC), and adhesives, as these can degrade the thermal coating.

Handling Tips:

- Handle rolls by the edges to avoid transferring oils or dirt to the thermal surface.
- Do not bend or crease the paper excessively before printing.

TROUBLESHOOTING

Most issues related to thermal paper are often linked to improper loading, storage, or printer settings.

| Problem | Possible Cause | Solution |
|------------------------------------|---|--|
| Faded or Light Print | <ul style="list-style-type: none"> Paper loaded incorrectly (non-thermal side facing print head). Low printer heat setting. Print head dirty or worn. Paper exposed to heat/light during storage. | <ul style="list-style-type: none"> Re-load paper with thermal side facing print head. Adjust printer's heat/darkness setting. Clean or replace print head (refer to printer manual). Ensure proper storage conditions. |
| Paper Jams | <ul style="list-style-type: none"> Improperly loaded roll. Paper roll too tight or loose. Debris in paper path. | <ul style="list-style-type: none"> Re-load paper correctly. Ensure roll fits snugly but can rotate freely. Inspect and clear paper path. |
| Print Fades Quickly After Printing | <ul style="list-style-type: none"> Exposure to direct sunlight or high heat. Contact with certain chemicals (e.g., hand sanitizers, plasticizers). | <ul style="list-style-type: none"> Store printed receipts away from light and heat. Avoid contact with degrading chemicals. |

PRODUCT SPECIFICATIONS

| Attribute | Detail |
|------------------------|-------------------------------------|
| Brand | ReceiptRoll |
| Model Number | T20080Z36 |
| Product Type | Thermal Paper Rolls |
| Roll Dimensions | 2 inches (width) x 80 feet (length) |
| Sheet Size (converted) | 2 x 960 inches |
| Paper Weight | 55 Gram (GSM) |

| Attribute | Detail |
|---------------|--|
| Color | White |
| Paper Finish | Smooth |
| Quantity | 36 Rolls per pack |
| Compatibility | Zebra QL220, Zebra IMZ220, and other compatible 2-inch thermal printers. |
| Manufacturer | ReceiptRoll |

WARRANTY AND SUPPORT

Information regarding specific product warranty terms or direct customer support contacts for ReceiptRoll thermal paper is not provided within this manual. For warranty claims or technical assistance, please refer to the original purchase documentation or contact the retailer from whom the product was acquired.

© 2024 ReceiptRoll. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.