TYPE S TOURING ITEMS AC56388

Type S Portable Car Jump Starter Instruction Manual

Model: AC56388

1. Introduction

This manual provides detailed instructions for the safe and effective use of your Type S Portable Car Jump Starter. This device is designed to jump-start 12V vehicles, serve as a portable power bank, and provide emergency lighting. Please read this manual thoroughly before operation and retain it for future reference.

2. Safety Information

WARNING: Improper use can result in injury or damage. Always follow these safety guidelines.

- Ensure the jump starter is fully charged before use.
- Do not attempt to jump-start vehicles with voltage systems other than 12V.
- Avoid short-circuiting the jumper clamps. Do not connect the red and black clamps together.
- Keep the device away from moisture, heat, and flammable materials.
- Do not disassemble or modify the unit. Refer all servicing to qualified personnel.
- Wear eye protection when working with car batteries.
- This jump starter features UL certification (E482421) and advanced protection against reverse polarity, sparks, over-discharge, overheating, and short-circuits.


3. What's in the Box



The image shows the Type S Portable Car Jump Starter unit in blue, along with the red and black jumper cables. This is the main product and its essential accessory for jump-starting vehicles.

- 1 x 12V Jump Starter Power Bank
- 1 x Storage Bag
- 1 x 12V USB Car Charger
- 1 x Micro USB Charging Cable
- 1 x Jumper Cable with Smart & Safe Protection

4. Product Overview



This image highlights the key features of the jump starter: Dual USB-A Ports for charging devices, 350A Peak Current for jump-starting, a Multimode LED Flashlight for illumination, and built-in Safety Features for user protection.

The Type S Portable Car Jump Starter is a multi-functional device featuring:

- **Jump Start Port:** For connecting the smart jumper cables.
- **Dual USB-A Ports:** For charging mobile devices (2.4A + 2.1A).
- **LED Flashlight:** With solid, strobe, and SOS modes.
- **Battery Level Indicator:** Displays the remaining charge.
- **Power Button:** To turn the unit on/off and cycle through flashlight modes.

5. Setup and Charging

5.1 Initial Charge

Before first use, fully charge the jump starter. Connect the Micro USB Charging Cable to the jump starter's input port and

the other end to the 12V USB Car Charger or any standard USB wall adapter (not included). The battery level indicator lights will illuminate during charging and turn solid when fully charged.

5.2 Maintaining Charge

For optimal performance, it is recommended to recharge the jump starter every 3-6 months, even if not used, to maintain battery health.

6. Operating Instructions


6.1 Jump Starting a Vehicle



This image illustrates the Type S Jump Starter connected to a car battery, with the red clamp on the positive terminal and the black clamp on the negative terminal, ready to jump-start the vehicle. It also shows icons for car, SUV, and truck, indicating compatibility.

1. Ensure the jump starter has sufficient charge (at least 3 indicator lights).
2. Connect the smart jumper cable's blue plug into the jump start port on the jump starter.
3. Connect the red (+) clamp to the positive (+) terminal of the vehicle's battery.
4. Connect the black (-) clamp to the negative (-) terminal of the vehicle's battery.
5. Once connected, the indicator light on the smart cable will turn green, indicating a safe connection. If it's red or flashing, check connections or refer to troubleshooting.
6. Start the vehicle's engine.
7. Once the vehicle starts, immediately disconnect the black (-) clamp, then the red (+) clamp, and finally disconnect the smart cable from the jump starter.
8. Do not crank the engine for more than 3 seconds. If the engine does not start, wait at least 30 seconds before attempting again.

6.2 Using as a Power Bank



This image shows the Type S Jump Starter with its dual USB-A ports, indicating its capability to charge compatible devices like phones, tablets, and headphones. A smartphone is shown connected and charging.

The jump starter features two USB-A output ports (2.4A and 2.1A) to charge your electronic devices.

1. Connect your device's USB charging cable to one of the USB-A output ports on the jump starter.
2. The jump starter will automatically begin charging your device.
3. Disconnect your device once charging is complete.

6.3 Using the LED Flashlight



This image displays the Type S Jump Starter with its built-in LED flashlight turned on, illuminating the area in front of it. This highlights its utility as an emergency light source.

The built-in LED flashlight has multiple modes for various situations.

1. Press and hold the power button for 3 seconds to turn on the flashlight (solid mode).
2. Press the power button once more to switch to Strobe mode.
3. Press the power button again to switch to SOS mode.
4. Press and hold the power button for 3 seconds to turn off the flashlight.

7. Maintenance

- Clean the unit with a dry, soft cloth. Do not use abrasive cleaners or solvents.
- Store the jump starter in a cool, dry place, away from direct sunlight and extreme temperatures.
- Ensure the unit is fully charged before storing for extended periods. Recharge every 3-6 months.
- Keep the jumper clamps clean and free of corrosion.

8. Troubleshooting

Problem	Possible Cause	Solution
Jump starter does not turn on.	Battery is depleted.	Charge the jump starter fully.
Vehicle does not start after jump.	Incorrect clamp connection; Vehicle battery too low; Vehicle issue.	Check clamp connections (red to +, black to -). Ensure jump starter is fully charged. If still no start, consult a mechanic.
Smart cable indicator is red/flashing.	Reverse polarity; Short circuit; Over-temperature.	Disconnect clamps and re-connect correctly. Allow unit to cool down if overheated.
Devices not charging via USB.	Jump starter battery low; Cable issue; Device issue.	Charge the jump starter. Try a different USB cable or device.

9. Specifications

Feature	Detail
Model	AC56388
Battery Capacity	8000mAh Lithium-Ion
Peak Output Current	1000 Amps
Amperage	1000 Amps
Vehicle Compatibility	12V systems, up to 6.0L gas engines
USB Output 1	5V / 2.4A
USB Output 2	5V / 2.1A
LED Flashlight Lumens	70 lumens
Certification	UL Certified (E482421)
Dimensions	5.43 x 3.07 x 1.06 inches
Weight	0.36 Kilograms (12.7 ounces)

10. Warranty and Support

TYPE S TOURING ITEMS is committed to providing quality products. For support and warranty information:

- **Extended Warranty:** Register your product online for extended warranty benefits.
- **Customer Care:** Contact our US-based customer care hotline for assistance.
- **Installation Videos:** Visit our YouTube channel for helpful installation and usage videos.
- For further assistance, please refer to the contact information provided with your product packaging or visit the official TYPE S website.

© 2024 TYPE S TOURING ITEMS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question