



[Manuals.plus](#) /

> [Outsunny](#) /

> Outsunny 2-Person Tent Cot, 4-in-1 Folding Tent Combo with Air Mattress, Foot Pump, Carry Bag, Off Ground Travel Cot for Camping, Hiking, Backpacking

Outsunny USA20-0870131

Outsunny 2-Person Tent Cot Instruction Manual

BRAND: OUTSUNNY | MODEL: USA20-0870131

INTRODUCTION

The Outsunny 2-Person Tent Cot is a versatile 4-in-1 folding tent combo designed for comfortable outdoor experiences. This comprehensive set includes a standard tent, a sturdy 2-person cot, a comfortable air mattress with a matching cover, and a convenient foot pump. All components are designed for easy transport and setup, making it ideal for camping, hiking, and backpacking. Its elevated design ensures you stay dry and warm, providing a home-like comfort in the wilderness.



Figure 1: The Outsunny 2-Person Tent Cot fully assembled.

SAFETY INFORMATION

- Always set up the tent cot on a flat, stable surface to prevent tipping.
- Do not use in severe weather conditions, including strong winds or heavy rain, unless additional waterproofing (e.g., a tarp) is applied.
- Ensure all poles and frame components are securely locked in place before use.
- Do not exceed the maximum weight capacity of 352 lbs (160 kg).
- Keep away from open flames and heat sources.
- Supervise children when they are near or inside the tent cot.

COMPONENTS LIST

Before assembly, ensure all the following components are present:

- Folding Cot Frame
- Tent Canopy

- Air Mattress
- Air Mattress Cover (Bedsread)
- Foot Pump
- Tent Poles (Fiberglass)
- Cross Connector for Tent Poles
- Carry Bag with Wheels

SETUP GUIDE

Step 1: Unpacking and Component Check

Remove all items from the carry bag. Lay out all components and verify against the components list. The carry bag itself features wheels for effortless transportation.

THOUGHTFUL DESIGN FOR EASY STORAGE & TRAVEL

Two wheels for effortless transportation



Figure 2: Wheeled carry bag for easy storage and travel.

Step 2: Inflating the Air Mattress

Unfold the air mattress. Connect the air nozzle of the foot pump to the mattress valve. Step on the pedal to inflate the mattress until it is firm. Ensure the valve is securely closed after inflation.



Figure 3: Instructions for inflating the air mattress using the foot pump.

Step 3: Assembling the Cot Frame

Unfold the cot frame completely. Ensure all legs are extended and locked into position. The cot is designed to be sturdy and elevated, keeping you off the ground.



Figure 4: Detail of sturdy steel legs and non-slip feet for stability.

Step 4: Attaching the Air Mattress Cover

Place the inflated air mattress onto the cot frame. Drape the mattress cover over the air mattress, similar to a fitted sheet. Secure the four buckles located on the mattress cover to the corresponding straps on the cot frame. Tighten the straps to ensure the mattress is held firmly in place.



Figure 5: Secure the mattress cover using the integrated buckles.

Step 5: Assembling Tent Poles

Connect the fiberglass tent poles. They are typically strung together with an elastic cord for easy assembly. Ensure all sections are fully inserted and secure. One pole will have a crook on the end for specific attachment.

Step 6: Attaching Tent to Cot Frame

Unfold the tent canopy. Locate the central tie point at the top of the tent and attach the cross connector. Starting from the bottom, feed the tent poles through the sleeves on the tent fabric, guiding them towards the top. Once the poles are through the sleeves, insert the metal tip of each pole into the corresponding hole on the cot frame. Secure the strap around the bottom of each pole to the cot frame for stability.

Your browser does not support the video tag.

Video 1: Official product overview demonstrating the Outsunny A20-087 Camping Tent features and setup process.

Step 7: Final Adjustments

Ensure the tent canopy is properly draped over the air mattress, with the mattress sitting snugly inside the tent. Adjust the tent fabric around the base of the air mattress to ensure a tight fit and prevent drafts or moisture from entering.



Figure 6: Detailed dimensions of the assembled tent cot.

OPERATING INSTRUCTIONS

- **Ventilation:** The tent features two mesh windows and a large zippered door for optimal airflow. Open these for ventilation during warm weather or zip them closed for privacy and protection from elements.
- **Comfort:** The air mattress provides a comfortable sleeping surface. Adjust inflation to your preferred firmness. The elevated cot keeps you away from cold or damp ground.
- **Separate Use:** The tent, cot, and air mattress can be used together as a complete unit or detached and used separately depending on your camping needs.

MAINTENANCE

- **Cleaning:** Hand wash the tent fabric and mattress cover with mild soap and water. Do not machine wash or tumble dry. Allow all components to air dry completely before packing away to prevent mildew.
- **Storage:** Ensure all parts are clean and dry before folding and storing them in the carry bag. Store in a cool, dry place away from direct sunlight.
- **Air Mattress Care:** Avoid over-inflating the air mattress. Keep sharp objects away from the mattress to prevent punctures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Air mattress deflates quickly.	Valve not properly sealed; small puncture.	Ensure valve is fully closed. Check for punctures and use a repair kit if necessary.
Tent leaks during rain.	Heavy rain exceeding water resistance; fabric tear.	This tent is designed for 3-season use and light rain. For heavy rain, use an additional tarp or rainfly. Inspect for tears and repair.
Tent fabric appears torn or damaged.	Rough handling; sharp objects.	Handle with care during setup and takedown. Repair tears with appropriate fabric repair patches.
Difficulty assembling cot frame or poles.	Components not aligned; tension issues.	Ensure all pegs and holes are correctly aligned. Apply firm pressure to create tension, especially for the last poles. Refer to setup steps.

SPECIFICATIONS

Feature	Detail
Product Dimensions (L x W x H)	76" x 57" x 70.75"
Item Weight	45.1 Pounds
Occupancy	2 Person
Seasons	3 Season
Material	Polyester Taffeta, Oxford Fabric, Fiberglass (Poles), Alloy Steel (Cot Frame)
Color	Dark Green
Max Weight Capacity	352 lbs (160 kg)
Water Resistance Technology	190 Inch (Water Resistant)
Assembly Time	Approximately 30 minutes

WARRANTY & SUPPORT

This Outsunny Tent Cot comes with a 1-Year Warranty against Manufacturer Defects. For support, questions, or to claim your warranty, please refer to the contact information provided in your product packaging or visit the official Outsunny website.

