

Festina F16936

Festina F16936/B Women's Analogue Quartz Watch Instruction Manual

Your guide to understanding and maintaining your Festina timepiece.

1. INTRODUCTION

Thank you for choosing a Festina timepiece. This manual provides essential information for the proper setup, operation, and maintenance of your Festina F16936/B Women's Analogue Quartz Watch. Please read these instructions carefully to ensure optimal performance and longevity of your watch.

2. PRODUCT OVERVIEW

The Festina F16936/B is an elegant women's analogue quartz watch featuring a durable stainless steel case and strap. It is designed for everyday wear with a classic aesthetic.



Figure 1: Front view of the Festina F16936/B Women's Analogue Quartz Watch, showcasing its silver dial with rose-colored Roman numerals and zircons, and stainless steel strap.

Key Components:

- **Case:** Circular stainless steel in silver color, 32.5 mm diameter.
- **Dial:** Silver color with rose-colored Roman numerals and zircon embellishments.
- **Crystal:** Mineral glass for durability.
- **Movement:** Reliable quartz movement for accurate timekeeping.
- **Strap:** Stainless steel bracelet with a buckle closure.
- **Crown:** Used for setting the time.
- **Water Resistance:** 5 ATM (50 meters), suitable for short periods of recreational swimming.



Figure 2: Close-up view of the stainless steel buckle clasp on the Festina F16936/B watch strap, featuring the Festina logo.



Figure 3: The elegant pink Festina watch box, designed for storage and presentation of your timepiece.

3. SETUP

3.1 Setting the Time

1. **Pull out the crown:** Gently pull the crown (the small knob on the side of the watch case) out to the first position.
2. **Adjust the time:** Turn the crown clockwise or counter-clockwise to set the hour and minute hands to the correct time.
3. **Push in the crown:** Once the time is set, push the crown back into its normal operating position. Ensure it is fully pushed in to maintain water resistance.

3.2 Strap Adjustment

The stainless steel bracelet of your Festina watch may require adjustment to fit your wrist comfortably. It is recommended to have this adjustment performed by a professional jeweler or watchmaker to avoid damage to the strap or clasp. They can add or remove links as needed.

4. OPERATING INSTRUCTIONS

4.1 Timekeeping

Your Festina F16936/B watch is powered by a precise quartz movement, providing accurate timekeeping. No further action is required for daily operation once the time is set, other than ensuring the crown is fully pushed in.

4.2 Water Resistance

This watch has a water resistance rating of 5 ATM (50 meters). This means it is suitable for short periods of recreational swimming, showering, or washing hands. It is **not** suitable for diving, snorkeling, or prolonged water activities. Always ensure the crown is fully pushed in before any contact with water.

- Do not operate the crown while the watch is wet or submerged.
- Avoid exposing the watch to hot water or steam, as this can compromise the seals.

5. MAINTENANCE

5.1 Cleaning Your Watch

To maintain the appearance of your watch:

- Wipe the case and strap with a soft, dry cloth regularly to remove dust and dirt.
- For stainless steel, a slightly damp cloth can be used, followed by immediate drying.
- Avoid using harsh chemicals, solvents, or abrasive cleaners, as these can damage the watch's finish.

5.2 Battery Replacement

Your quartz watch is powered by a nonstandard battery. When the watch stops running, it indicates that the battery needs to be replaced. It is highly recommended to have the battery replaced by an authorized Festina service center or a qualified watchmaker to ensure proper sealing and maintain water resistance.

5.3 Storage

When not wearing your watch, store it in a cool, dry place, away from direct sunlight, extreme temperatures, and strong magnetic fields. The original watch box (Figure 3) is ideal for storage.

6. TROUBLESHOOTING

- **Watch not running:**
 - Check if the crown is fully pushed in. If it is pulled out, the watch will not run.
 - The battery may be depleted. Refer to Section 5.2 for battery replacement.
- **Condensation under the crystal:**
 - This indicates a potential issue with the watch's water resistance. Seek immediate professional service to prevent further damage to the movement.

For any issues not covered here, please contact Festina customer support or an authorized service center.

7. SPECIFICATIONS

Feature	Detail
Model Number	F16936
Movement Type	Quartz
Display Type	Analog
Case Material	Stainless Steel
Case Diameter	32.5 Millimeters
Case Thickness	7.9 Millimeters
Band Material	Stainless Steel
Band Width	15.35 Millimeters
Crystal Type	Mineral Glass
Water Resistance Depth	50 Meters (5 ATM)
Power Source	Battery Powered (1 Nonstandard Battery)
Item Weight	66 Grams
Closure Type	Buckle
Dial Color	Silver
Band Color	Silver

8. WARRANTY AND SUPPORT

Your Festina watch is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details. Keep your proof of purchase for warranty claims.

For technical support, service, or warranty inquiries, please contact your authorized Festina dealer or visit the official Festina website for customer service contact information.