



[Manuals.plus](#) /

› [InnovaGoods](#) /

› InnovaGoods Fresh Microwave Double Steamer User Manual

InnovaGoods IG814038

InnovaGoods Fresh Microwave Double Steamer User Manual

Model: IG814038

1. INTRODUCTION

Thank you for choosing the InnovaGoods Fresh Microwave Double Steamer. This manual provides essential information for the safe and efficient use, maintenance, and care of your new appliance. Please read these instructions thoroughly before first use and retain them for future reference.

2. PRODUCT OVERVIEW AND COMPONENTS

The InnovaGoods Fresh Microwave Double Steamer is designed for convenient and healthy cooking in a microwave oven. It features a modular design allowing for single or double compartment use.



Figure 2.1: Assembled InnovaGoods Fresh Microwave Double Steamer.

Components:

- **Lid:** Transparent lid with steam release vents.
- **Upper Steaming Compartment:** Perforated base for steaming.
- **Lower Steaming Compartment:** Perforated base for steaming.
- **Base/Water Reservoir:** Collects water and can be used as a single steaming compartment with the lid.



Figure 2.2: Exploded view showing the lid, two steaming compartments, and base.

3. SAFETY INSTRUCTIONS

- Always ensure the steamer is suitable for your microwave oven's size and power.
- Do not use the steamer in a conventional oven, on a stovetop, or under a grill.
- Exercise caution when removing the steamer from the microwave, as it will be hot. Use oven mitts or heat-resistant gloves.
- Be careful when removing the lid, as hot steam will escape. Always open the lid away from your face.
- Ensure there is always sufficient water in the base when steaming to prevent damage to the steamer or microwave.
- Do not overheat food.
- Keep out of reach of children.
- The product is made of Polypropylene, which is generally safe for microwave use. However, avoid using abrasive cleaners or sharp objects that could damage the material.

4. SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Initial Cleaning:** Before first use, wash all parts of the steamer with warm soapy water and rinse thoroughly. Dry completely.
3. **Assembly:** The steamer can be assembled with one or two compartments.
 - **Single Compartment Use:** Place food in the base or one of the steaming compartments. If using a steaming compartment, place it directly on the base. Cover with the lid.
 - **Double Compartment Use:** Place food in the lower steaming compartment, then place it on the base. Place food in the upper steaming compartment, then stack it on top of the lower compartment. Cover with the lid.

5. OPERATING INSTRUCTIONS

Follow these steps to steam food using your InnovaGoods Microwave Double Steamer:

1. **Add Water:** Pour a small amount of water (approximately 1-2 cm deep) into the base of the steamer. This water will create the steam.
2. **Prepare Food:** Place your desired food items (e.g., vegetables, fish, poultry) into the steaming compartments. Ensure food is cut into similar-sized pieces for even cooking.
3. **Assemble Steamer:** Stack the compartments as desired (one or two) onto the base. Place the lid securely on top.
4. **Microwave:** Place the assembled steamer into your microwave oven.
5. **Set Cooking Time:** Refer to general microwave steaming guidelines for your specific food type. Cooking times will vary based on food quantity, type, and microwave power. Start with shorter times and add more if needed.
 - For vegetables, typical steaming times range from 3-8 minutes.
 - For fish fillets, typical steaming times range from 4-7 minutes.
6. **Monitor:** The transparent lid allows you to observe the steaming process.
7. **Remove:** Once cooking is complete, carefully remove the hot steamer from the microwave using oven mitts.
8. **Serve:** Carefully remove the lid, directing steam away from your face. Serve the steamed food immediately.



Figure 5.1: Steamer in use, demonstrating its capacity for various foods.



Figure 5.2: Steamer compartments with prepared food.

6. MAINTENANCE AND CLEANING

Proper cleaning and maintenance will extend the life of your steamer.

- **Dishwasher Safe:** All components of the InnovaGoods Fresh Microwave Double Steamer are dishwasher safe. Place them on the top rack for best results.
- **Hand Washing:** If washing by hand, use warm soapy water and a soft sponge or cloth. Rinse thoroughly and dry completely before storing.
- **Avoid Abrasives:** Do not use abrasive cleaners, scouring pads, or sharp utensils, as these can scratch or damage the plastic.
- **Stains:** For stubborn food stains, a mixture of baking soda and water can be used as a gentle scrub.
- **Storage:** Store the steamer in a clean, dry place when not in use.



Figure 6.1: Steamer components are suitable for dishwasher cleaning.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Food not cooking evenly or thoroughly.	Insufficient cooking time; too much food; food pieces are too large or unevenly cut; not enough water in the base.	Increase cooking time; reduce food quantity; cut food into smaller, uniform pieces; ensure adequate water in the base.
Steamer appears warped or damaged.	Overheating; prolonged exposure to high microwave power without sufficient water.	Ensure water is always present in the base during steaming. Do not exceed recommended microwave cooking times. Replace if significantly damaged.
Steam escaping excessively from lid.	Lid not properly seated; steam vents are blocked.	Ensure the lid is securely placed on the top compartment. Check that steam vents are clear.

8. SPECIFICATIONS

- **Brand:** InnovaGoods
- **Model Number:** IG814038
- **Material:** Polypropylene
- **Color:** Green
- **Product Dimensions (L x W x H):** 8.66" x 8.66" x 4.72" (22 cm x 22 cm x 12 cm)
- **Item Weight:** 9.9 ounces (280 grams)
- **Capacity:** Approximately 22.5 Liters (Note: This capacity seems unusually high for a steamer of these dimensions. It might refer to the total volume of the product, not usable cooking capacity.)

- **GTIN:** 08435527814038



Figure 8.1: Product dimensions illustration.

9. WARRANTY AND SUPPORT

This product is covered by the standard warranty provided by the manufacturer or seller at the point of purchase. For specific warranty details, please refer to your purchase documentation or contact the retailer where the product was acquired.

For technical support or inquiries regarding your InnovaGoods Fresh Microwave Double Steamer, please contact the customer service department of InnovaGoods or your product retailer. Please note that international products may have separate terms and conditions, and may differ from local products in terms of fit, age ratings, and language of product, labeling, or instructions.