

Best Choice Products SKY7174

Best Choice Products 61-Key Electronic Keyboard Piano User Manual

Model: SKY7174

INTRODUCTION

This manual provides essential information for the setup, operation, maintenance, and troubleshooting of your Best Choice Products 61-Key Electronic Keyboard Piano. Please read this manual thoroughly before using the product to ensure proper function and longevity.



Image: The 61-Key Electronic Keyboard Piano set, including the keyboard, stand, bench, headphones, and microphone.

WHAT'S INCLUDED

Verify that all components are present in the package:

- 1 x 61-Key Electronic Keyboard
- 1 x H-style Keyboard Stand
- 1 x Music Stand (Holder)
- 1 x Power Adapter
- 1 x Padded Stool (Bench)
- 1 x Headphones
- 1 x Microphone
- LED Screen (integrated)

- Recorder with Playback function (integrated)

What's Included




x1 Keyboard



x1 Headphone



x1 Holder



x1 Stand



x1 Microphone



x1 Chair

Image: All components of the Best Choice Products 61-Key Electronic Keyboard Piano set, laid out for identification.

SETUP

1. Assembling the Keyboard Stand and Stool

Follow the instructions provided with the stand and stool for proper assembly. Ensure all screws are tightened securely for stability. The stool is adjustable to three heights for user comfort.

2. Placing the Keyboard

Carefully place the 61-key electronic keyboard onto the assembled H-style stand. Ensure it is stable and centered.

3. Connecting Power

Connect the provided power adapter to the keyboard's power input jack and then to a standard electrical outlet.

4. Connecting Accessories

- **Headphones:** Plug the headphones into the 3.5mm headphone jack on the keyboard. This allows for private practice.
- **Microphone:** Plug the microphone into the designated microphone input jack.
- **USB Devices:** The keyboard supports USB connectivity for playing songs stored on a USB device.

Product Dimensions



Image: Detailed product dimensions for the keyboard, stand, and stool.

OPERATING INSTRUCTIONS

Powering On/Off

Press the **POWER** button to turn the keyboard on or off. The LED screen will illuminate upon power-on.

3-Step Intelligent Teaching Modes

This keyboard features three intelligent teaching modes designed to assist beginners:

- **One-Key:** Allows you to play along with a demo song by pressing any key. The correct note will sound regardless of which key is pressed.
- **Follow:** The keyboard waits for you to play the correct note before proceeding with the demo song.
- **Ensemble:** The keyboard plays the accompaniment, and you play the melody.

3 Teaching Modes

Follow along with 3-step intelligent teaching with modes like One-Follow, Follow, and Ensemble



Image: The control panel highlighting the "3 Teaching Modes" section.

Customizing Sound

Explore the various sound options to enhance your musical creations:

- **Timbre Options:** Select from 255 different timbre options to change the instrument sound.
- **Rhythms:** Choose from 255 rhythms to accompany your melodies.
- **Percussion Sounds:** Access 32 percussion sounds for rhythmic accents.
- **Demo Songs:** Play along with 24 built-in demo songs.

Customize Your Sound

Create your own full masterpiece when you mix timbres and rhythms or explore the keyboard percussion sounds



255
Timbres



255
Rhythms



24
Demo
Songs



32
Percussions
Sounds



Image: The control panel displaying options for timbre, rhythm, and demo songs.

Recording and Playback

Use the integrated recorder to capture your performances and play them back. Refer to the detailed instruction manual for specific steps on recording and playback functions.

Using Headphones and Microphone

The included headphones allow for quiet practice without disturbing others. The microphone enables singing along with your playing or recorded tracks.

Immersive Accessories

Kids can listen and sing along to their favorite music



Padded Earphones



Microphone



Image: Padded headphones and microphone, highlighting the immersive accessory experience.

MAINTENANCE

- Keep the keyboard clean by wiping it with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- Protect the keyboard from direct sunlight, extreme temperatures, and high humidity.
- When not in use, cover the keyboard to prevent dust accumulation.
- Ensure all cables are unplugged and stored properly when moving or storing the keyboard for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No sound from speakers/headphones.	Power not connected, volume too low, headphones not fully plugged in.	Check power connection. Increase Master Volume. Ensure headphones are fully inserted.
Keyboard does not power on.	Power adapter not connected, power outlet issue.	Verify power adapter connection to keyboard and outlet. Try a different outlet.
Keys are not responding.	Keyboard may be in a specific teaching mode or a setting is preventing sound.	Ensure the keyboard is not in a mode that mutes keys (e.g., certain teaching modes). Power cycle the unit.


SPECIFICATIONS

Feature	Detail
Model Name	61-Key Beginners Electronic Keyboard Piano Set w/ Lighted Keys
Model Number	SKY7174
Number of Keys	61
Product Dimensions (Keyboard)	33"D x 10.5"W x 3"H
Item Weight	17.2 Pounds
Connectivity Technology	USB
Headphones Jack	3.5mm Jack
Teaching Modes	One-Key, Follow, Ensemble
Timbre Options	255
Rhythms	255
Percussion Sounds	32
Demo Songs	24
Color	Black
Material Type	Specialty Plastic

WARRANTY AND SUPPORT

For warranty information, product registration, or technical support, please refer to the warranty card included with your product or visit the official Best Choice Products website. Keep your purchase receipt for warranty claims.





[61-Key Electronic Teaching Keyboard Instruction Manual](#)

Comprehensive instruction manual for the 61-Key Electronic Teaching Keyboard by Best Choice Products. Learn about assembly, features, functions, and basic operation.

lang:en score:36 filesize: 438.93 K page_count: 16 document date: 2023-08-30