

## MARATHON TI030018WH

# MARATHON 100 Hour Direct Entry Digital Tabletop Timer

MODEL: TI030018WH

Brand: MARATHON

## 1. Introduction

The MARATHON 100 Hour Direct Entry Digital Tabletop Timer is designed to assist with precise time management for various tasks. Featuring a large, easy-to-read LCD display and a direct entry keypad, this timer offers both countdown and count-up functionalities, a clock mode, and memory presets for repetitive events. Its robust design includes a magnetic back and an integrated kickstand for versatile placement.

## 2. Product Overview



Figure 1: Front view of the Marathon Digital Timer.




Figure 2: Timer on a kitchen counter, highlighting large display and loud alarm.



Figure 3: Timer showcasing dual function, included batteries, and versatile memory.

## Key Features:

- **Direct Entry Keypad:** For quick and precise time setting.
- **Large LCD Display:** Easy-to-read numbers for clear visibility.
- **Dual Function Alarm:** Supports both countdown and count-up timing up to 99 hours, 59 minutes, and 59 seconds.
- **Loud Ring Alarm:** Audible across a room.
- **LED Indicator:** Flashing light for silent alarm or hearing impairment assistance.
- **Clock Feature:** Displays time in 12-hour or 24-hour format when not in timer mode.
- **Built-in Memory Function:** Stores up to four consecutive times for interval timing and four memory presets for repetitive events.
- **Versatile Placement:** Integrated kickstand for tabletop use and magnetic back for attachment to metal surfaces.
- **Batteries Included:** Comes with 2 AA batteries.

## 3. Setup

---

### 3.1. Battery Installation

1. Locate the battery compartment cover on the back of the timer.
2. Slide the cover open.
3. Insert two (2) AA batteries, ensuring correct polarity (+/-) as indicated inside the compartment. The timer comes with batteries included.
4. Replace the battery compartment cover securely.



In 1939, Morris Wein founded Marathon Watch and since 1941, Marathon has been manufacturing timing instruments for the Allied Forces. Today the fourth generation of the family continues the tradition with a wide range of instruments measuring time, temperature and distance.

Figure 4: Back view with battery compartment and kickstand.

## 4. Operating Instructions

---

### 4.1. Mode Selection

Use the **MODE** switch located on the side of the timer to select between different functions:

- **CLOCK:** Displays the current time.
- **INTERVAL TIMER:** For setting multiple consecutive timers.
- **COUNT-UP:** Functions as a stopwatch.
- **TIMER:** For setting a single countdown timer.




Figure 5: MODE switch for function selection.

### 4.2. Setting the Clock

1. Slide the **MODE** switch to **CLOCK**.
2. Press and hold the **SET** button until the time digits begin to flash.
3. Use the number keypad (0-9) to enter the desired time (HH:MM).
4. Press **SET** again to confirm and exit clock setting mode.
5. To switch between 12-hour and 24-hour format, press the **12/24H** button (if available, or refer to specific model instructions).

### 4.3. Setting a Countdown Timer (TIMER Mode)

1. Slide the **MODE** switch to **TIMER**.
2. Use the number keypad (0-9) to directly enter the desired countdown time (HH:MM:SS). The timer supports up to 99 hours, 59 minutes, 59 seconds.

3. Press the **START/STOP** button to begin the countdown.
4. To pause the timer, press **START/STOP** again. Press it once more to resume.
5. When the countdown reaches zero, the alarm will sound, and the LED indicator will flash. The timer will then automatically begin counting up to show elapsed time since the alarm.
6. To stop the alarm and clear the display, press the **CLEAR** button.

4.4. Using the Count-Up Timer (COUNT-UP Mode)

1. Slide the **MODE** switch to **COUNT-UP**.
2. Ensure the display shows 00:00:00. If not, press **CLEAR**.
3. Press the **START/STOP** button to begin counting up.
4. To pause the count-up, press **START/STOP** again. Press it once more to resume.
5. To reset the count-up timer to zero, press **CLEAR**.

4.5. Using Memory Functions (M1-M4 Presets)

The timer features four memory buttons (M1, M2, M3, M4) for storing and recalling frequently used times or for interval timing.

1. In **TIMER** mode, enter the desired time using the number keypad.
2. Press and hold one of the memory buttons (M1-M4) until the display confirms the time has been saved.
3. To recall a saved time, simply press the corresponding memory button (M1-M4). The saved time will appear on the display, ready to start.
4. For interval timing, set the first interval, save it to M1. Then set the second interval, save it to M2, and so on. You can then cycle through these presets as needed.

4.6. Adjusting Alarm Volume

The timer features a volume switch, typically located on the side or back, allowing you to select between different alarm levels (e.g., High, Low, Mute) or a flashing LED indicator for silent operation.

5. Maintenance

- Clean the timer with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.
- Avoid exposing the timer to extreme temperatures or direct sunlight for prolonged periods.
- If the display becomes dim or the alarm weakens, replace the batteries promptly.

6. Troubleshooting

Problem	Possible Cause	Solution
Timer not turning on.	Batteries are dead or incorrectly installed.	Check battery polarity or replace with new AA batteries.
Display is dim.	Low battery power.	Replace batteries.
Alarm is not sounding.	Alarm volume is set to mute or low.	Check the alarm volume switch and adjust as needed.

Problem	Possible Cause	Solution
Timer not responding to button presses.	Unit may be in a locked state (if applicable) or requires a reset.	Remove and reinsert batteries to perform a hard reset. Check for any lock switches.

## 7. Specifications

- **Model:** TI030018WH
- **Brand:** MARATHON
- **Material:** Plastic
- **Dimensions:** 4.45 x 2.64 x 4.45 inches
- **Item Weight:** 7.1 ounces
- **Power Source:** 2 x AA batteries (included)
- **Max Timer Duration:** 99 hours, 59 minutes, 59 seconds
- **Features:** Direct Entry, Dual Function (Count-up/Count-down), Clock, Memory Presets, LED Indicator, Magnetic Back, Kickstand
- **UPC:** 063442000342






Figure 6: Product dimensions.

## 8. Warranty and Support

For warranty information or technical support, please refer to the manufacturer's official website or contact their customer service department. Keep your purchase receipt as proof of purchase.

© 2024 MARATHON. All rights reserved.

### Related Documents - TI030018WH

	<p><a href="#">Marathon 24 Hour Compact Digital Countdown Timer with Count-Up &amp; Clock Feature</a></p> <p>Operating instructions and features for the Marathon 24 Hour Compact Digital Countdown Timer, including setting the clock, timer, and count-up functions. Details on time format, preset times, and warnings.</p>
	<p><a href="#">Marathon CL030049 Wall/Desk Alarm Clock User Manual</a></p> <p>Comprehensive user manual for the Marathon CL030049 digital wall and desk alarm clock. Covers features like calendar, temperature display, dual alarms, snooze, countdown timer, and language settings. Includes operation instructions, precautions, and warranty information.</p>
	<p><a href="#">Marathon TI030018 100-Hour Digital Countdown Timer User Manual</a></p> <p>Comprehensive user manual for the Marathon TI030018 100-Hour Keypad Digital Countdown Timer, covering its features, operation modes (Clock, Interval Timer, Count Up, Timer), unit appearance, button functions, battery replacement, precautions, and technical specifications.</p>



[Marathon Wall Clock with Moon Phase User Manual](#)

User manual for the Marathon Wall Clock with Moon Phase, detailing setup, features like alarms, temperature, moon phases, and multilingual support. Includes operating instructions and precautions.



[Marathon Hotel Collection LED Alarm Clock with USB Charger User Manual](#)

Comprehensive user manual for the Marathon Hotel Collection LED Alarm Clock (Model CL030070), detailing installation, time/alarm settings, USB charging, troubleshooting, and product care.



[Marathon T1080001 Large Digital Timer: User Manual and Operating Instructions](#)

Comprehensive user manual for the Marathon T1080001 Large Digital Timer. Learn how to set the clock, use the timer functions (countdown, countup), manage memory presets, and understand its features. Includes product specifications and operating instructions in English.