

Mattel GGL47

Mattel Disney Cars Race Around Radiator Springs Playset

Model: GGL47

Brand: Mattel

INTRODUCTION

Welcome to the exciting world of Disney Pixar's Cars with the Race Around Radiator Springs Playset! This playset allows you to recreate thrilling races and adventures in Lightning McQueen's hometown. Featuring iconic locations like the Cozy Cone tunnel, Ramone's, and Flo's V8 Cafe, this set is designed for interactive play. It includes a 1:55 scale plastic Lightning McQueen vehicle to get the fun started immediately. Expand your racing world by connecting other die-cast cars (sold separately) for competitive play.




Image: The complete Race Around Radiator Springs Playset, showcasing the figure-8 track layout and various iconic buildings.

SAFETY INFORMATION

WARNING: CHOKING HAZARD—Small parts. Not for children under 3 yrs.

Recommended for ages 4 and above.

WHAT'S IN THE BOX

- 1 x Race Around Radiator Springs Playset (unassembled)
- 1 x 1:55 scale plastic Lightning McQueen vehicle

SETUP INSTRUCTIONS

1. **Unpack Components:** Carefully remove all parts from the packaging. Identify the track pieces, buildings (Cozy Cone, Ramone's, Flo's V8 Cafe), and accessories.
2. **Assemble the Track:** Connect the track pieces to form the figure-8 layout as shown in the diagram. Ensure all connections are secure.

3. **Place Buildings:** Position the Cozy Cone tunnel, Ramone's garage, and Flo's V8 Cafe in their designated spots along the track.
4. **Install Batteries:** The playset requires 4 D batteries (not included) for the motorized booster. Locate the battery compartment, insert the batteries according to polarity, and secure the cover.
5. **Apply Stickers:** Apply any included decorative stickers to the playset components as per the visual guide on the packaging or included instructions.



ONE VEHICLE INCLUDED. OTHERS SHOWN SOLD SEPARATELY.

Image: The fully assembled playset, ready for action, with various Cars characters positioned around the track and buildings.

Setup Demonstration Video

Your browser does not support the video tag.

Video: A demonstration of the Cars Radiator Springs Trackset, showing key features and assembly.

OPERATING INSTRUCTIONS

1. **Start Your Engine:** Place the included Lightning McQueen vehicle (or other compatible 1:55 scale die-cast cars) at the starting point of the track.
2. **Activate Speed Boost:** Push the button or lever near the Cozy Cone tunnel to activate the motorized booster, sending your car speeding around the track.



Image: Close-up of a hand pressing the activation button for the speed boost feature on the track.

3. **Visit Ramone's:** Guide your car onto Ramone's rotating car lift for a 'custom look'.



Image: Lightning McQueen positioned on the rotating car lift at Ramone's garage, ready for a 'customization'.

4. **Fuel Up at Flo's:** Stop by Flo's V8 Cafe for a 'fill up' before continuing the race.



Image: Lightning McQueen is shown at the gas pumps of Flo's V8 Cafe, simulating a pit stop.

5. **Navigate Diverters:** Use the track diverters to switch between the inside and outside tracks, adding dynamic elements to your race.
6. **Expand Play:** Connect other compatible Disney Pixar Cars playsets (sold separately) to create an even larger Radiator Springs world.

360-Degree View Video

Your browser does not support the video tag.

Video: A 360-degree view of the Cars Radiator Springs Trackset, highlighting its various features and interactive elements.

MAINTENANCE

- **Cleaning:** Wipe down the playset with a damp cloth as needed. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, disassemble the playset and store it in its original packaging or a suitable container to prevent damage and loss of small parts.
- **Battery Care:** Remove batteries if the toy will not be used for an extended period to prevent leakage.

TROUBLESHOOTING

- **Car Not Moving:** Ensure the motorized booster has fresh batteries and is correctly installed. Check that the car is properly placed on the track.
- **Track Disconnecting:** Verify that all track pieces are securely snapped together.
- **Playset Stability:** Ensure the playset is assembled on a flat, stable surface.

SPECIFICATIONS

Feature	Detail
Product Dimensions	22 x 4.25 x 15 inches
Item Weight	4.4 pounds
Item Model Number	GGL47
Manufacturer Recommended Age	4 - 10 years
Batteries Required	4 D batteries (not included)
Manufacturer	Mattel

WARRANTY & SUPPORT

For warranty information or customer support, please refer to the contact details provided on the product packaging or visit the official Mattel website.