

BFT Mitto 2 B RCB02 R1 D111904

User Manual for BFT Mitto 2 B RCB02 R1 Remote Control

Model: D111904 | Frequency: 433.92 MHz

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your BFT Mitto 2 B RCB02 R1 remote control. Designed for garage and gate opener systems, this remote operates at a frequency of 433.92 MHz and offers reliable control. Please read this manual carefully before use to ensure proper functionality and longevity of your device.



Image: Three BFT Mitto 2 B RCB02 R1 remote controls. These compact, black remote controls feature two grey buttons and a prominent red BFT logo. They are designed for controlling garage doors and gates.

SETUP

1. Battery Installation

Your BFT Mitto 2 B RCB02 R1 remote control requires a 12V battery. While the remote typically comes with a battery pre-installed, follow these steps if replacement is needed:

1. Locate the battery compartment on the back of the remote control.
2. Carefully open the compartment using a small screwdriver or coin if necessary.
3. Insert the 12V battery, ensuring the correct polarity (+ and -) as indicated inside the compartment.

4. Close the battery compartment securely.

2. Programming the Remote Control

The BFT Mitto 2 B RCB02 R1 remote control is programmed directly with your gate or garage opener receiver. The exact programming procedure may vary depending on your specific receiver model. Refer to your receiver's instruction manual for detailed steps. Generally, the process involves:

- Accessing the programming mode on your receiver (often by pressing a "Learn" or "Program" button).
- Pressing a button on your new BFT remote control within a specified timeframe to pair it with the receiver.
- Confirming successful pairing (e.g., an LED on the receiver flashes or changes color).

Note: If you are replacing an existing remote, some receivers may require you to clear all existing codes before programming new ones. Consult your receiver's manual for this procedure.

OPERATING INSTRUCTIONS

Once programmed, operating your BFT Mitto 2 B RCB02 R1 remote control is straightforward:

- **Opening/Closing:** Press the programmed button on the remote control once to activate your gate or garage opener. Pressing it again will typically stop or reverse the operation, depending on your system's configuration.
- **Range:** Ensure you are within effective operating range of your receiver. Obstructions like walls or large vehicles can reduce the signal range.
- **Multiple Remotes:** If you have multiple remotes, each must be programmed individually to the receiver.

MAINTENANCE

To ensure optimal performance and extend the lifespan of your remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- **Battery Replacement:** If the remote's range decreases significantly or the indicator light (if present) becomes dim, it may be time to replace the 12V battery.
- **Storage:** Store the remote in a dry place, away from extreme temperatures and direct sunlight. Avoid dropping the remote or exposing it to water.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote not working.	Dead or low battery.	Replace the 12V battery.
Remote not working.	Not programmed correctly.	Re-program the remote control to the receiver following the receiver's instructions.
Reduced operating range.	Low battery.	Replace the 12V battery.
Reduced operating range.	Interference or obstructions.	Ensure clear line of sight to the receiver. Remove any large metallic objects or other sources of radio interference.

Problem	Possible Cause	Solution
Remote works intermittently.	Loose battery connection.	Check battery compartment for secure fit.

SPECIFICATIONS

- **Model:** BFT Mitto 2 B RCB02 R1 (D111904)
- **Frequency:** 433.92 MHz
- **Number of Buttons:** 2
- **Battery Type:** 12V (e.g., 23A or A23)
- **Compatibility:** BFT gate/garage opener receivers operating at 433.92 MHz with rolling code technology.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your original purchase or contact the retailer/manufacturer directly. Keep your proof of purchase for warranty claims.

© 2024 BFT. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

