**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**bruder 62506**

# Bruder bworld Horse Stable Set 62506 Instruction Manual

## Introduction

This instruction manual provides detailed guidance for the assembly, operation, and maintenance of your Bruder bworld Horse Stable Set, model 62506. The set is designed to offer a realistic play environment for activities such as riding, feeding, grooming, and stable cleaning. It includes various accessories and can be combined with other bworld theme sets for expanded play.

## Safety Information

- **WARNING:** Not suitable for children under 3 years due to small parts which may present a choking hazard.
- Adult supervision is recommended during play.
- Keep all packaging materials away from children.

## Package Contents

Please ensure all the following components are present in your set:

- Stable background elements (double-sided printed) with adjustable feet
- Pivoting door for the horse box
- Wall shelf with shelves and supports
- 1 Horse figure
- 1 Rider figure with helmet and whip
- Stable equipment: 1 shovel, 1 fork, 1 bucket, 1 cleaning kit
- Riding equipment: 1 saddle, 1 bridle, 4 leg wraps

## Setup

Follow these steps to assemble your bworld Horse Stable Set:

1. **Assemble Background Elements:** Connect the double-sided printed background elements using the

adjustable feet to form the stable walls. Ensure they are stable and upright.

2. **Install Horse Box:** Attach the horse box with its pivoting door to the designated section of the stable walls.
3. **Mount Wall Shelf:** Secure the wall shelf with its shelves and supports to the stable wall. This provides storage for accessories.
4. **Arrange Accessories:** Place the stable equipment (shovel, fork, bucket, cleaning kit) and riding equipment (saddle, bridle, leg wraps) in their appropriate locations within the stable or on the wall shelf.
5. **Position Figures:** Place the horse and rider figures in the stable as desired.

Image 1: Assembled stable set with a black horse and rider, showcasing the stable walls and outdoor elements.

Image 2: Assembled stable set with a white horse and rider, showcasing the stable walls and outdoor elements.

## Operating Instructions

The bworld Horse Stable Set allows for various interactive play scenarios:

- **Riding:** Place the saddle and bridle on the horse. Position the rider figure on the horse, holding the whip.

- **Grooming:** Use the cleaning kit accessories to simulate grooming the horse.
- **Feeding:** Use the bucket to simulate feeding the horse.
- **Stable Cleaning:** Utilize the shovel and fork to simulate cleaning the stable area. The pivoting door allows for easy access to the horse box.

Image 3: Rider figure grooming a black horse inside the stable, with various stable tools organized on the wall.

Image 4: Rider figure grooming a white horse inside the stable, with various stable tools organized on the wall.

Image 5: Rider figure cleaning the stable with a shovel and fork, demonstrating stable maintenance.

## Maintenance

To ensure the longevity and cleanliness of your Bruder bworld Horse Stable Set:

- **Cleaning:** Wipe all plastic components with a damp cloth and mild soap if necessary. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the set in a clean, dry place away from direct sunlight to prevent material degradation and color fading.
- **Inspection:** Periodically check for any damaged or broken parts. Replace any damaged components to maintain safety and play quality.

## Troubleshooting

This product is designed for durability and ease of use. Should you encounter any issues, please consider the following:

- **Assembly Difficulties:** Refer back to the 'Setup' section and ensure all pieces are correctly oriented and connected. The background elements are designed to fit together securely.
- **Missing Parts:** If any components are missing upon unboxing, please contact the retailer or manufacturer's customer support.
- **General Wear and Tear:** Over time, plastic parts may show signs of use. Regular cleaning and proper storage can help minimize this.

## Specifications

| | |
|---|---|
| **Model Number** | 62506 |
| **Brand** | Bruder |
| **Dimensions (L x W x H)** | 22.5 x 7.5 x 16.5 cm (8.86 x 2.95 x 6.5 inches) |
| **Weight** | 361 Grams (0.79 lbs) |

| | |
|---|---|
| **Material** | Plastic |
| **Recommended Age** | 3-99 years |
| **Components Included** | Figures and accessories |
| **Theme** | Sport |

## Warranty and Support

Information regarding product warranty and customer support is not available in the provided product details. Please refer to the product packaging or the manufacturer's official website for specific warranty terms and contact information for support.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question