



[Manuals.plus](#) /

> [WowWee](#) /

> WowWee Fingerlings Hugs Rachel Interactive Plush Narwhal Instruction Manual

WowWee 3691

WowWee Fingerlings Hugs Rachel Interactive Plush Narwhal Instruction Manual

Model: 3691

[Introduction](#) [What's in the Box](#) [Setup](#) [Operating Instructions](#) [Care & Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

The WowWee Fingerlings Hugs Rachel is an interactive plush narwhal designed for affectionate play. This plush toy features a light-up horn and responds to various interactions, including sound repetition, swinging, shaking, and tickling. Its long fins allow for hugging, and it includes Kiss Tech for interactive kissing sounds.



Image: The Rachel interactive plush narwhal, featuring its pink glitter body and light-up horn.

2. WHAT'S IN THE BOX

- One (1) WowWee Fingerlings Hugs Rachel Interactive Plush Narwhal
- Two (2) AAA batteries (pre-installed)

3. SETUP

3.1 Battery Installation

Your Fingerlings Hugs Rachel comes with two AAA batteries pre-installed. If replacement is needed:

1. Locate the battery compartment on the back or underside of the plush toy.
2. Using a small Phillips head screwdriver, open the battery compartment cover.
3. Remove the old batteries and insert two new AAA batteries, ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.

Note: Always use fresh batteries of the same type. Do not mix old and new batteries or different types of batteries.

4. OPERATING INSTRUCTIONS

The Fingerlings Hugs Rachel offers various interactive modes and responses:

4.1 Basic Interactions

- **Hugs:** Wrap the narwhal's long fins around your neck or arm. The Velcro on the fins allows them to connect, simulating a hug.
- **Kisses (Kiss Tech):** Press the narwhal's mouth against your cheek. It will make kissing sounds. The longer you hold it, the longer the kiss lasts.
- **Light-Up Horn:** The narwhal's horn lights up in different colors to indicate its mood or during certain interactions.

4.2 Advanced Play Modes

- **Sound Repetition:** Press and hold the narwhal's tail, speak a message, then release. It will repeat your message in a funny voice.
- **Swinging:** Gently swing the narwhal to elicit playful sounds and reactions.
- **Shaking:** Shake the narwhal for different interactive sounds.
- **Tickling:** Place the narwhal on a flat surface and gently tickle its belly to make it giggle.
- **Sleeping Mode:** Cradle and rock the narwhal in your arms, or lay it down, and its eyes may close as it makes sleepy sounds and snores.
- **Upside Down Reactions:** Turn the narwhal upside down for unique pet sounds and interactions, including a "raspberry kiss" if its mouth is pressed against your skin while inverted.

Your browser does not support the video tag.

Video: Official demonstration of the WowWee Fingerlings Hugs Rachel interactive plush narwhal features.

5. CARE AND MAINTENANCE

- **Cleaning:** The plush narwhal cannot be machine washed due to internal electronic components. Surface clean only with a damp cloth and mild soap. Allow to air dry completely.
- **Storage:** Store the toy in a clean, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** Remove batteries if the toy will not be used for an extended period to prevent leakage.
- **Handling:** Avoid excessive force or rough handling, especially on the horn, as this may damage internal components or the light-up feature.



Image: A child demonstrating a hug with the Fingerlings Hugs Rachel narwhal.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Toy does not turn on or respond.	Low or dead batteries; incorrect battery installation.	Replace batteries with fresh AAA batteries, ensuring correct polarity.
Horn light is not working.	Battery issue; physical damage to the horn.	Check/replace batteries. Avoid rough handling of the horn.
Sound repetition feature is not working correctly.	Microphone obstruction; environmental noise; incorrect activation.	Ensure no obstruction near the microphone. Speak clearly and hold the tail as instructed. Try in a quieter environment.
Toy is not making sounds or interactions.	Battery issue; sensor obstruction; toy in sleep mode.	Check/replace batteries. Ensure sensors are clean and unobstructed. Interact with the toy (e.g., shake it) to wake it from sleep mode.

7. SPECIFICATIONS

- **Brand:** WowWee
- **Model Name:** Fingerlings Hugs Rachel
- **Model Number:** 3691
- **Item Type:** Interactive Plush Narwhal
- **Color:** Pink Glitter
- **Material:** Polyester
- **Item Dimensions (L x W x H):** 7.91" x 11.3" x 13.98"
- **Item Weight:** 1.76 Pounds
- **Power Source:** 2 x AAA Batteries (included)
- **Manufacturer Minimum Age:** 24 Months
- **GTIN/UPC:** 771171136910

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the official WowWee website or contact their customer service department. Keep your purchase receipt as proof of purchase.

Website: www.wowwee.com