

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Stanley](#) /
- › [Stanley 37204 Wireless Light Switch Remote System User Manual](#)

Stanley 37204

Stanley 37204 Wireless Light Switch Remote System User Manual

Model: 37204

INTRODUCTION

This manual provides essential instructions for the safe and efficient use of your Stanley 37204 Wireless Light Switch Remote System. Please read this manual thoroughly before installation and operation, and retain it for future reference.

PRODUCT OVERVIEW

The Stanley 37204 system allows you to wirelessly control lights and other electrical devices. It includes three wireless outlets and two remote transmitters. The units are pre-programmed for immediate use and offer individual control for each outlet, as well as an all-on/all-off function.



Image 1: Components of the Stanley 37204 Wireless Light Switch Remote System. This image displays two white remote

transmitters on the left and three white wireless outlets on the right, illustrating the complete system package.

Key Features:

- Wireless control for hard-to-reach lights and appliances.
- Potential for energy saving by easily turning off unused appliances.
- Operating range of up to 100 feet.
- Each receiver features one grounded outlet, rated for 15 Amps.
- Two touch-sensing remote transmitters included.

IMPORTANT SAFETY INFORMATION

- **WARNING:** For indoor use only. Do not expose to moisture or extreme temperatures.
- **CAUTION:** Do not exceed the maximum electrical ratings of 15 Amps or 1875 Watts.
- Ensure the device is properly grounded.
- Do not attempt to disassemble or modify the product.
- Keep out of reach of children.

SETUP INSTRUCTIONS

1. **Unpack Components:** Carefully remove all wireless outlets and remote transmitters from the packaging.
2. **Install Remote Batteries:** The remote transmitters come with lithium batteries included. Ensure they are properly seated. If replacing, use a CR2032 type battery.
3. **Plug in Wireless Outlets:** Insert each wireless outlet into a standard 120V AC wall receptacle. Ensure the outlet is easily accessible for initial setup.
4. **Connect Appliances:** Plug the appliance or light you wish to control into the grounded outlet on the wireless receiver. Ensure the appliance's power switch is in the "ON" position.
5. **Initial Pairing (Pre-programmed):** The units are typically pre-programmed at the factory. Test functionality by pressing the "ON" and "OFF" buttons on the remote for each corresponding outlet. Each remote has three pairs of ON/OFF buttons (I, II, III) to control up to three individual outlets. There is also an "ALL ON" and "ALL OFF" button.
6. **Manual Pairing (If needed):** If an outlet does not respond to a remote, follow these steps to manually pair:
 - Plug the wireless outlet into a wall receptacle.
 - Within 5 seconds of plugging it in, press and hold the desired "ON" button (I, II, or III) on the remote transmitter for approximately 3 seconds.
 - The outlet should respond, indicating successful pairing.
 - Repeat for any other outlets or if you wish to change which remote button controls which outlet.



Image 2: Demonstrates the use of the Stanley wireless remote control with an outlet. A hand holds the remote, aiming it at a wireless outlet plugged into a wall, which has a green power cord connected to it.

OPERATING INSTRUCTIONS

Once the wireless outlets are plugged in and paired with the remote transmitters, operation is straightforward:

- **Individual Control:** Press the "ON" button (I, II, or III) corresponding to the desired outlet to turn the connected appliance ON. Press the respective "OFF" button to turn it OFF.
- **All On/Off:** Use the "ALL ON" button to activate all paired outlets simultaneously. Use the "ALL OFF" button to deactivate all paired outlets simultaneously.
- **Range:** The system operates up to 100 feet in open areas. Obstructions like walls and metal structures may reduce the effective range.

MAINTENANCE

- **Cleaning:** Wipe the devices with a soft, dry cloth. Do not use liquid cleaners or solvents.
- **Battery Replacement:** If a remote transmitter becomes unresponsive, replace its lithium battery (CR2032). To replace, open the battery compartment on the back of the remote, remove the old battery, and insert a new one with the correct polarity.
- **Storage:** Store the system in a cool, dry place when not in use for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Outlet does not respond to remote.	<ul style="list-style-type: none"> • Outlet not powered. • Remote battery is low or dead. • Outlet and remote not paired. • Out of range. 	<ul style="list-style-type: none"> • Ensure the wall receptacle has power. • Replace the remote battery (CR2032). • Perform manual pairing as described in the Setup section. • Move closer to the outlet.
Appliance connected to outlet does not turn on.	<ul style="list-style-type: none"> • Appliance's power switch is OFF. • Appliance is faulty. 	<ul style="list-style-type: none"> • Ensure the appliance's power switch is in the "ON" position. • Test the appliance by plugging it directly into a working wall outlet.
Remote buttons are inconsistent or overly sensitive.	<ul style="list-style-type: none"> • Low remote battery. • Environmental interference. 	<ul style="list-style-type: none"> • Replace the remote battery (CR2032). • Ensure no other wireless devices are causing interference nearby.

SPECIFICATIONS

Model Number:	37204
Input Voltage:	120 Volts AC
Max Current Rating:	15 Amps
Max Wattage:	1875 Watts
Wireless Range:	Up to 100 feet (line of sight)
Remote Battery Type:	CR2032 Lithium (included)
Number of Outlets:	3
Number of Transmitters:	2
Material:	Plastic
Certification:	FCC
Dimensions (Outlet):	Approximately 3.81 x 6.35 x 10.16 cm (1.5 x 2.5 x 4 inches)
Weight (System):	265 g (0.58 lbs)




WARRANTY AND SUPPORT

Specific warranty details and direct customer support contact information were not provided in the product data. For warranty claims or technical assistance, please refer to the product packaging or contact Stanley

customer service through their official website or the retailer where the product was purchased.

© 2023 Stanley. All rights reserved.

Related Documents - 37204

 <p>STANLEY QUICK START GUIDE GUIA DE INICIO RÁPIDO GUIDE DE DÉMARRAGE RAPIDE</p> <p>2-Outlet Indoor Remote Control Remoto para interiores con 2 Enchufe Iluminado pour intérieur avec 2 prise</p> <p>Customer Service / Servicio al Cliente / Servizio Clienti 1-800-735-3107 • 1-604-1-6961 • 6961 ES1 Modelo / Modelo / Modelo # PK303</p>	<p>Stanley PK303 2-Outlet Indoor Remote Quick Start Guide</p> <p>This guide provides instructions for installing and pairing the Stanley PK303 2-Outlet Indoor Remote Control. It covers pairing new transmitters and resetting existing pairings.</p>
 <p>STANLEY SRP 4960 COMPACTION REVERSIBLE PLATE</p> <p>SRP 4960 PARTS MANUAL</p>	<p>Stanley SRP 4960 Compaction Reversible Plate Parts Manual</p> <p>Comprehensive parts manual for the Stanley SRP 4960 Compaction Reversible Plate, detailing all components, part numbers, quantities, and assembly kits. Includes technical specifications, adhesive torque conversions, and maintenance information.</p>
 <p>STANLEY CO25 HYDRAULIC CUT-OFF SAW</p> <p>USER MANUAL Safety, Operation and Maintenance</p>	<p>STANLEY CO25 Hydraulic Cut-Off Saw User Manual</p> <p>This user manual provides comprehensive safety, operation, and maintenance instructions for the STANLEY CO25 Hydraulic Cut-Off Saw. It includes specifications, troubleshooting, and parts information.</p>
 <p>STANLEY CH18 HYDRAULIC CHIPPING HAMMER</p> <p>Safety, Operation and Maintenance USER MANUAL</p>	<p>Stanley CH18 Hydraulic Chipping Hammer User Manual: Safety, Operation, and Maintenance</p> <p>Comprehensive user manual for the Stanley CH18 Hydraulic Chipping Hammer, covering safety precautions, operating procedures, maintenance guidelines, troubleshooting, and specifications. Essential reading for safe and effective use.</p>
 <p>STANLEY PP10 HYDRAULIC POST PULLER</p> <p>Safety and Operation Manual</p> <p>Focused on performance™</p>	<p>Stanley PP10 Hydraulic Post Puller: Safety and Operation Manual</p> <p>This manual provides essential safety, operation, and maintenance instructions for the Stanley PP10 Hydraulic Post Puller. Learn about proper usage, hydraulic requirements, troubleshooting, and warranty information to ensure safe and effective operation.</p>



© 2018 Stanley Access Technologies. All rights reserved. This document is the property of Stanley Access Technologies. It is intended for use only for the specific product and model mentioned. No part of this document may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, without the prior written permission of Stanley Access Technologies.

[Stanley MC521 PRO Control Box Quick-Reference Guide for Magic-Swing, Magic-Force, Bifold Operators](#)

This quick-reference guide from Stanley Access Technologies provides essential information on wiring, installation, and tune-in procedures for the MC521 PRO control box, compatible with Magic-Swing, Magic-Force, and Bifold automatic door operators.