

[Manuals.plus](#) /

> [foxydry](#) /

> foxydry Mini Ceiling Mounted Clothes Drying Rack - Model 120 Gray User Manual

foxydry Foxydry Mini

foxydry Mini Ceiling Mounted Clothes Drying Rack

MODEL: 120 GRAY

User Manual

Introduction

The foxydry Mini is a ceiling-mounted clothes drying rack designed to optimize space in your home. This vertical folding laundry airer features a pulley system for easy raising and lowering, making it suitable for both indoor and outdoor use. When not in use, the rack retracts discreetly to the ceiling, maintaining a tidy and clutter-free environment.



Image: The foxydry Mini clothes drying rack in its lowered position, holding various garments for drying.

Safety Information

- Ensure the drying rack is securely mounted to a structurally sound ceiling or wall according to the installation instructions.
- Do not exceed the maximum weight capacity of 10 kg (22 lbs) to prevent damage or injury.
- Keep children and pets away from the drying rack during operation to avoid entanglement or injury.
- Regularly inspect all components, including ropes, pulleys, and mounting hardware, for signs of wear or damage. Replace any worn parts immediately.
- Avoid hanging heavy, bulky items that could cause uneven weight distribution or strain the mechanism.

Package Contents

The foxydry Mini package includes all necessary components for assembly and installation. Please verify that all parts are present before beginning installation:

- Drying rack frame (aluminum)

- 8 aluminum rods (120 cm length for this model)
- Pulley mechanism with chain
- Mounting brackets and hardware (wall plugs and screws)
- Installation template
- Allen wrenches for assembly

Setup and Installation

Installation of the foxydry Mini is designed to be straightforward. It is recommended to have a second person assist during certain steps. Ensure you have appropriate tools such as a drill, level, and measuring tape.

1. **Choose Location:** Select a suitable ceiling or wall area that can support the weight of the rack and wet laundry (up to 10 kg). Ensure there is enough clearance for the rack to be fully lowered and raised.
2. **Mark Mounting Points:** Use the provided installation template to accurately mark the drilling points for the mounting brackets on your ceiling. For ceiling joists, drill pilot holes and avoid over-tightening screws.
3. **Install Brackets:** Securely attach the mounting brackets to the marked points using the supplied wall plugs and screws.
4. **Assemble Frame:** Assemble the main frame of the drying rack according to the diagrams in the detailed manual. Attach the aluminum rods.
5. **Mount Rack to Brackets:** Carefully lift the assembled rack and attach it to the installed mounting brackets. Ensure it is securely fastened.
6. **Install Pulley System:** Thread the ropes through the pulley mechanism as instructed. The chain mechanism is designed for smooth operation.
7. **Adjust Ropes:** Use a level to ensure the rack is plumb and square to the ceiling when raised. Adjust the rope lengths as needed for proper balance and movement.



Image: A detailed view of the pulley system and the aluminum frame, highlighting the components involved in raising and lowering the rack.


Your browser does not support the video tag.

Video: An official demonstration of the foxydry Mini ceiling clothes drying rack in operation, showing its lowering and raising functionality.

Operating Instructions

The foxydry Mini is designed for effortless operation using its integrated pulley and chain system.

- **To Lower the Rack:** Gently pull the chain downwards. The rack will smoothly descend to your desired height, up to 180 cm from the ceiling. Release the chain to lock the rack in place.
- **To Load Laundry:** Once lowered, hang your clothes on the 8 aluminum rods. Distribute the weight evenly across the rods to ensure stability and prevent strain on the mechanism.
- **To Raise the Rack:** Pull the chain upwards. The rack will ascend towards the ceiling. Release the chain to lock it at any height, or allow it to fully retract for maximum space-saving.



Light to lift

- ✓ **no effort** in the lifting
- ✓ The rack can stop at **any height**

Image: A close-up shot of the pulley and chain system, illustrating how to operate the drying rack.

Your browser does not support the video tag.

Video: A demonstration of the foxydry Mini pulley system, showing how the rack is easily raised and lowered for use.

Maintenance

To ensure the longevity and optimal performance of your foxydry Mini, follow these maintenance guidelines:

- **Cleaning:** Wipe down the aluminum rods and frame with a damp cloth and mild detergent as needed. Avoid abrasive cleaners that could damage the finish.
- **Lubrication:** Periodically check the pulley mechanism. If movement becomes stiff, apply a small amount of silicone-based lubricant to the moving parts.
- **Inspection:** Regularly inspect the ropes, chain, and mounting points for any signs of fraying, wear, or loosening. Address any issues promptly.
- **Outdoor Use:** While designed for outdoor use, prolonged exposure to extreme weather conditions may accelerate wear. Consider retracting the rack when not in use during harsh weather.



Image: A close-up view highlighting the durable aluminum and stainless steel construction of the foxydry Mini, designed for long-lasting use.

Troubleshooting

Problem	Possible Cause	Solution
Rack does not lower/raise smoothly	Ropes tangled, pulleys stiff, uneven weight distribution.	Check ropes for tangles. Lubricate pulleys. Redistribute laundry weight.
Rack is unstable or sways	Loose mounting, overloaded, unevenly loaded.	Check and tighten mounting screws. Do not exceed 10 kg. Distribute weight evenly.
Missing parts after unboxing	Packaging error or transit damage.	Contact foxydry customer support immediately for replacement parts.

Specifications

- **Model:** Foxydry Mini

- **Size:** 120 cm (50.39 inches)
- **Color:** Gray
- **Material:** Aluminum, Stainless Steel
- **Product Dimensions (Lowered):** 21.26"D x 50.39"W x 70.86"H (54cm D x 128cm W x 180cm H)
- **Product Dimensions (Retracted):** 9.84"H (25cm H)
- **Weight Limit:** 10 Kilograms (22 Pounds)
- **Special Features:** Collapsible, Long Lasting, Pulley System
- **Assembly Required:** Yes




Image: A technical diagram illustrating the open and closed dimensions of the foxydry Mini, including height, width, and depth measurements.

Warranty and Support

The foxydry Mini comes with a **2-year warranty** from the date of purchase, covering manufacturing defects. For warranty claims, technical support, or to order replacement parts, please contact foxydry customer service through their official website or the retailer where the product was purchased.

Your browser does not support the video tag.

Video: A short clip demonstrating the foxydry Mini in a laundry room, highlighting its compact and efficient design.

Your browser does not support the video tag.

Video: An overview of the foxydry Mini, showcasing its features and benefits as a ceiling-mounted clothes drying solution.