

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Ultimate Ears](#) /
- › [Ultimate Ears WONDERBOOM 2 Portable Wireless Bluetooth Speaker Instruction Manual](#)

## Ultimate Ears WONDERBOOM 2

# Ultimate Ears WONDERBOOM 2 Portable Wireless Bluetooth Speaker

Model: WONDERBOOM 2 (984-001550)

Brand: Ultimate Ears

## PRODUCT OVERVIEW

---

The Ultimate Ears WONDERBOOM 2 is a highly portable wireless Bluetooth speaker designed to deliver surprisingly big 360-degree sound. It features an all-new Outdoor Boost mode for louder, crisper audio tuned for outdoor listening. With a robust 13-hour battery life, it is built to last through extended use. The speaker boasts an IP67 rating, making it super waterproof, dustproof, and even floatable, suitable for various environments including pools, beaches, and showers. For an enhanced audio experience, two WONDERBOOM 2 speakers can be wirelessly paired for a bigger stereo or mono sound. Its convenient loop, dirt-resistant, and drop-proof design make it an ideal companion for bikes, backpacks, and outdoor adventures. Music control is straightforward, allowing users to play, pause, and skip tracks directly from the speaker without needing to access their phone. It is compatible with smartphones, tablets, and other devices supporting Bluetooth and Bluetooth Smart wireless audio profile (A2DP).

## WHAT'S IN THE BOX

---

- WONDERBOOM 2 Speaker
- Micro USB Cable

## SETUP

---

### Charging the Speaker

Before first use, fully charge your WONDERBOOM 2 speaker. Connect the included micro USB cable to the charging port on the speaker and a compatible USB power source. A full charge takes approximately 2.6 hours and provides up to 13 hours of playback time.



Image: Ultimate Ears WONDERBOOM 2 speaker in Bermuda Blue with its micro USB charging cable.

## Bluetooth Pairing

To pair your WONDERBOOM 2 with a Bluetooth device:

1. Power on the WONDERBOOM 2 by pressing the power button located on the top of the speaker.
2. Press and hold the Bluetooth pairing button (small dot icon) on the top of the speaker until you hear a tone and the LED light flashes rapidly.
3. On your device (smartphone, tablet, etc.), go to Bluetooth settings and select "WONDERBOOM 2" from the list of available devices.
4. Once paired, you will hear a confirmation tone, and the LED light on the speaker will glow solid.




Image: Bottom view of Ultimate Ears WONDERBOOM 2 speaker showing power, Bluetooth pairing, and outdoor boost buttons.

Video: Official product video demonstrating the key features and ease of use of the Ultimate Ears WONDERBOOM 2 speaker, including power on and Bluetooth pairing.

## OPERATING INSTRUCTIONS

### Power On/Off

Press the power button on the top of the speaker to turn it on or off.

### Volume Control

Use the large '+' and '-' buttons on the front of the speaker to adjust the volume.

### Play/Pause/Skip

Press the center button on the top of the speaker once to play or pause music. Double-press the center button to skip to the next track.

### Outdoor Boost Mode

For louder and crisper audio specifically tuned for outdoor listening, press the 'tree' icon button located on the bottom of the speaker. This activates Outdoor Boost mode.

## **Double Up Mode (Stereo Pairing)**

To achieve a wider soundstage or louder volume, you can pair two WONDERBOOM 2 speakers together:

1. Ensure both WONDERBOOM 2 speakers are powered on.
2. On one speaker, press and hold the center button (play/pause) for a few seconds until you hear a tone.
3. Repeat this action on the second speaker.
4. The speakers will connect, and you will hear a confirmation tone, indicating they are now playing in stereo or mono mode.

Video: Official product video providing a general overview of the Ultimate Ears WONDERBOOM 2 speaker, showcasing its design and basic controls.

## **KEY FEATURES**

---

### **Waterproof, Dustproof & Floatable (IP67 Rated)**

The WONDERBOOM 2 is designed to withstand immersion in water up to 1 meter for 30 minutes. Its dustproof construction ensures durability in various environments, and its ability to float makes it perfect for poolside or beach use.



Image: Ultimate Ears WONDERBOOM 2 speaker floating in blue water.



Image: Hand pouring water over an Ultimate Ears WONDERBOOM 2 speaker, demonstrating its waterproof and dustproof features.

Video: Official product video highlighting the waterproof, floatable, and portable design of the Ultimate Ears WONDERBOOM 2 speaker, ideal for outdoor activities.

### **Surprisingly Bigger 360 Sound with Outdoor Boost**

Experience immersive audio from every angle. The Outdoor Boost feature enhances loudness and clarity, making your music sound great even in open-air environments.

# BIGGER 360 SOUND WITH OUTDOOR BOOST



Image: Two people outdoors with an Ultimate Ears WONDERBOOM 2 speaker, highlighting 360 sound and outdoor boost.

## Epic 13-Hour Battery Life

Enjoy your music for longer with up to 13 hours of continuous playback on a single charge, perfect for day trips and extended adventures.

# EPIC 13 HR BATTERY LIFE



Image: Two people relaxing on a beach with an Ultimate Ears WONDERBOOM 2 speaker, emphasizing 13-hour battery life.

## Double Up, Now in True Stereo

Pair two WONDERBOOM 2 speakers to amplify your sound. Enjoy true stereo separation for an even more immersive listening experience.



Image: Two people sitting with two Ultimate Ears WONDERBOOM 2 speakers, illustrating the Double Up stereo pairing feature.

## MAINTENANCE

---

### Cleaning

To clean your WONDERBOOM 2, ensure the charging port cover is securely closed. Use a soft, damp cloth to wipe down the speaker. Avoid using harsh chemicals or abrasive cleaners.

### Storage

Store the speaker in a cool, dry place when not in use. Avoid extreme temperatures.

## TROUBLESHOOTING

---

- **No Power:** Ensure the speaker is charged. Connect it to a power source using the micro USB cable.
- **Cannot Pair:** Make sure the speaker is in Bluetooth pairing mode (flashing LED). Check your device's Bluetooth settings and ensure it's discoverable. Try restarting both the speaker and your device.
- **Poor Sound Quality:** Ensure the speaker is within the 100 ft Bluetooth range of your device. Check for obstructions between the speaker and your device. Adjust the volume on both the speaker and your device.
- **Outdoor Boost Not Working:** Press the 'tree' icon button on the bottom of the speaker to activate or

deactivate Outdoor Boost mode.

For more detailed troubleshooting, please refer to the official Ultimate Ears support website.

## **SPECIFICATIONS**

---

Feature	Detail
Model Name	Wonderboom 2
Speaker Type	Outdoor
Special Feature	Noise Cancellation
Recommended Uses	Pool, Outdoor, Beach
Compatible Devices	Phones, Smartphone, Tablet
Unit Count	1.0 Count
Surround Sound Channel Configuration	2.0
Color	Bermuda Blue
Included Components	WONDERBOOM 2, micro USB cable
Product Dimensions	3.68"D x 3.68"W x 4.02"H
Item Weight	425 Grams (15 ounces)
Is Waterproof	TRUE (IP67)
Warranty Type	Limited
Maximum Range	100 Feet (30.48 Meters)
Number of Items	1
Control Method	App
Wireless Communication Technology	Bluetooth
Power Source	Battery Powered
Water Resistance Level	Waterproof
Number of Batteries	1 Lithium Polymer batteries required
Audio Driver Type	Dynamic Driver
Battery Capacity	13000 Milliamp Hours
Charging Time	2.6 Hours
Manufacturer	Ultimate Ears
Speaker Maximum Output Power	10 Watts
Connectivity Technology	Bluetooth
Audio Output Mode	Stereo
Mounting Type	Freestanding

## WARRANTY AND SUPPORT

---

The Ultimate Ears WONDERBOOM 2 comes with a Limited Warranty. For specific warranty details, product registration, and technical support, please visit the official Ultimate Ears website or contact their customer service. Keep your proof of purchase for warranty claims.