

Monte Carlo 3MAVR70BKD

Monte Carlo Maverick Max 70" Ceiling Fan Instruction Manual

MODEL: 3MAVR70BKD

1. Introduction

Welcome to your Monte Carlo Maverick Max 70" Ceiling Fan. This manual provides essential information for the safe installation, operation, and maintenance of your new ceiling fan. Please read all instructions carefully before beginning installation and retain this manual for future reference.

2. Safety Information

- Always disconnect power at the main fuse box or circuit breaker before beginning installation or performing any maintenance.
- All electrical connections must be in accordance with local codes, ordinances, or national electrical codes. If you are unfamiliar with electrical wiring, consult a qualified electrician.
- The ceiling fan must be mounted to a structurally sound ceiling joist or an outlet box approved for fan support. Ensure the mounting structure can support the fan's weight (13.2 lbs).
- Ensure there is adequate clearance between the fan blades and any obstacles, including walls and furniture.
- This fan is CUL Approved for DAMP Locations, making it suitable for covered outdoor areas like patios.
- Do not insert objects into the path of the fan blades while the fan is operating.

3. Package Contents

Verify that all components listed below are included in your package:

- Ceiling Fan Motor Assembly
- 3 Balsa Wood Blades
- Integrated LED Light Kit
- Hand-Held Remote Control
- Downrod (6 inches)

- Mounting Hardware
- Vaulted Canopy (for sloped ceilings)

4. Installation

Follow these steps for proper installation of your ceiling fan. It is recommended to have two people for installation.

1. **Pre-Installation Checklist:** Ensure power is turned off at the circuit breaker. Gather all necessary tools (screwdriver, wire strippers, ladder, etc.).
2. **Mounting the Bracket:** Securely attach the mounting bracket to an approved ceiling outlet box or a structural ceiling joist. Ensure all screws are tightened.
3. **Assembling the Fan:** Carefully attach the downrod to the fan motor assembly. Feed the electrical wires from the fan through the downrod.
4. **Wiring:** Connect the electrical wires from the ceiling to the fan's wiring according to the wiring diagram provided in the separate wiring instructions. Ensure all connections are secure and insulated.
5. **Attaching Blades:** Securely attach the three balsa wood blades to the fan motor assembly using the provided screws. Ensure blades are firmly attached.
6. **Installing Light Kit:** Connect the integrated LED light kit's wiring to the fan's light wiring. Carefully attach the light kit to the fan housing.



Figure 1: Monte Carlo Maverick Max 70-inch ceiling fan installed. This image shows the fan with three matte black balsa wood blades and an integrated LED light, mounted on a white ceiling.

5. Operating Instructions

Your Monte Carlo Maverick Max ceiling fan is controlled by a hand-held remote control. Ensure the remote has fresh batteries installed.

- **Power On/Off:** Press the power button on the remote to turn the fan and light on or off.
- **Fan Speed Control:** Use the fan speed buttons to cycle through the 6 available fan speeds.
- **Light Control:** Press the light button to turn the integrated LED light on or off. To dim the light, press and hold the light button until the desired brightness is achieved.
- **Reverse Function:** The remote control includes a button to reverse the fan's blade direction. This function is useful for seasonal comfort:
 - **Downward Airflow (Summer):** Creates a cooling effect.
 - **Upward Airflow (Winter):** Circulates warm air trapped near the ceiling.

6. Maintenance

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may damage the finish or blades.
- **Blade Care:** Periodically check all blade attachment screws for tightness. It is normal for them to loosen over time.
- **Light Source:** The LED light kit is integrated and designed for long-term use. No bulb replacement is necessary.

7. Troubleshooting

If you experience issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Remote control batteries are dead; Loose wire connections.	Check circuit breaker/fuse; Replace remote batteries; Verify all wire connections are secure.
Fan wobbles	Loose blade screws; Improperly mounted fan.	Tighten all blade screws; Ensure mounting bracket is securely fastened to the ceiling.
Light does not work	Loose wire connection to light kit; Remote control batteries are dead.	Check light kit wiring; Replace remote batteries.
Remote not responding	Dead batteries; Interference.	Replace remote batteries; Ensure no strong radio frequency interference nearby.

8. Specifications

- **Brand:** Monte Carlo
- **Model Name:** 3MAVR70BKD
- **Product Dimensions:** 70" Diameter x 13.8" Height (from ceiling to bottom of fan light, includes 6" downrod)
- **Item Weight:** 13.2 lbs
- **Number of Blades:** 3
- **Blade Material:** Balsa Wood
- **Blade Span:** 70 Inches
- **Blade Pitch:** 13 Degrees
- **Air Flow Capacity:** 5943 Cubic Feet Per Minute (CFM)
- **Motor Type:** Premium Power 85 X 28 mm DC motor
- **Light Kit:** 18 Watt Integrated LED, Dimmable (3000K, 1100 Lumens, 90 CRI)
- **Control Method:** Hand-Held Remote Control (6 speeds, reversing function, light dimming)
- **Installation Type:** Flat and Sloped Ceilings (up to 15°)
- **Finish Type:** Matte Black
- **Indoor/Outdoor Usage:** Outdoor (CUL Approved for DAMP Locations)
- **Efficiency:** ENERGY STAR qualified, 25 watts (high-speed electricity use)
- **Voltage:** 120 Volts

9. Warranty and Support

For warranty details and technical support, please refer to the documentation included with your product or visit the official Monte Carlo website. Keep your purchase receipt as proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question