Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JVC HAF19MAH

JVC HAF19MAH Retro Earbuds User Manual

Model: HAF19MAH | Brand: JVC

1. Introduction and Overview

The JVC HAF19MAH Retro Earbuds are designed for a comfortable audio experience with a classic aesthetic. These wired earbuds feature a built-in microphone and remote control, offering convenience for music playback and call management. They are also sweat and splash-proof, making them suitable for active use.



Image: JVC HAF19MAH Retro Earbuds, showcasing their blue and grey design with the inline remote.

2. Setup

Setting up your JVC HAF19MAH Retro Earbuds is straightforward. These earbuds utilize a standard 3.5mm headphone jack for connectivity.

2.1 Connecting to Your Device

1. Locate the 3.5mm headphone jack on your audio device (smartphone, tablet, laptop, etc.).
2. Insert the 3.5mm plug of the earbuds firmly into the device's headphone jack until it clicks into place.
3. Ensure the connection is secure to prevent audio interruptions.

2.2 Device Compatibility

The JVC HAF19MAH earbuds are designed for broad compatibility, working seamlessly with most devices that feature a standard 3.5mm headphone jack, including Android phones and iOS devices (with appropriate adapters if needed, not included).






Image: Retail packaging of the JVC HAF19MAH Retro Earbuds, showing the product inside.

3. Operating Instructions

The JVC HAF19MAH earbuds feature an inline remote control with a single button and a built-in microphone for convenient operation.

3.1 Music Control

- **Play/Pause:** Press the single button once to play or pause your music.

3.2 Call Management

- **Answer/End Call:** Press the single button once to answer an incoming call or end an ongoing call.
- **Decline Call:** Press and hold the single button for approximately 2 seconds to decline an incoming call.

Video: An official product video demonstrating the features and usage of the JVC HAF19MAH Retro Earbuds with Microphone.

4. Features

The JVC HAF19MAH Retro Earbuds offer a blend of functionality and design:

- **Integrated Microphone and Remote:** Allows for easy control of music playback (play/pause) and hands-free call management (answer/end incoming calls).
- **Sweat and Splash Proof (IPX2):** Provides protection against light sweat and splashes, making them suitable for

workouts and outdoor activities.

- **3.3 Foot Cord:** A practical cord length for comfortable use with various devices.
- **Retro Shade Design:** Features a distinctive blue and grey color combination for a classic and fashionable appearance.






Image: A close-up view of one JVC HAF19MAH earbud, highlighting its design and ear tip.

5. Specifications

Specification	Detail
Model Name	HAF19MAH
Connectivity Technology	Wired
Included Components	Headphones
Item Weight	1.6 ounces
Water Resistance Level	Water Resistant (IPX2)
Product Dimensions	40 x 3.15 x 1.57 inches
Headphones Jack	3.5 mm Jack
Control Type	Remote (Single Button)
Cable Feature	Retractable
Ear Placement	In Ear
Form Factor	In Ear
Manufacturer	JVC
Country of Origin	China

6. Maintenance

Proper care and maintenance will help extend the lifespan of your JVC HAF19MAH Retro Earbuds.

- **Cleaning:** Regularly wipe the earbuds and cable with a soft, dry, lint-free cloth. Avoid using harsh chemicals, solvents, or abrasive cleaners.
- **Storage:** When not in use, store the earbuds in a clean, dry place. Avoid tangling the cable by coiling it neatly.

- **Moisture Protection:** While sweat and splash-proof, avoid submerging the earbuds in water or exposing them to heavy rain. Dry them thoroughly if they get wet.
- **Jack Care:** Keep the 3.5mm jack clean and free of dust or debris to ensure optimal connection.

7. Troubleshooting

If you encounter issues with your JVC HAF19MAH Retro Earbuds, try the following troubleshooting steps:

- **No Sound or Intermittent Sound:**
  - Ensure the 3.5mm jack is fully inserted into your device.
  - Check the volume level on your device.
  - Test the earbuds with another audio device to determine if the issue is with the earbuds or the original device.
  - Clean the 3.5mm jack on both the earbuds and your device to remove any dust or lint.
- **Microphone Not Working:**
  - Ensure the earbuds are fully plugged into your device.
  - Check your device's audio settings to ensure the correct microphone input is selected.
  - Test the microphone with another application or device.
- **Remote Control Not Responding:**
  - Ensure the earbuds are securely connected.
  - Some older devices or specific applications may not fully support all remote functions.

8. Warranty and Support

For information regarding warranty coverage, product registration, or technical support, please refer to the documentation included with your purchase or visit the official JVC website.
You can find more information and support resources on the JVC brand store:JVC Official Store on Amazon

© 2024 JVC. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07NHSXX9F

More documents and user manuals: **https://manuals.plus/**