Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEGO 40350

LEGO BrickHeadz 40350 Easter Chick Building Kit Instruction Manual

Model: 40350

1. Introduction

This manual provides comprehensive instructions for the assembly and care of your LEGO BrickHeadz 40350 Easter Chick Building Kit. This set allows you to construct a BrickHeadz-style Easter Chick character, complete with a decorative base featuring Easter flowers and eggs. Designed for builders aged 10 and older, this kit contains 120 LEGO elements.

2. What's in the Box

Upon opening your LEGO BrickHeadz 40350 Easter Chick Building Kit, you will find the following components:

- 120 assorted LEGO Building Elements
- Instruction booklet with 43 step-by-step visual guides



Image: The product box, showing the assembled Easter Chick and kit details.

3. Setup & Assembly

Follow the included instruction booklet for a detailed, step-by-step guide to assemble your LEGO BrickHeadz Easter Chick. The manual contains 43 visual steps to ensure accurate construction.

1. Unpack all LEGO elements and sort them by color and size to facilitate the building process.
2. Begin assembly by following the first step in the instruction booklet. Each step illustrates the pieces required and their placement.
3. Carefully connect the bricks as shown in the diagrams. Ensure all connections are firm to create a stable model.
4. Proceed through all 43 steps until the Easter Chick character and its decorative base are fully constructed.



Image: The fully assembled LEGO BrickHeadz Easter Chick model.



Image: A detailed view of the Easter Chick's face and body.

4. Operating Instructions (Display & Customization)

Once assembled, your LEGO BrickHeadz Easter Chick is ready for display. This model is designed as a decorative item.

- **Display:** Place the assembled Easter Chick on a flat, stable surface. Its compact size makes it suitable for shelves, desks, or as a seasonal centerpiece.
- **Customization:** LEGO BrickHeadz models are designed to be compatible with other BrickHeadz sets, allowing you to create unique hybrid characters or integrate them into larger displays.

5. Maintenance

To ensure the longevity and appearance of your LEGO BrickHeadz model, follow these maintenance guidelines:

- **Cleaning:** Dust the model regularly with a soft, dry cloth or a soft-bristled brush. For deeper cleaning, gently wash individual bricks with mild soap and lukewarm water (not hot water). Rinse thoroughly and air dry. Avoid harsh chemicals or abrasive materials.
- **Storage:** If disassembling for storage, keep all LEGO elements in a sealed container to prevent loss and protect them from dust and light.

6. Troubleshooting

Should you encounter any issues during assembly or with your completed model, consider the following:

- **Missing Pieces:** Double-check all packaging and sorting areas. If a piece is genuinely missing, please refer to the LEGO Customer Service section for assistance.
- **Difficulty Assembling:** Ensure you are following the instruction booklet step-by-step. Sometimes, a small error in an earlier step can affect later connections. Review previous steps carefully.
- **Stability Issues:** Verify that all bricks are firmly pressed together. Loose connections can lead to an unstable model.

7. Specifications

Brand	LEGO
Model Name	Easter Chick 40350
Model Number	6251951
Number of Pieces	120
Recommended Age	10+ years (Manufacturer Minimum Age: 72 months)
Item Dimensions (L x W x H)	5.55 x 4.8 x 2.4 inches
Item Weight	0.14 Kilograms
Color	Multicolor
Educational Objective	Creative Thinking

8. Warranty & Support

LEGO products are manufactured to high-quality standards. For any questions regarding missing parts, product defects, or assembly assistance, please contact LEGO Customer Service.

- **Online Support:** Visit the official LEGO website and navigate to the 'Customer Service' or 'Support' section for FAQs, replacement parts, and contact information.
- **Contact Information:** Specific contact details (phone numbers, email) can typically be found on the LEGO website or on the product packaging.

Please retain your proof of purchase for any warranty claims or support requests.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07NJ4RJYS

More documents and user manuals: **https://manuals.plus/**